



1	K40CNMDX	Top-shell, black (mounted-right)		
1	K40CNMDX	Top-shell, black (mounted-left)		
2	K48FNM	Bottom-shell, black (mounted)		
4	Z159RK	Bag lock lining, 1 pcs.		
6	Z210K	Chrome bushing for lock set		
7	Z312K	Hinge plate		
8	Z314NM2K	Hinge, complete black		
10	Z1632R	Oval KAPPA Logo, in aluminium, 1 pcs.		
11	Z217K	Push button		
12	Z106K	Bolt		
13	Z109K	Long bolt springs		

15	Z277K	Plate below lock		
16	Z115RK	Stop bag opening yarn, 2 pcs.		
17	K566	Elastic belt		
18	K622N902	Inserts Peints		
19	K623D	Direction indicator (right)		
20	K624D	Direction indicator (right)		
20	K624S	Direction indicator (left)		
21	K625	Plate for reflector with logo in relief		
23	Z590RK	Pin. Medium, 2 pcs.		
24	K500	Key lock complete of bushing and red cap		