



1	<b>K48CNM</b>	Top-shell, black (mounted)		
2	<b>K48FNM</b>	Bottom-shell, black (mounted)		
4	<b>Z159RK</b>	Bag lock lining, 1 pcs.		
6	<b>Z210K</b>	Chrome bushing for lock set		
7	<b>Z312K</b>	Hinge plate		
8	<b>Z314NM2K</b>	Hinge, complete black		
10	<b>Z1632R</b>	Oval KAPPA Logo, in aluminium, 1 pcs.		
11	<b>K558</b>	Plate for reflector		
12	<b>Z217K</b>	Push button		
13	<b>Z106K</b>	Bolt		

14	<b>Z109K</b>	Long bolt springs		
16	<b>Z277K</b>	Plate below lock		
17	<b>Z115RK</b>	Stop bag opening yarn, 2 pcs.		
18	<b>K566</b>	Elastic belt		
19	<b>K615</b>	Reflector		
20	<b>Z337K</b>	Top-case reflector		
22	<b>615KA</b>	White sticker for K615		
23	<b>Z590RK</b>	Pin. Medium, 2 pcs.		
24	<b>K500</b>	Key lock complete of bushing and red cap		