# babybrezza one step sterilizer dryer




Please visit
babybrezza.ca
©2017 Baby Brezza Enterprises LLC


### IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- 1. Read all instructions carefully before using your sterilizer.
- 2. Ensure that the supply voltage marked on the appliance corresponds with your mains supply.
- 3. If there is any visible damage to the appliance, the plug or to the supply cord, disconnect the appliance immediately and do not use it.
- 4. If the supply cord is damaged, it must be replaced by the distributor in order to avoid a hazard.
- 5. Do not allow children to touch or use the appliance. The appliance becomes very hot and the steam can cause severe scalding.
- 6. Do not move the appliance when it is in use or contains hot liquids.
- 7. Do not touch the hot surfaces.
- 8. Do not place the appliance on or near hot surfaces, in a heated oven or near a gas or electric heater.
- 9. Unplug the appliance from the power supply before cleaning or storage.
- 10. Do not immerse the supply cord, plug or base unit in water or any other liquid.
- 11. This appliance does not contain any user serviceable parts inside. Do not dismantle.
- 12. This appliance is for indoor household use only. Do not use outdoors.
- 13. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 14. This appliance has a polarized plug (one blade wider than the other). To reduce risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the pug in any way.
- 15. a) Short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
  - b) Extension cords are available and may be used if care is exercised in their use.
  - c) If an extension cord is used: The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance; The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally (especially by children).
- 16. Children should be supervised to ensure that they do not play with the appliance.
- 17. Not for space heating purpose.
- 18. Always use on a level heat resistant surface.
- 19. Always keep the electric sterilizer and its plug out of reach of small children.
- 20. To disconnect, turn any control "off", then remove plug from wall outlet.
- 21. Ensure water has been added to the base unit before the sterilization cycle is switched on.
- 22. Always add 120ml of water before use. If you put too little or too much water into the sterilizer, the high sterilization efficiency may not be reached.
- 23. Always unplug from the electric outlet when not in use. Allow to cool before putting on or taking off any parts.
- 24. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Please contact the distributor's Customer Service for more information.
- 25. The use of accessory attachments is not recommended by the appliance manufacturer as this may cause injuries.
- 26. This sterilizer is intended to be used in household and similar application such as a. staff kitchen areas in shops, offices and other working environments. b. farm houses. c. by clients in hotels, motels and other residential type of environments. d. bed and breakfast.
- 27. Do not open while in use as this product contains boiling water. Beware of escaping steam from the vent holes in the lid.
- 28. Allow at least 30 minutes interval between two operations and make sure the unit has been cooled down before pressing the start button for sequential use.
- 29. Steam escaping from the unit can cause burns. Always allow 5 minutes to cool down after the cycle finishes before lifting the lid.
- 30. KEEP CHILDREN AWAY from this sterilizer at all times.
- 31. To provide continued protection against risk of electric shock, connect to properly grounded outlets only.
- 32. CAUTION: Risk of electric shock, disconnect electric power before servicing.
- 33. Use only distilled water, bottled water or fresh running water to sterilize.
- 34. Never use any additives



## Control Panel and LCD screen



TECHNICAL DATA
Supply voltage: 120V ~ 60Hz

Model: BRZ0098 Power: 600W

# Set-up and Use

Before placing items in the appliance for sterilization it is important that all bottles, nipples and accessories are empty and that they are CLEAN and FULLY RINSED in fresh water.

- 1. Place the appliance on a flat surface where it is out of reach of children and it will not be knocked or moved during operation.
- 2. Remove the lid and accessory rack from the sterilizer base.
- 3. Pour distilled water on the stainless steel heater surface to MAX line (120ml). Never fill past MAX line.
- 4. Place the accessory rack on the base.
- 5. Place clean bottles with their opening facing downward on the lower posts of the accessory rack. Place the bottle accessories (e.g. nipple, collar, cap, etc) on the upper posts of accessory rack.
- 6. Place the lid on top of sterilizer base. Please ensure that the lid fits securely on the base without any gaps where the lid and base meet.
- 7. Plug the appliance into the power outlet.
- 8. Press the On/Off button once. The LCD will display "00:00" and the backlight will turn blue. Choose your desired function following the instructions below. If there is no selection of function after pressing on/off button, the appliance will automatically switch off.

#### Sterilize and Auto-Dry Function:

- 1. Choose the drying time (after steam sterilization): Press the \$\infty\$ Sterilize/Dry button one time for 45 minute dry time, two times for 60 minute dry time, three times for 30 minute dry time. The sterilize/dry cycle will start 3 seconds after the last button is pressed
- 2. When the sterilization cycle starts, the LCD will count up second-by-second for the duration of the sterilization cycle.
- 3. When the sterilization cycle is complete, the appliance will beep, pause for 3 seconds and begin the drying cycle for the amount of time selected in step 1. The timer on the LCD will count down second-by-second until it reaches 00:00.
- 4. When the drying cycle is completed, the appliance will beep 5 times and switch off automatically.

#### Sterilization only function:

- 1. Press the Sterilize button one time, the LCD will display "00:00" and the steam icon. The sterilization cycle will start 3 seconds after pressing the sterilize button and the LCD will count up second-by-second for the duration of the sterilization cycle.
- 2. When the sterilization cycle is complete, the appliance will beep 5 times and switch off automatically.

#### Dryer only function:

- 1. Press the Dry button one time for 30 minute dry time, two times for 45 minute dry time, three times for 60 minute dry time. The drying cycle will start 3 seconds after the last button is pressed and the timer on the LCD will count down second-by second until it reaches 00:00.
- 2. When the drying cycle is completed, the appliance will beep 5 times and switch off automatically.

Caution: If it is necessary to remove water from the base, always POUR AWAY FROM FAN OPENING. Note water pour direction icon on base, and pour in direction of arrow.



#### Cleaning

- Always unplug your product before cleaning.
- Do not immerse the base, the supply cord or the plug in water or other liquids.
- Do not clean base under water tap.
- Use a soft damp cloth to clean the base and control console.
- Never use abrasive pads to clean the plastic parts of the machine.
- The lid, accessory rack can be cleaned in hot soapy water.
- Mineral residue, particularly in hard water areas, may deposit on the stainless steel heating plate after a few sterilization cycles. To avoid scale build up, wipe the surfaces with a soft moist cloth after each operation.
- Deposits can be removed with proprietary scale removers or by leaving 30ml water and vinegar solution (1 part vinegar to 4 parts water) on the heating bowl for approximately 30 minutes. The bowl should then be wiped clean with a clean, dry cloth. Some discoloration spots may remain after cleaning with a vinegar solution, but these are harmless.
- Do not use abrasives or solvents for cleaning; they may damage the appliance and the surface of the heating bowl.
- Dismantle the filter box and clean the filter once a month. Make sure the filter is fully dried before placing back to the filter box.

# Troubleshooting

Condition	Possible Cause	Remedy
Appliance will not start.	Unit is unplugged.	Make sure the plug is securely inserted into the power outlet.
	Unit is not turned on.	Press On/Off switch before choosing function.
	Insufficient water is in heater plate area.	Add 120ml water to heater plate area.
Scaling on water tank heater plate.	Mineral rich water used persistently.	Clean heater plate after each use and use distilled water.

#### **Limited 1-Year Warranty**

The limited warranty is valid only on products bought through authorized resellers and used in Canada. Buying through an unauthorized reseller or using this product outside of Canada automatically voids this warranty. This warranty is available to consumers only. You are a consumer if you own a Baby Brezza\* Sterilizer Dryer that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners. We warrant that your Baby Brezza\* Sterilizer Dryer will be free of defects in material or workmanship under normal home use for one year from the date of original purchase. Customer will be required to present original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture. If your Baby Brezza\* Sterilizer Dryer should prove to be defective within the warranty period, we will repair it or, if we consider it necessary, replace it.

To obtain warranty services, please call Customer Service at 1-800-667-8184 or write to: service@elfe.ca

DISTRIBUTED BY:
ELFE JUVENILE PRODUCTS
4500 THIMENS BLVD
SAINT-LAURENT (QC) H4R 2P2
service@elfe.ca www.elfe.com
1-800-667-8184