












Machine	Explode	Code	Description
FT693-A Apuro Bain Marie	1		Water Pan
FT693-A Apuro Bain Marie	2		Frame
FT693-A Apuro Bain Marie	3	AL194	Indicator Light
FT693-A Apuro Bain Marie	4	N146	On/Off Switch
FT693-A Apuro Bain Marie	5	AC885	LH Temperature Thermostat
FT693-A Apuro Bain Marie	6	AL195	Chrome Knob
FT693-A Apuro Bain Marie	10		Small Alu Plate
FT693-A Apuro Bain Marie	11	AL197	Auto Recover Thermostat
FT693-A Apuro Bain Marie	12		Pressure Plate for Thermostat Sensor
FT693-A Apuro Bain Marie	13		Main Screw
FT693-A Apuro Bain Marie	14		Bottom Plate
FT693-A Apuro Bain Marie	15	AC883	Rubber Feet
FT693-A Apuro Bain Marie	16		Cover for Heating Element
FT693-A Apuro Bain Marie	17		Pressure Sticker
FT693-A Apuro Bain Marie	18	AL198	Heating Element 1200W
FT693-A Apuro Bain Marie	19		Pressure Plate
FT693-A Apuro Bain Marie	20	AL199	Manual Thermostat
FT693-A Apuro Bain Marie	21		Alu. Plate
FT693-A Apuro Bain Marie	22	AC882	Strain Relief Bushing
FT693-A Apuro Bain Marie	23		Power Cord