



Machine	Explode	Code	Description
FT694-A Apuro Bain Marie with Tap without Pans	1		Water Pan
FT694-A Apuro Bain Marie with Tap without Pans	2		Frame
FT694-A Apuro Bain Marie with Tap without Pans	3	AL194	Indicator Light
FT694-A Apuro Bain Marie with Tap without Pans	4	N146	On/Off Switch
FT694-A Apuro Bain Marie with Tap without Pans	5	AC885	LH Temperature Thermostat
FT694-A Apuro Bain Marie with Tap without Pans	6	AL195	Chrome Knob
FT694-A Apuro Bain Marie with Tap without Pans	7	AC892	Round Alu Connector for Drain Tube
FT694-A Apuro Bain Marie with Tap without Pans	8	AC890	Oblong Drain Alu Tube
FT694-A Apuro Bain Marie with Tap without Pans	9	AL196	Tap
FT694-A Apuro Bain Marie with Tap without Pans	10		Small Alu Plate
FT694-A Apuro Bain Marie with Tap without Pans	11	AL197	Auto Recover Thermostat
FT694-A Apuro Bain Marie with Tap without Pans	12		Pressure Plate for Thermostat Sensor
FT694-A Apuro Bain Marie with Tap without Pans	13		Main Screw
FT694-A Apuro Bain Marie with Tap without Pans	14		Bottom Plate
FT694-A Apuro Bain Marie with Tap without Pans	15	AC883	Rubber Feet
FT694-A Apuro Bain Marie with Tap without Pans	16		Cover for Heating Element
FT694-A Apuro Bain Marie with Tap without Pans	17		Pressure Sticker
FT694-A Apuro Bain Marie with Tap without Pans	18	AL198	Heating Element 1200W
FT694-A Apuro Bain Marie with Tap without Pans	19		Pressure Plate
FT694-A Apuro Bain Marie with Tap without Pans	20	AL199	Manual Thermostat
FT694-A Apuro Bain Marie with Tap without Pans	21		Alu. Plate
FT694-A Apuro Bain Marie with Tap without Pans	22	AC882	Strain Relief Bushing
FT694-A Apuro Bain Marie with Tap without Pans	23		Power Cord