










Machine	Explode	Code	Description
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	1		Triangle Plate
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	2	N117	Breaker
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	3	AK916	Heating Element
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	4		Gasket
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	5	AH342	Switch
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	6	AC608	Oil Pan Assembly
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	7	AD585	Indicator Light
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	8	N116	Thermostat
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	9	N152	Feet
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	10	AK361	Knob
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	11		Stuffing Nut
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	12	N283	Basket
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	13		Electrical Box Assy
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	14		Electrical Box Assembly
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	15	AK556	Handle
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	16	AK365	Cover Assembly
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	17		Main Body Assy
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	18	AH040	Switch
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	19	AK559	Bushing
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	20		Teflon Stick
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	21		Baffle Assy
FB970-A Apuro Single Fryer - 5Ltr 2.2kW	22		Power Cord