



Machine	Explode	Code	Description
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	1		Electric Box Back Cover
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	2	N116	Thermostat
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	3	AK361	Knob
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	4		Baffle Plate
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	5	AF054	Heating Element
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	6		Sensor Clamp
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	7	N302	Drain Tap
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	8	AK367	Oil Pan Assembly
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	9	AK368	Basket
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	10	AK366	Cover Assy
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	11		Handle
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	12	AH040	Switch
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	13	AD585	Indicator Light (Green)
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	14	AE837	Eletronic Timer Assy
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	15	N117	Breaker
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	16	AH342	Switch
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	17		Left Complete Fryer Head/Eletronic Box Assy
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	18		Right Complete Fryer Head/ Eletronic Box Assy
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	N/A	DF502	Stand
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	N/A		AUS Power Cord
Apuro Double Fryer - 2 x 8Ltr 2.9kW with Timer	N/A		Timer Decal