















Machine	Explode	Code	Description
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	1		Lid Handle
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	2		S/S Lid
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	3		Body Handle
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	4		S/S Reservoir
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	5	AF336	Tap
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	6		Thermal Cut out
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr			Manual-Reset Assembly
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	7		Steel Support Bracket
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	8		S/S Base
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	9		Bottom Cover
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	10		Plastic Foot
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	11	AK110	Temperature Dial
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	12	AK818	105C Thermostat
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	13		Red Control Light
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr			Green Control Light
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	14		Power Cord& Plug
GL349-A Apuro Manual Fill Hot Water Urn 40Ltr	15		Power Cord Clip