



EXPAND MESH

BLUETOOTH® HEADSET WITH MESH INTERCOM™


QUICK START GUIDE

1.0.0

ENGLISH

Downloadable Sena Software


Download the **Sena Outdoor App** at [Google Play Store](#) or [App Store](#).




Sena Outdoor

- Device configuration setting

Download the following items at [sena.com](#).




Firmware



Sena Device Manager

- Firmware upgrade
- Device configuration setting




Quick Start Guide, User's Guide


Follow us on Facebook, YouTube, Twitter and Instagram to check the latest information and helpful tips.

SENA SENATECHNOLOGIES, INC.
 CUSTOMER SUPPORT: [SENA.COM](#)

Product Details



Wearing the Headset



• For more information about installation, refer to the User's Guide.


Icon Legend


TAP 1x Tap button the specified number of times


HOLD 10s Press and Hold button for the specified amount of time


 "Hello" Audible prompt

Basic Operations


Powering On  **HOLD 1s**

Powering Off  **TAP 1x**



Volume Up  **TAP 1x**

Volume Down  **TAP 1x**


Checking the Battery Level

Powering On 

Phone Pairing

①  **HOLD 5s** →  "Phone pairing"


② Select **Expand Mesh** in the list of Bluetooth devices detected.





• The headset will enter the **Phone Pairing mode** automatically when you **initially turn on** the headset.


• For more information on phone pairing, refer to the User's Guide.

Using the Phone


Answer a Call  **TAP 1x**


End a Call  **HOLD 2s**


Reject a call  **HOLD 2s**

Voice Dial  **HOLD 3s** in stand-by mode

Music Control

Play/Pause  **HOLD 1s**



Track forward  **HOLD 1s**



Track backward  **HOLD 1s**

Mesh Intercom™

Open Mesh™: communication within the same channel.
Group Mesh™: communication within the same private group.

• For more information on **Mesh Intercom**, refer to the User's Guide.

Mesh Intercom On  **TAP 1x** →  "Mesh intercom on, Open Mesh, channel 1"



Mesh Intercom Off  **TAP 1x** →  "Mesh intercom off"

Note: When **Mesh Intercom** is on, the **Expand Mesh** will automatically connect to nearby **Expand Mesh** users and the headset will be in **Open Mesh (default: channel 1)** initially.



Open Mesh

Channel Setting (Default: channel 1) in Open Mesh



Using the Button



① Enter into the **Channel Setting**.
 **TAP 2x** →  "Channel setting, 1"

② Navigate between channels.
 (1 → 2 → ... → 8 → 9 → Exit → 1 → ...)

 **TAP 1x** →  "#"

or

 **TAP 1x** →  "#"

③ Save the channel.
 **TAP 1x** →  "Channel is set, channel #"

Using the Sena Outdoor App
 You can select the channel through the **Sena Outdoor App**.

Group Mesh


Group Mesh is a closed group intercom function that allows users to join, leave, or rejoin a group intercom conversation without pairing each headset.


1) Creating a Group Mesh

Creating a **Group Mesh** requires **two or more Open Mesh users**.

Open Mesh → **Group Mesh**




① **Users (You, B, and C)** enter into **Mesh Grouping** to create a **Group Mesh**.
 **HOLD 5s** →  "Mesh grouping"



② When **Mesh Grouping** is completed, the **users (You, B and C)** will hear a voice prompt on their headset as **Open Mesh** switches to **Group Mesh**.
 "Group Mesh"


2) Joining an Existing Group Mesh

One or more current users in an **Existing Group Mesh** can allow **new users (one or more)** in **Open Mesh** to join the **Existing Group Mesh**.

Existing Group Mesh + **Open Mesh** → **Existing Group Mesh**




① **One (You) of the current users** in the **Existing Group Mesh** and **new users (D and F)** in **Open Mesh** enter into **Mesh Grouping** to join the **Existing Group Mesh**.
 **HOLD 5s** →  "Mesh grouping"

② When **Mesh Grouping** is completed, the **new users (D and F)** will hear a voice prompt on their headset as **Open Mesh** switches to **Group Mesh**.
 "Group Mesh"

Enable/Disable Mic (Default: Enable)

Users can enable/disable the microphone when communicating in a **Mesh Intercom**.

 **HOLD 1s** →  "Mic on" or "Mic off"

Reset Mesh

If a headset in an **Open Mesh** or **Group Mesh** resets the **Mesh**, it will automatically return to **Open Mesh (default: channel 1)**.

 HOLD 8s → "Reset Mesh"

Configuration Menu

Accessing the Configuration Menu
 HOLD 10s → "Configuration menu"

Navigating Between Menu Options
 TAP 1x or **TAP 1x**

Execute Menu Options
 TAP 1x

Troubleshooting

Factory Reset

① **HOLD 10s** → "Configuration menu"

② **TAP 2x** → "Factory reset"

③ **TAP 1x** → "Headset reset, good-bye"

Fault Reset

Note: **Fault Reset** will not restore the headset to the factory default settings.

Quick Reference

TYPE	OPERATION	BUTTON COMMANDS
Basic Operations	Power on	HOLD 1s
	Power off	TAP 1x
	Volume up / Volume down	TAP 1x or TAP 1x
Mobile Phone	Answer phone call	TAP 1x
	End/reject phone call	HOLD 2s
	Voice Dial	HOLD 3s
Music	Play/Pause music	HOLD 1s
	Track forward	HOLD 1s
	Track backward	HOLD 1s

TYPE	OPERATION	BUTTON COMMANDS
Mesh Intercom™	Mesh Intercom on/off	TAP 1x
	Channel setting	TAP 2x
	Mesh Grouping	HOLD 5s
	Reset Mesh	HOLD 8s
	Enable/Disable Mic	HOLD 1s