

Markerboard

Use & Care Instructions

What markers should I use?

- Heartwork recommends writing with the markers included with each markerboard.
- Heartwork-approved genuine dry-erase markers, including Expo Dry Erase markers, can also be used.
 - **Note:** Reach out to orders@heartwork.com to get approval for specific marker products.

How should I erase the markerboard?

- For daily use, use the microfiber cloth provided with the markerboard and dampen with water to erase any markings.
- For tough stuck-on markings, apply the cleaning spray to the microfiber cloth first, then use the cloth to remove the markings.
 - **CAUTION:** Be careful when using cleaning spray and apply directly to the cloth to ensure there is no overspray onto the powdercoat finish of the product the markerboard is mounted on.

How can I remove the markerboard after installation?

- Markerboard can be removed from product by lifting up a corner and slowly peeling it away from the product.
 - Markerboard should be discarded after removed, as it cannot be reapplied.
- If the markerboard leaves any residue, wipe your Heartwork product using warm water and a mild detergent as needed.
 - Heartwork recommends using a gentle green detergent, as it is both effective and good for the environment!

Can I remove the markerboard and apply it to a different product?

- Markerboard can be removed from product without causing damage, but cannot be reapplied.
- Markerboard only supports single application – markerboard does not retain stickiness after removed.

Can I use magnets on the markerboard?

- The markerboard itself is not magnetic, but it allows the steel product to retain its magnetic properties.
- Magnets will also be included with each markerboard, as required for the installation process. Heartwork recommends keeping these magnets to use on a regular basis after installation.

Questions? Contact us:

Email: orders@heartwork.com

Phone: 1 (888) 749-7003

Website: heartwork.com

