



Round button 1 ,2, 3,4 : function buttons,

Operation: single time push-down button is to turn on the water, double time push-down button is to turn off the water

I.e. if you turn on the rainfall, you just push down button that control rainfall function.

The square knob is to control water temperature. You can move the knob to the left side after you push down the small button on the square knob. This is anti-scale setting.