


Precautions for handwheel installation

※1: The red line can't misplace, it should be kept in a line, otherwise the water temperature of 100°F or 38°C will not be correct.



Precautions for handwheel installation

※2: Please ensure that A Plastic locating ring and B handwheel locating pin kept in the same line with 100°F or 38°C. Otherwise, the water temperature will be wrong.

