

DRAGONN

Alkaline Water Pitcher Instruction Manual



SKU: DN-KW-WP01



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

<https://idragonn.com/products/dragonn-alkaline-water-pitcher-3-5-liters>

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST



help@idragonn.com



www.idragonn.com
Chat live with an agent!



309-278-5303

WARNING!

If you do not understand these directions, or if you have any doubts about the installation, please call a qualified technician. Check carefully to make sure there are no defective or damaged parts. Improper installation may result in product damage. Do not use this product for any purpose that is not explicitly specified in this manual. We cannot be liable for damage or injury caused by improper use.

WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.

BEFORE USE

Step 1. Remove the filter from the packaging, making sure to also remove the blue cover from underneath.

Step 2. Fully submerge the filter in water for 12 minutes, then rinse it 2-3 times under running water. The water from the filter may have a black color until the filter is completely clean. Repeat if the water from the filter is still black.

Step 3. Clean the pitcher using soap and water. Rinse thoroughly.

SET UP AND WATER FILTRATION

Step 1. Press the filter into place in the water pitcher.

Step 2. Pour water into the pitcher. Wait for all of the water to be filtered.

Step 3. Place the lid on the pitcher.

LCD TIMER DISPLAY

1. The LCD timer display on the lid of the pitcher indicates when the filter must be replaced.
2. The filter should be replaced after 60 days or 150L of water.
3. The timer will begin flashing as a reminder to replace the filter.
4. Reset the timer after replacing the filter.

LCD TIMER OPERATION

Step 1. For first use, press and hold the “start” button for 8 seconds.

Step 2. Press and hold the “start” button for 3 seconds (the display will flash 3 times). Release the button, and the LCD will then display the remaining number of days before the filter must be replaced, as well as the remaining filter life (displayed in bars). The flashing black dot on the lower right corner indicates that the memory function is working correctly.

Step 3. The number (No.) of days will decrease by 1 each day until the number reaches 0 and the displayed bars begin flashing, indicating that the filter must be replaced.

Step 4. To restart the timer, press and hold the “start” button for 8 seconds or until the display stops flashing. The timer will then reset and start again.

Step 5. To turn off the timer, press and hold the “start” button for 3 seconds. The display will flash 3 times and the timer will turn off. To turn the timer back on, press and hold the “start” button for 3 seconds.

NOTES

1. For best filtration, we recommend replacing the filter every 2 months with regular use.
2. Only use tap water with the filter. Other liquids or heavily contaminated water may clog the filter.
3. Do not use hot water. Only cold water should be used with the filter.
4. Keep filtered water refrigerated. We recommend using the water at the earliest opportunity for best flavor and freshness.
5. Only clean the pitcher using soapy warm water and a soft cloth. Do not use strong detergents, which may leave unwanted flavor in the water. Do not clean in a dishwasher.



Love your new Dragonn setup and want to share?
Tag us in your photo! **@dragonnbrands**

LAST UPDATED: 03/17/2020



Open **Monday - Friday 7:00am - 7:00pm** CST,
our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.



help@idragonn.com



www.idragonn.com
Chat live with an agent!



309-278-5303

FOR MORE DRAGONN PRODUCTS, CHECK OUT OUR WEBSITE AT: www.idragonn.com