

User Manual

Mini Camera

REV 1.1.0

1.Packing List

Open the package, then make sure the WiFi Camera (device) is intact, and includes all the accessories below



1 X Security Camera



1 X Adjustable bracket






1 X USB Cable



1 X Quick Installation Guide

Product Diagram



2.Preparation

Please prepare the following objects before using them

You would need:A smartphone or tablet with IOS 12.0 or Android 10.0 (Mac or Windows PC not accepted) (higher versions accepted)



Wi-Fi Router

- The device can only connect to a 2.4 GHz Wi-Fi router.
- The distance between the router and the device should be within 3 meters when configuration.
- Make sure to turn on the DHCP for the router and the MAC address should be off.



Wi-Fi Router

- Please do not use Chinese, symbols and other special characters as passwords. The WiFi name and wi-Fi password should not be empty.

3.APP Installation


Please prepare the items below before you using them.

- Download app from Apple Store/Google Play.
- Or scan the QR code below to download this APP.

4.Charge the device

Working time:about 1.5h
Fully charged:about 2h

Light Status
Working time:Green Light
Fully charged:Light goes off




5.How to Power on Camera?

Press the power button once, the light is on, the camera indicator starts to blink after 1 minute, the system of the camera emits signals

Note:

- Please fully charge the device before using the device.
- If the red indicator light does not blink twice at a time, please reset the camera.
- How to reset the camera?
Please press and hold the reset button for 10 seconds, waiting for 1 minute the red indicator light will blink twice at a time.



Device	Button	Press and long hold	Camera Indicator States
Light on	Power button	1 sec	Camera is on
Light blinking	/	Wait 1 minute	Ready for Wi-Fi connection
Light off	Power button	5 sec	Camera is off
Reset	Reset button	10 sec	Wait 1 minute will blink


6.Configure Device




- Mobile Phone Setting WLAN (WiFi)
- Open the App click "+"



- Click "Manual Add"
- Click Search Camera from LAN





- Click format SD card
- Set SD card recording



The default pass word is : admin

The default pass word is : admin

7.Watch Video




If the live video is filed,please close it and open again.If it is still freezed,please power off and restart the device and the WiFi outer, and keep the device and the WiFi router within 3m to configure again.


8.Connect the device to the router




- Continue with the previous operation.
- The product is away from the router 3-5 m.
- Open the APP>>Settings>>Network Information (WIFI) >>Wi-Fi manage>>Find Your Router SSID >>Enter Router SSID Password.




- Make sure the Wi-Fi is connected to the Internet.
- Make sure the smart phone/table PC are in the same Lan.
- Make sure to input the right password.



- Choose time, time zone setting



- Choose to set local time zone then click "save"



- Select SD card recording settings



FAQ

- Q:How many users can watch the video the same time?
>5 persons maximum.
- Q:Whether device supports ONVIF?
>Yes,it is standard.
- Q:How many cameras does the App holds at the same time?
>To make sure the App works well please do not connect over 10 cameras.
- Q:Can I record the live video into my phone?
>Yes,the manually record will saved into your phone.But the auto record will saved into the SD card.
- Q:Whether device supports SD video recording?
>Yes,up to 64G Micro-SD card.
- Q:How long does my SD card can record?
>If your camera is running full time recording,one 64G SD card can record about 4 days.If the SD card is no space for new video, it will erase the oldest video to save the newest.
- Q:What is the format of the video reording on the Micro-SD card?
>AVI,H.264 and most of the main media player ormat.
- Q:How to use smart phone to watch the SD card recording?
>Press the APP,press the local ecording "SD",then you can watch the video recording.

FAQ

- Q:Why system prompt that equipment is off line after added?
>Please click software "reconnect". or check whether the equipment power supply and the network connection is OK.
- Q:Why stuck and time-lag situation happens some times when watching the video?
>Please check your network connection or set up video quality to "low" pattern under advanced setting.
- Q:What can I do if I forgot the equipment password?
>Press (RST/SET) button on the unit and hold 5 seconds at last the device will be reset to the factory default setting in about 1 i minue.
- Q:How do I change the password?
>Open the App and click the gear icon,then you can nd'Modify Device Password'.The default passwor d is 'admin'.
- Q:Why can't it connec to WIFI or is it unstable?
>Please make sure that the distance between the device and the WIFI router is within 3 meters and there are no walls in the middle.
- Q:Why can't it connect to a dual-band router?
>Please choose 2.4Ghz WIFI for the connection.
- Q:Why can't t configure with the app?
>If you bought the devie before 2019, please use the old version. Our new app is just for the devie on or after 2019.
- Q:Why there is a red indicator light under the ventilation hole when the device is energized?
>The red light indicates a normal operation of the devie.If it bothers you,you can turn it off the APP manually.

Similar products, you will like



The User Manual may be updated because of the products version upgrade or other requirements,if you need the latest version of the user manual, please contact customer service.

About the User Manual:

The user manual is used as a guide. The photos,graphics,charts and illustrations provided in the User Manual are only used for explanation and interpretation, which may be different from specific products,plase refer to the real object.