HD 1080P Wireless Security Wi-Fi Camera




5. Press (icon on the right corner of camera -> WiFi Config ->Select local Wi-Fi (SSID) -> Input password -> Tap Next;

6. Quit APP, wait 30 seconds (device restart automatically) and connected with set Wi-Fi(Wi-Fi indicator is solid):

7. Enter APP to check live video locally or remotely anywhere.

P.S.: Contact local dealer for tutorial video setting up.

Product structure of Tiny Clock(2):



(3) Invisible night vision leds (Turn ON/OFF Automatically)

2 Display 4 Device UID & QR code



Overview:

In the box:

1 x USB Cable

Size: 109x39x46mm



Size: 112x40x43mm



Tiny Clock ①

These two fashion designed tiny clock, local temperature and humidity info which auto-sync from internet once connected with Wi-Fi; The most

important, it is integrated with a powerful 1080p smart invisible Wi-Fi

First, it can be used for watching live streaming video day and night.

Usages: Nanny camera, Home/ Shop/ Office/ Warehouse surveillance

Warning: " illegal use is not allowed! Or, there will be consequences

1 x Camera Unit 1 x 5V2A power adapter 1 x Micro SD Card Reader

or taking photo and video by APP in smart-phone remotely after Wi-Fi connected; Also, it supports Point to Point (P2P) function,

camera comes with 6 meters powerful night vision.

easily connected for local live video without Wi-Fi. Second, it also support motion detect alarm function, cycle

1 x User Manual

recording and work when charging.



Tiny Clock 2

Product structure of Tiny Clock (1):



Invisible night vision leds (Turn ON/OFF Automatically)

(4) Device UID & QR code

Wi-Fi Camera Connection Setting

Step1: Download and install APP

Scan below QR code or search and download free APP named <TinyCam Pro> in Apple APP store, Google play or Electronic market, and install it;

Tips: Please allow "TinyCam Pro" to access your location while you are using





the app(for syncing local weather info).



Quick guide of Wi-Fi camera function:

1.Download Free App <TinyCam Pro> from App Store or Google


Tips:Please allow "TinyCam Pro" to access smartphone location while using the APP.

2. Take off back cover and pull out the battery insulator --> Insert micro SD card --> Press the ON/OFF key, wait for 1 minute (Power indicator and Wi-Fi indicator is flashing regularly.): Tips: After above operation, please put on back cover and plug power adapter for long time use

3. Enter smartphone settings -> Search and connect device's Wi-Fi named: AIS....., wait till phone status bar appear Wi-Fi symbol 🛜;

4. Enter APP, tap below "(+)" icon --> LAN search-->Tap the found device -> Tap Add -> Camera Online then; Tips:This step = P2P mode, can check video locally when without Wi-Fi.

2



(6) Micro SD card slot (7) ON/OFF Key (8) Reset Key

(9) Power indicator (10) Wi-Fi indicator (11) Charging indicator

Clock part of Tiny Clock 1:

Short press = Centigrade degree to Fahrenheit °C%F Long press = Turn off / on display

12h / 24h € Time set


Short press = Snooze (J)(0)

Long press = Turn off clock setting

5:13 ₹ nti 🗢 🕕 Q tinycam pro Cancel 4

Step 2: Take off back cover and pull out the battery insulator --> Insert micro SD card --> Press the ON/OFF key, wait for 1 minute (Power indicator and Wi-Fi indicator is flashing regularly.);

Tips: After above operation, please put on back cover and plug power adapter for long time use.



(5) USB port 6 Micro SD card slot 7 ON/OFF Key 8 Reset Key (9) Power indicator (10) Wi-Fi indicator (11) Charging indicator

Clock part of Tiny Clock2:

Time/Alarm set

Hour/Month set / 12 vs 24Hour

Minute/Day set / 12 vs 24Hour


 $(\overline{-})$ Alarm on/off

Turn off/on display

Tips: Local Time and Temperature info will be updated automatically every 2 hours after connecting to local Wi-Fi.

Step 3:Connect Wi-Fi

1.Open smartphone settings, search and connect the device's wireless signal named "AIS.....", wait Wi-Fi connected, and phone status bar appear Wi-Fi symbol.



Set camera name and private code

Set name:Tap the () after the camera, Input a new name(like Office ...) in Device Name;

Set new password: Tap the (3) after the camera, Tap Device Password --> Old password = 888888.




15

Specification

Resolution	1 Mega CMOS
Video pixel in phone	Max 1920*1080
Video pixel in card	1080*720
Frames	Max 25fps
Compressed format	H.264
View angle	120 Degree
Type of memory card	TF card>=Class 4/10 and HC marked
Maximum capacity of memory card	128GB
PC operation system	Windows 7, 8 / Mac OS X
Play software	VLCPlayer/SMPlayer
Mobile phone operation system	Android/iOS
Web browser	IE7 and above,chrome,firefox
Power consumption	300MA/3.7V
Battery Capacity	Rechargeable 3000 mA
Recording	1 minute/ around 20MB
Working time in day time	Around 8 hours
Working time in night time	Around 3 hours
Charging time	3-4 hours
Power adapter	5V / 2A

2.Enter APP, tap below " \bigoplus " icon --> LAN search --> Tap the found device --> Tap Add --> Camera Online then;



Tips: This step = P2P mode, can check video locally when without Wi-Fi.

12

APP introduction:





Tips: 1. Please confirm phone setting has allowed TinyCam Pro App to access the location services:


2. A TF card(Micro SD card) must be inserted for saving alerts pictures.

16

FAQ

- Q: Time display is not stable, always blinking?
 A: It's with low battery, please charge it.
- Q: Can't get device Wi-Fi signal?
 A:Press reset key for 10 seconds and wait 1 minute.
- 3. Q: Live video not smooth and clear?
 - A: Select suitable resolution according to the real time network environment.
- 4. Q: Motion detect set and alarm?
- A: 1). Set motion detect sensitivity in App Setting > Alarm Config;
- 2). When motion detected, camera will push a alarm message to your phone and take one picture for checking in the APP [Page 16 Alert notification]. (A micro sd card MUST be inserted for saving alarm pictures)

3.Tap (i) icon on the right corner of camera —> Wi-Fi Config—> Select local Wi-Fi (SSID) —> Input password —> Tap Next;



Flip video vertically
Flip video horizontally
Night vision setting
Contrast
Brightness
Snapshot
Record videos

Full screen
Resolution/1080P/720P/
640P/480P,1080P=Highest
resolution)
Listen
Talk

5. Q: Micro SD card instruction?


A: 1). Set motion detect sensitivity in App Setting > Alarm Config;

17

2). Once device is connected to Wi-Fi, can set SD management in App Setting > Micro SD Card Config.

- 6. Q: How to play micro SD card video?
 - A: 1). Use a card reader to read and play;
 - 2). Use APP to play back [Page 16 TF card recorded files];
 - 3). Play back in good speed network.
- 7. Q: Forget camera password, or item goes abnormal? A: Turn on camera and wait for 1 minute, press reset key around 10 seconds till back indicators off to restore factory default. Camera restarts and get ready again in 1 minute.
- 8. Q: Any operation video demo of the camera for setting up?A: Please contact local dealer for video guide.

- 4.Quit APP , wait 30 seconds (device restart automatically) and connected with set Wi-Fi(Wi-Fi indicator is solid) ;
- 5.Enter APP and check live video locally or remotely anywhere.



- Share camera with others by QR code
- Wi-Fi Config: Set camera to connect to local Wi-Fi
- Alarm Config: Set motion detection sensitivity
- Micro SD Card Record Config: Set SD card recordmode / Resolution /File length...
- (5) Working Indicator: To turn on/off device's working led
- Firmware Update: Update
 device's latest firmware by app



The end!

19 20 21