

USB Flash Drive Digital Voice Recorder X-09



User Manual

Usage method:

1. **Recording** Turn the switch to the ON position, and after the red light flashes off, the recording starts. Turn the switch to the OFF position, the recording ends, and the machine saves the recording automatically and shuts down.

2. **Recording while charging:** During the power off state, connect to the computer or charger, and after the red light flashes or the blue light flashes all along, turn the switch to the ON position. After the red light flashes, the recording starts. Turn the switch to the OFF position, the machine will save the recording automatically.

3. **Play:** Connect to the computer and open the record file for playback.

4. **Voice-activated recording (This function is only available in the version of the Three - steps switch):** Move the switch to the middle position. After the blue light flashes a few times and goes off, the voice-activated recording starts. Push the switch to OFF, recording will stop and save the recording date.

Note:

1. When charging, the red light flashes slowly. When the power is full, the blue light is on.
2. During recording, do not connect to the computer, otherwise the recording file will be lost.

*Recording Format: WAV

*Sampling Rate:48KHz

*Music Formats :MP3/WMA/WAV

*Digits:192KBPS