


**1** Open the support legs by loosening the metal wing nuts. When setting the shelf on the windowsill, ensure the tip of a measuring tape fits in between your window and its frame (see video using QR code below).

**IMPORTANT:** *Make sure your current sill is no wider than 4" – this shelf will not work with wider windowsills!*

**2** Place the aluminum angled profile in between the window and the wooden ledge (window frame).



**3** Push the support legs against the wall to level the perch and firmly fasten the wing nuts. Support legs should be at an angle of 45 degrees. If windowsill does not accommodate the standard legs, please use the included extra set of legs!



***Use this QR Code to View the Installation Video!***

**Please Note:** *If you would like to move the perch to another window, simply loosen the wing nuts, lift the perch and place it another window. No hardware, glue or drilling is needed!*