

## Tips on how to use the Toniebox



Find out all you need to know about setting up and using the Toniebox, discover how the Tonies work and learn how to play your own content on the Creative-Tonies. Have fun reading, and don't forget to spread the word!

## Important features of the Toniebox explained



### Switch on

To switch on the Toniebox, pinch one of the ears between finger and thumb. After 10 minutes of inactivity, the Toniebox switches off automatically.



### Skip forward and backward

When your download is complete, to skip forward or backward between chapters, just tap the side of the Toniebox. To fast-forward or rewind, tilt the Toniebox.



### Listen and pause

When the LED on the Toniebox turns to a steady green light, a Tonie can be placed on top. Pause the Tonie? Simply take it off the box. Put it back on again, and it will continue where it left off.



### Volume control

Pinch the big ear to make the Toniebox louder, pinch the small ear to make it quieter.



### LED Display

Warning - low battery! Place your Toniebox on the charging station to recharge the battery.

# Troubleshooting tips

### Restart?

If all else fails, a restart can help: Turn the Toniebox without the charging station upside down and press both ears until you hear an audio signal (after about 10 seconds).



### Reset to factory settings

Turn the Toniebox with the connected charging station upside down while keeping the ears pressed until you hear an audio signal (after about 10 seconds). Beware: all connections, contents and settings will be deleted!

# Set up & listen to the Toniebox

## You will need:



Toniebox

and charging

Tonie or

Creative-Tonie



Input device



Wireless connection



Internet access







First set up the Toniebox and connect it to the Wi-Fi. To do this, you will need a smartphone, a tablet or a computer. The setup is simple. Find a step-by-step explanation at





For assistance with problems or questions, please contact our support team on +44 (0)20-31 92 14 92, Monday-Saturday 7 am-5 pm Answers to many questions are also found online at tonies.com/support.

### How the Creative-Tonie works



Place the Creative-Tonie on the

Toniebox. First, a connection to the Toniecloud must be established. As soon as the Creative-Tonie responds with a voice message, it is ready to use.



Important: As long as the blue status LED is flashing (download in process), the Toniebox must be within Wi-Fi range.



Synchronise and put Creative-Tonie back on top. Take the Tonie off the Toniebox and press one of the ears for 3 seconds until you hear an audio signal. When the LED turns green again and you hear a second audio signal, replace the Tonie on the Toniebox and the new



Record your own audio content to the Toniecloud on https://my.tonies.com.

The Creative-Tonie automatically appears in the user's account, where existing audio files (MP3, own recordings, etc.) can be uploaded and allocated to the Creative-Tonie. It has room for up to 90 minutes of audio content.



... or use the Tonie-App to record your own voice or audio content, upload it to the Toniecloud and allocate it to the Creative-Tonie.



Start listening

content will download.




As soon as the LED turns green, all your new content is on the Toniebox.



UPLOAD YOUR OWN SONGS AND STORIES!

Tonies with stories, music or other great content

Beside the Creative-Tonies, there are Tonies that come with their own content, like stories, music or things to learn. The first time a Tonie is put on the Toniebox, its content is automatically downloaded from the Toniecloud as long as there is a Wi-Fi connection. Once you have downloaded the content over Wi-Fi, you can listen to it everywhere. The category, recommended age and running time are stated on the packaging. Attached to each package is a booklet with a tracklist and brief descriptions. By the way: all Tonies and Creative-Tonies are hand-painted.













Find all Tonie audio samples at tonies.com/audio-sample.

GREAT STORIES TO ENJOY



