



AIR TENT USER MANUAL

Please read this manual carefully before installation, and retain it for future reference.

V1.0



ABOUT US

Founded in 2018, the San Hima brand stands for passion and enthusiasm for exploring the spectacular nature of the great outdoors. Since its inception, the trusted solutions and proven designs that San Hima offers to the market have made adventure and travelling flexible and enjoyable!

Based in Australia, San Hima has under its umbrella a wide selection of outdoor solutions, including cargo systems, vehicle protection accessories and tow & trailer parts, that are designed to help you carry your gear wherever your passion takes you and boost your performance when conquering the peaks!

At San Hima, we have wild souls and we are committed to designing products that are tough enough to take on any adventures and at the same time, making them safe and easy to use. These values in our conviction are what drive us to make innovations. Since pursuit your passion shouldn't be complicated.

Live the Peak, Conquer the Everest, San Hima is your brand of choice!

TABLE OF CONTENTS

1. IMPORTANT INFORMATION	-----	2
2. WARNINGS AND SAFETY INSTRUCTIONS	-----	2
3. PARTS LIST	-----	4
4. SETUP INSTRUCTIONS & STEPS	-----	5
5. MAINTENANCE AND STORAGE	-----	7
6. WARRANTY	-----	8



IMPORTANT INFORMATION

- This user manual that accompanies this air tent contains important information on setup, handling, maintenance and storage.
- Before using the product, read the manual carefully. This particularly applies to the warnings and safety instructions. Failure to do so may result in personal injury or damage to the product. San Hima is not liable for damage or accidents resulting from non-observance of the warnings and safety instructions, changes to parts, or the use of parts other than San Hima's original parts.
- The warnings, safety and setup instructions in this manual cannot cover every imaginable situation, so it is the user's responsibility to exercise common sense and caution.
- It is your responsibility to pass these instructions on to third parties using this air tent, including second-hand sales.

WARNINGS AND SAFETY INSTRUCTIONS

GENERAL GUIDELINE:

- Before pitching the San Hima air tent, please choose a suitable site. The user manual of this air tent should ALWAYS be kept at hand.
- Regular inspection of the tent for damage and wear increases the level of safety, broken or defective parts must be replaced.
- DO NOT use your tent if there is ANY visible damage to ANY part of the tent, instead contact San Hima to see how we can help.
- NEVER force ANY of the components which could result in damage when opening and closing the tent.
- ANY dirt or stains can be removed by brushing, or gently washing, using cold water. DO NOT use cleaning fluids containing bleach, alcohol or ammonia or ANY other chemicals that would otherwise damage your tent.
- Recommended to store your tent indoors if it's not going to be used for a long time.
- NEVER leave the tent open for a long time where insects, rodents, or moisture could occur.
- DO NOT leave your tent unattended.

FIRE HAZARDS:

- DO NOT set up cooking or heating devices inside the tent.
- DO NOT use ANY gas or other combustion devices near or inside the tent.
- Keep the tent away from open fire. DO NOT start a fire inside the tent.
- Keep a look out for ANY airborne burning embers that may come into contact with the tent.
- Keep a fire extinguisher or water bucket nearby.
- DO NOT smoke within the tent.
- Ensure there is ALWAYS an unobstructed path of escape out of the tent. Keep calm in the event of fire and leave the tent on the shortest way.

VENTILATION:

- If the inside of the air tent is not adequately ventilated, there is a risk of suffocation. Make sure the windows are ALWAYS open in the event of high temperatures.
- DO NOT leave children unattended in the tent.
- Avoid continual exposure to sunlight to prevent the accumulation of heat inside the air tent.



POLES AND ROPES:

- Once set up, the stainless steel pole is under tension. Please note that improper handling of the pole may result in injury.
- Ensure the poles will not end up in the hands of children.
- When handling the stainless steel poles, pay attention to nearby persons.
- Keep the guy ropes out of the reach of children. DO NOT allow children to play with the guy ropes. If they end up in the hands of children, they could strangle themselves.

SITE SELECTION:

- Ensure that you site the air tent on clear/level ground before set up, with no sharp objects beneath and zips fully closed. San Hima recommends conducting a trial run of your air tent to familiarise yourself with the assembly of the tent. Should you have ANY issues in relation to setting up your air tent; please contact San Hima for assistance before your holiday.

SETUP:

- Incorrect setup, improper handling of the product could result in damage.
- DO NOT place the tent with its entrance against the wind.
- DO NOT place ANY objects on top of the tent.
- Ensure you have enough room around your tent in order to be able to tension the guy ropes properly.
- If a zip opening is tight it is more than likely due to the fact that your tent or its awning is not pitched correctly.

SNOW LOADS:

- DO NOT expose your tent to snow loads. It cannot withstand them. This tent is not suitable for use in temperatures below -40°C(-40°F) or when there is a snowfall. Disassemble the tent in case of snowfall.

SOFT AND SANDY GROUND:

- Verify that your pegs have enough resistance. Properly secure the ropes with the pegs. Look for other suitable ground if the pegs can be pulled out of the ground easily.

EXTREME WEATHER CONDITIONS:


- Your tent was not created for extreme weather conditions. DO NOT use, set up or leave your air tent in ANY potentially harsh weather conditions such as: hail, sleet, snow, extreme cold or heat, lightning etc.
- Promptly take the tent down in the event of an incoming storm, thunderstorm or in case of strong wind. Even if properly anchored, it may come loose.

CLEANING:

- DO NOT use any aggressive cleaners, sharp or metallic cleaning utensils such as knives, hard scrapers and the like. They could damage the surfaces.
- NEVER wash the product in the washing machine.
- NEVER have the product dry cleaned.
- ONLY use clean water to clean the product.
- Let the inner and outer tent dry completely before storage.

PARTS LIST

- 1 PC(s) San Hima Air Tent
- 2 PC(s) Stainless Steel Poles
- 22 PC(s) Pegs
- 2 PC(s) Guy Ropes
- 1 PC(s) Pump
- 1 Kit (s) LED Strip Light
- 1 PC(s) User Manual



SETUP INSTRUCTIONS & STEPS

1. TEST RUN (RECOMMENDED)

It is recommended to practice setting up your San Hima air tent in a suitable site to ensure you've fully understood the steps.

2. SITING

Select a site that is dry and level and, if possible, protected from the wind. Clear the ground of any sharp objects to avoid damaging the tent. It is recommended to set up your air tent with the door facing away from the wind. DO NOT pitching your tent under the trees as falling branches and sap might damage the tent.

3. UNPACKING

Be careful when opening.

- (1) Take the product out of the package.
- (2) Check to make sure that the product and its accessories is complete (see parts list).
- (3) Check whether the product or the individual parts exhibit damage. If there is ANY, DO NOT use the product.
- (4) San Hima recommends taking a photo to see how the product is packed. This will help you when it comes to storage.

4. UNFOLDING THE TENT


Spread out the air tent, ensure the floor facing down, orient the tent in the correct direction and peg out the four main corners ensuring the tent is pulled taut and square. It is recommended to pitch the tent so it is in line with wind, never side on.

5. INFLATION

There is an external valve located on the air tube. Before inflating, unscrew the valve cap on top of the valve. Insert the pump hose into the valve and start inflating with the supplied San Hima Hurricane air pump.

You may need to help the tube stand up when you've inflated it to about 5 PSI so keep pumping until the tube feels rigid. Make sure you ONLY inflate to the recommended pressure (6 PSI) as over-inflation can lead to damage. Once you have finished inflating, remove the pump nozzle and replace the outer securing cap. NEVER USE ELECTRIC AIR COMPRESSORS.

Ensure the strap is located above the joint of the air tube and its velcro tape sticks on it.




6. ADJUST THE FLOOR

Making sure the tent is sitting evenly. You may need to adjust the base of each air pole so it sits flat with the ground.

7. PEGGING

When pegging out poles, make sure the ropes are at a 45° angle to pull even tension on the flap.




8. GUY ROPES

Unravel the guy ropes and pull them away from the tent, while making sure they are tensioned. The length and rope tension of individual ropes can be adapted by the fasteners attached to some of the ropes. Secure the guy ropes at suitable spots in the ground using the pegs. Use a hammer (not included) if necessary to drive the pegs into the ground.

9. AWNING

Starting from one side of the awning, slide the top of the stainless steel pole through the ring of the awning. Secure the pole in place by its end into the ground. The pole has been set up and is under tension.




10. DEFLATION

- (1) Close the mesh door, but leave the door open to allow air to escape.
- (2) Peg out all ropes and roll them up.
- (3) Peg out all pegs, clean and dry the pegs before storage.
- (4) Carefully open the outer cap of the valve. Carefully press the beam to release the air. Never force the air out of the beam, as you might risk damaging the pole. When packing the tent away, the valves should be left open to allow any trapped air to escape.

11. FOLDING

Fold the steps as per below. Ensure that the air valve is not obstructed to allow the remaining air to escape. To reduce the chance of valve malfunction, the valve should be fully unscrewed when the product is in storage. Ensure the tent is completely dry and clean before storing away and store it in a dry environment.



IMPORTANT:

- Your San Hima air tent is made from the best available materials. After several times of use, you may find some slight variances in colour and changes due to the weather and the environment. These are all normal and will not affect the performance of the product and are not faults or errors.
- You may also experience, depending on the weather and use, condensation. This should not be confused with leakage. To reduce the risks of condensation, please ensure your tent is adequately ventilated. Please note that under certain conditions, all tents will suffer from internal condensation depending on atmospheric conditions, the weather, the amount of moisture in the air/ ground, evening and night time temperatures etc.
- Discolouration of the fabric may be an early indication that your tent has been attacked. To limit damage by UV, wherever possible, please site your air tent in a shaded area avoiding direct sunlight. Fabrics can be weakened by prolonged exposure to sunlight.

MAINTENANCE AND STORAGE

The San Hima air tent is designed to be a reliable companion on your adventures. In order to keep it performing at its best, San Hima recommends some care and maintenance steps that will help prolong its life.

- Prior to each use, inspect your air tent and its accessories.
- Dry your air tent thoroughly before you close it. If unable to properly dry your air tent prior to closing, open it up and air dry it at your next opportunity. Failure to properly dry your tent can lead to the growth of mold and mildew which can degrade the tent material, cause discoloration, and foul odor.
- To clean your air tent use with cold water and a sponge. DO NOT use soap or detergent.
- Zippers should be pulled with even force and in a gentle manner. Keep your zippers free from dust and dirt.



WARRANTY

San Hima ("Manufacturer") warrants, to the original purchaser ("User") that its tent, if purchased from manufacturer or an authorized distributor or dealer, will be free of defects in material and /or workmanship under normal usage from the date sold and for the duration (the "Warranty Period") of 2 YEARS.

This warranty shall ONLY be effective for the original purchaser and apply ONLY to the San Hima air tent that is correctly installed on the vehicle for which it is intended. San Hima will either replace the product or provide you with a refund at our discretion provided that the fault is found to have been caused by a design or manufacturing defect that results in its failure to perform correctly as described. The limited warranty is the only one that applies to this product, and it sets forth all the responsibilities of San Hima.

EXCLUSIONS:

This warranty does not cover defects, failure or damage caused by incorrect installation, intentional damage, misuse or abuse. It is recommended that the installation should be performed by suitably qualified technicians or the warranty will be voided. For further clarity, this warranty is also void if the air tent:

- is repaired, altered or modified carried out by anyone other than San Hima, or without San Hima's authorization,
- is damaged by mold and mildew as the tent is not properly dried prior to closing,
- is damaged by extreme weather (e.g. storm, hail or strong wind), extreme temperature, accidents, negligence, daily wear and tear, incorrect setup, or failure to check the condition of tent before each use,
- is damaged by UV degradation or acid rain to the tent/awning and its components,
- is damaged from improper storage, or a failure to provide routine maintenance,
- is used on permanent sites or commercial displays.

CLAIMS:

If a San Hima product is suspected of being defective, you'll need to provide proof of purchase (e.g. a screenshot of the order) and a picture and a video of the damaged goods in their entirety to sales@sanhima.com. If the product is found to be defective and covered by this limited warranty, the remedy is replacement or refund, at San Hima's option. No charges will be accepted for external labour or materials.