



Fold here



0% Financing Available

2020 | casafurnitureusa.com
All rights reserved | 407.567.0020

casa
MODERN FURNITURE

Scan me with
your camera



J E M
DINING CHAIR

DESCRIPTION

Give your dining look that classic retro look that you love when you incorporate the Jem Dining Chair into the space. A curved seat blending seamlessly into the elongated rectangular back is interrupted only by the honeycomb style cutouts along the back. It is supported by handsome wooden legs.


- Beautiful armless design promotes comfort and a sleek silhouette.
- Modern honeycomb cutouts offer extra visual appeal.
- Crafted out of top quality material.

MATERIAL

Solid Wood, Acrylic

DIMENSIONS

Total Weight: 19 lb




BOX DIMENSIONS

Box 1: 15 x 19 x 38
Box 2: 18,5 x 18 x 20,5


ASSEMBLY

5 MIN



JEM COLLECTION: Dining Chair | Barstool

AVAILABLE IN:



Toupe|Acrylic

PRODUCT CARE

Wood

Use a soft and slightly dampened cloth to clean Solid Wood furniture. Follow with a clean, dry cloth immediately for best results. To repair scratches to wood, apply a colorless wax. Test wax on a small inconspicuous area first before applying to the rest of the wood. Important things to remember:

- Do not use chemical bleaches.
- Do not use glass cleaner.
- Keep Solid wood away from pets as their bodily fluids may cause damage, or they may scratch finish.
- Avoid contact with acidic liquids (e.g. sodas, vinegar, acidic cleaners) to prevent damage.

Acrylic

Stick with micro-fiber type of cloth. Avoid ammonia-based products, like Windex or other home glass cleaners, because they contain harmful chemicals that will damage the surface leaving it cloudy looking. Soapy water is the safest and most effective cleaning solution for acrylic.