



Fold here



0% Financing Available

2020 | casafurnitureusa.com
All rights reserved | 407.567.0020

casa
MODERN FURNITURE

Scan me with
your camera



N O R A
ACCENT CHAIR

DESCRIPTION

Put an additional seating option in your living space while enhancing its overall appearance when you choose the Nora Accent Chair. This accent chair is wide and accommodating with its open arms and spacious seat. Both the seat and the button-tufted back are upholstered with fabric.


- Roomy and comfortable padded accent chair
- Beautiful button tufting adds a classic feel
- Neutral gray upholstery works in rooms of any style

MATERIAL

Leather, Veneer

DIMENSIONS

Total Weight: 23 lb





BOX DIMENSIONS


Box: 27 x 32 x 36 | 23 lb

ASSEMBLY

Assembled



AVAILABLE IN:



Black | Leather

PRODUCT CARE

Veneer

Use a soft and slightly dampened cloth to clean veneer furniture. Follow with a clean, dry cloth immediately for best results. To repair scratches to veneer, apply a colorless wax. Test wax on a small inconspicuous area first before applying to the rest of the wood.

Important things to remember:

- Do not use chemical bleaches.
- Do not use glass cleaner.
- Keep veneer away from pets as their bodily fluids may cause damage, or they may scratch finish.
- Avoid contact with acidic liquids (e.g. sodas, vinegar, acidic cleaners) to prevent damage.

Leather

Clean and dust eco-leather with a soft, clean cloth. You may use mild soap and water, followed by a new cloth to dry for standard eco-leather care.

Important things to remember:

- Do not use harsh detergents to clean eco-leather.
- Avoid using drying products like alcohol, or concentrated detergents.
- Eco-leather, like traditional leather will naturally crease, wrinkle and stretch with regular use.
- Prevent sun damage and discoloration by making use of your window curtains or blinds.