



Fold here



0% Financing Available

2020 | casafurnitureusa.com
All rights reserved | 407.567.0020

casa
MODERN FURNITURE

Scan me with
your camera



ROSEWOOD

COFFEE TABLE

DESCRIPTION

Impress your guests with a coffee table that is as artistic as it is functional with the Rosewood Coffee Table that features a sleek, shining cream white center surrounded by a wooden lip. The tabletop is supported by a circular metal base that further adds to its appearance.

- One of a kind spacious circular coffee table
- Supportive metal base
- Warm wooden finish on the rim

MATERIAL

Composite Wood, Natural Veneer Wood, Lacquer, Stainless Steel

DIMENSIONS

Total Weight: 124lb




BOX DIMENSIONS

Box 1: 59 x 35½ x 19¼ | 124 lb

ASSEMBLY

20 MIN



AVAILABLE IN:



Walnut|Matte Light Gray

PRODUCT CARE

Veneer

Use a soft and slightly dampened cloth to clean veneer furniture. Follow with a clean, dry cloth immediately for best results. To repair scratches to veneer, apply a colorless wax. Test wax on a small inconspicuous area first before applying to the rest of the wood. Important things to remember:

- Do not use chemical bleaches.
- Do not use glass cleaner.
- Keep veneer away from pets as their bodily fluids may cause damage, or they may scratch finish.
- Avoid contact with acidic liquids (e.g. sodas, vinegar, acidic cleaners) to prevent damage.

Lacquer

Use a dry, soft cloth to dust lacquer furniture. For heavily soiled furniture, use a mild mixture of soap and water—only do this sparingly. Too much soap or using soap too frequently will ultimately damage the lacquer finish. Important things to remember:

- Always wipe in the direction of the grain.
- Do not use furniture polish as this may damage lacquered furniture.
- Do not use alcohol products, as this may dissolve the lacquer finish.
- Wipe up any spills immediately. Prolonged exposure to colored liquids can stain furniture.