



All-U-Need glass grinder bits

Transform the All-U-Need lap machine into a power-horse glass grinder with a glass grinder bit. Shape and grind the edges of glass, ceramic and tile pieces or create grooves in stained glass for wire wrapping, all on the All-U-Need.

INSTRUCTIONS FOR USE AND CARE

- 1** Remove the All-U-Need arbor using the Allen wrench included with your All-U-Need lap machine, turning counter-clockwise. Once loosened, pull the arbor off of the motor shaft.
- 2** Put the glass grinder bit onto the motor shaft. Tighten using the Allen wrench that comes with your glass grinder bit, turning clockwise. *Important note: Always use the Allen wrench included with the glass grinder bit to tighten and loosen the glass grinder bit. The Allen wrench included with the All-U-Need machine is a different size and is only to be used to tighten and loosen the All-U-Need arbor.*
- 3** Dip the square-shaped sponge included with the glass grinder bit into clean water and place the sponge behind the glass grinder bit to keep your work piece properly lubricated while working. Your set-up should match the images on the right. *Important note: Always use water with glass grinder bits. Like all diamond tools and products, use with water to provide proper lubrication and to prevent grinding dust.*



hitechdiamond.com

☎ (630) 596-9909 ✉ sales@hitechdiamond.com 📘 facebook.com/hitechdiamond 🐦 [@hitechdiamond](https://twitter.com/hitechdiamond)