



MAINTENANCE

To ensure you enjoy the best results and long-term satisfaction, we recommend that you follow the operating and maintenance instructions carefully. Please follow the steps below if the unit has been used for 5-6 times or 2-3 days.

STEP 1: Disconnect the AC adapter from the power supply. Take off the cover while keeping the unit stable. Disconnect the DC plug from the unit.




STEP 2: If there is water left in the tank, pour it from the drain side. DO NOT pour from the air outlet side or water may flow into the unit.




STEP 3: Use a damp cloth or cotton bud with water or diluted mild kitchen detergent to clean the ultrasonic mechanism and machine body.

Please DO NOT use chlorine, acidic or enzyme-based detergents to clean the outside or inside of the unit.

IMPORTANT: DO NOT press heavily or scratch the ultrasonic mechanism in the water tank during cleaning.



STEP 4: If there is any dirt inside the mist outlet, please press position A slightly then take off the inner cover to clean it. To re-insert the inner cover, line up the mist outlets and press gently until you hear it click.



STEP 5: Add water into the tank with the water cup. Install the cover. Activate the unit to operate for 30 minutes. Rinse it after pouring out the remaining water.

PRECAUTIONS AND SAFETY WARNINGS

To ensure safety in operating this unit, please follow the instructions below:

- ⊘ DO NOT disassemble, alter or repair the unit. If the product needs repairing please return to the retailer or the manufacturer.
- ⊘ DO NOT use the product when there is an abnormal odour or noise coming from the unit or the unit is overheating abnormally.
- ⊘ DO NOT keep the adapter connected to the power supply during maintenance or when adding water.
- ⊘ DO NOT allow children to use the product. Keep out of reach of children and pets.
- ⊘ DO NOT use accessories not designed for this model.
- ⊘ DO NOT pour the remaining water from the air outlet side. Please pour from the drain side.
- ⊘ DO NOT soak the unit in water or use in a wet area such as a bathroom or greenhouse.
- ⊘ DO NOT use the product if the power lead has been damaged or the socket is loose. For safety reasons, these parts may only be replaced by authorised service personnel.
- ⊘ DO NOT scratch or press hard on the ultrasonic mechanism in the centre of the tank.
- ⊘ DO NOT twist, puncture or stretch the cord of the power adapter or place hot items on the wire or heavy pressure that may bend or squash the cord.
- ⊘ DO NOT use inferior essential oil. It may damage the product and be detrimental to your health.
- ⊘ DO NOT place the unit on an unstable surface or move during operation.
- ⊘ DO NOT take off the cover of the unit during operation.
- ⊘ DO NOT keep the adapter connected to the power supply for a long unused time.
- ⊘ DO NOT place on electrical appliances such as computer, TV or audio equipment.
- ⊘ DO NOT use hot water, mineral water or refill while the unit is in operation. Please use only cold tap water or distilled water.
- ⊘ DO NOT cover the unit or block the mist outlet.




WARNING

Any misuse caused by ignoring the manual of the precautions may damage the product, even hurt the user.



Bosisto's

ULTRASONIC DIFFUSER



OPERATING MANUAL


FEATURES

- Humidifies the air
- Safe & cool to touch
- Up to 9 hours operation
- Auto switch off
- 16 LED light options
- Operating times 60/180/360mins & ON
- Water capacity 300mL

Please read the manual instruction carefully. Retain this manual so that you can refer to it in case of any problem.

How the Bosisto's Ultrasonic Diffuser works:


Through water and vibration at 2.4 million vibrations per second, high frequency oscillation converts water and the essential oil into a fine mist and disperses it into the air without using any kind of heat.




NOTE: There may be a difference between physical and photo, please refer to the physical.

OPERATING INSTRUCTIONS

1 Keep the unit stable, remove the cover shielding the water tank by carefully twisting counter clockwise then pull upwards. DO NOT lean the unit if there's water remaining.



2 Attach the DC plug of the adapter to the DC-IN jack, fix the power cord in the slot.




3 Add clean cold tap water to the water tank using the measuring cup, without exceeding the maximum waterline. DO NOT spill any water outside the tank. DO NOT use hot water or refill while the unit is in operation.

4 Add 6-9 drops of essential oil to the water.


5 Put the cover on the water tank and twist clockwise. Align the dot indicator on the bottom of the cover with the dot on the base. DO NOT tilt the unit to avoid spillage.

6 Connect the AC adapter to the power supply.



7 Press the "Mist" button for more than one second to turn on the mist. Set desired time [60/180/360minutes/ON or OFF] If you press the "Mist" button for more than one second, the unit will power off.

8 LIGHT: Press the "light" button to turn on the LED colour. The colour will change automatically. Press the "Light" button again to fix color. Press the "Light" button again to change colour. Press the "Light" button for more than one second and the LED will power off.



9 If the unit will not be used for a long time, please drain any remaining water, clean it and keep it in a dry and cool place. Clean it with diluted mild detergent before reusing. The unit is in power-off state when plugged into a power supply.

If the water level inside the unit runs low, it will automatically stop operating even if you activate it. LED light will power off when the timer is up.

1 YEAR WARRANTY

This product has been produced with the greatest care for normal, household use. Following directions carefully will ensure dependable operation. If you experience unsatisfactory operation or are dissatisfied with your Bosisto's Ultrasonic Diffuser please contact our friendly Customer Service team at FGB Natural Products.

Modification to the product by the consumer or failure to follow the manufacturer's operating instructions will void the warranty.

If repair is required under the warranty period, the product should be returned with proof of purchase.

The purchaser assumes responsibility for the proper care and use of the product in accordance with the printed operating manual. The purchaser or user must make his or her judgment as to when to use the product and the length of use. Keep the operating manual available as it is your guide to safe, efficient operation.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law 2011. You are entitled to a replacement of the faulty unit or refund for a major failure.

For warranty claims please call 1800 655 841

SPECIFICATIONS

[Dimensions] 110mm (d) x 154mm (h)

[Weight] Approx. 315g

[Power] Special Adapter

Input: AC 100-240V 50/60 Hz

Output: DC24V 600mA

Length of power line: Approx. 170cm

Power: Approx. 14.4 W

[Timer] 60/180/360mins/ON

[Applicable Area] 12-20 Sq metres

[Water Capacity] 300mL

[LED Light] 6 pcs

[Material] PP, ABS

[Noise] <20 DB

[Accessories]

Special AC Adapter

Water Cup

Manual Instructions

[Aromatherapy] Combination of water and essential oil can be spread as a small molecule under the high ultrasonic vibration. The essential oil is kept natural rather than damaged by heating.

[Ultrasonic Frequency] 2.4 MHz



Felton Grimwade & Bosisto's Pty. Ltd.
61-81 Clarinda Road (PO Box 74), Oakleigh South, VIC 3167, Australia
Website www.fgb.com.au E-mail mail@fgb.com.au Free Call 1800 655 841