

///0917

POWERAUDIO

Buds 01


True Wireless

Earphones



User Guide

Quick Start Guide



Packaging Contents

- 1 x Bluetooth earbuds
- 1 x Charging case
- 1 x Type-C cable
- 3 x silicon earplugs (S, M, L)

Operating Instructions

Charge the Earbuds

Please fully charge before first use.

- Place the earbuds into the case as they will charge automatically through the magnet.
- The LED light on the earbuds will turn solid red while the LED indicator on the charging case will flash white while charging the earbuds.
- Once the charging is complete, both LED indicator will turn off.

Note: Battery low -- LED will flash red every 30 seconds with a voice aprompt "battery low".

Charge the Charging Case

- Use the provided Type-C cable and connect to an adapter or computer to charge the case
- During charging, the LED indicator on the case will flash green. Once fully charged, the LED indicator on the case will turn solid green.

Note: Charging time is around 2 hours.

Pairing Instructions

1. Open the charging case, the earbuds will begin auto-pairing with each other.
2. The LED light on the earbuds will flash red and blue and go to device pairing mode.
3. Activate the Bluetooth function on your device to search for "0917 PA-BUDS EP" and connect it.

Single Earbuds Usage

Each earbud can be used independently.

Operating Instructions

ENC Tech

The ENC (Environmental Noise cancellation tech) algorithm cancels the background noise so that you can be heard crystal clear via voice calls. The earbuds are equipped with 4 mics and the ENC is already activated by default during calls.

Take Calls

- Answer/End call – Touch L/R earbud twice
- Reject an incoming call – Touch and hold L/R earbud 2 seconds until you hear a prompt tone.

Play Music

- Play/Pause – Touch L/R earbud twice
- Next track – Touch R earbud 3 times
- Previous track – Touch L earbud 3 times

Voice Assistant

Touch and hold L earbud for 2 seconds until you hear a prompt sound to active the Voice Assistant/ Siri function. This function may not work for all devices.

ANC Function

- Transparency On – Long press R for 2 seconds
- ANC On – Long press R for 2 seconds
- ANC Off – Long press R for 2 seconds

Operating Instructions

Power Off

- Method 1: Place the earbuds back into the charging case.
- Method 2: Touch and hold the earbuds for 5seconds until you hear prompt "Power off".

Reset the Earbuds

- Place L/R earbuds into the charging case, keep the case open and press the reset button on the charging case for 5s-7s.
- Note:** TWS will power off automatically without connecting to any device for 5mins.

Specifications

Bluetooth Version	5.4
ANC Level	-28dB
Hall Switch	Yes
Earbuds Battery	40mAh (2C fast charging)
Case Battery	500mAh
Usage Time	6.5H / 29H ANC off
	5.5H / 24.5H ANC on
Charging Time	Earbuds 0.8H
	Case 2H

For FAQs and more information, please visit:



WWW.0917LIFESTYLE.COM

Follow us on to get updates
on promos and discounts:

 @0917LIFESTYLEPH

 @0917

 @0917LIFESTYLE

You can also reach us at:

0917lifestylecustomercare@globe.com.ph