

2E

COLOR-CHANGE

- For cold color change, use ice water at approximately 32°F (0°C) for best results.
- Warm color change will start at approximately 100.4°F (38°C), but best results occur if the water is approximately 104°F (40°C).
- Not all included fashions or accessories change color.
- Color change will only work on certain parts of the doll's body.
- Extreme weather conditions may cause the color change pattern reveal upon arrival. To return it to its original color, place the doll in a room temperature area at approximately 68–77 °F (20–25 °C).
- If color change does not work properly or quickly, the temperature of the doll's body may be too close to the temperature of the water.
- Color change temperatures may vary according to weather conditions.

* WARNING

An adult must be present and supervise when placing the doll in warm water, as the water may be hot.

IMPORTANT INFORMATION

- Before beginning, cover the play area to protect from possible water damage.
- Your doll has a unique water feature and will either spit, pee, cry, or change color.
- One unique doll will color change in both warm and cold water. Try both!
- Certain dolls will have dual water features. These dolls will change color and either cry or pee.
- For best results, fill the bottle and feed the doll two times.
- Do not place the doll in extremely hot water.
- Do not feed the doll extremely hot water.
- An adult must be present when children are playing with water.
- Do not store the doll in direct sunlight for extended periods of time.
- Squeeze out all water from the bottle and the doll after each use.
- Thoroughly drain the doll on a dry towel in well-ventilated area after use and before storing.
- Air dry only. Do not place in the dryer or subject to excessive heat.
- Do not apply stickers to other surfaces, as it may not be completely removed.



www.LOLsurprise.com

© 2022 MGA Entertainment, Inc.

L.O.L. SURPRISE! FASHION SHOW™ is a trademark of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA.

MGA Entertainment, Inc.
9220 Winnetka Ave.
Chatsworth, CA 91311 U.S.A.
(800) 222-4685

MGA Entertainment (Netherlands) B.V.
Baronie 68-70, 2404 XG Alphen a/d Rijn
The Netherlands
Tel: +31 (0) 172 758 038

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill
Milton Keynes, MK8 0ES
Bucks, UK
+ 0800 521 558

Imported by MGA Entertainment
Australia Pty Ltd
Suite 2.02, 32 Delhi Road, Macquarie
Park NSW 2113
1300 059 676

The preferred method of contact for
Customer Service is through our e-mail
contact form at www.mgae.com

Printed in China
0322-0-E/INT

Please keep this manual as it contains important information.
Illustrations are for reference only. Styles may vary from actual contents.

LOL
SURPRISE!
FASHION
SHOW



AGES 3+
ADULT SUPERVISION REQUIRED
SKU: 584254 / 584261

 **WARNING:**
CHOKING HAZARD-Small parts.
Not for children under 3 years.

