aykah


ASSEMBLY SHEET



Theo/Eiffel Counter Stool









NO power tools required.



Time: 25 minutes



Use a damp cloth to clean.



Level of difficulty: 2/4

ASSEMBLY INSTRUCTIONS

Thank you for making a purchase with Aykah. The goal of this assembly sheet is to help you assembly the product in a way that will contribute to its longevity and durability. Kindly follow all the instructions carefully to ensure a safe and accurate assembling process.

A few important things to note:


- Please do not use a power tool to assemble this product. Using one may hinder and/or damage the item and will invalidate any claims for warranty.
- Depending on the amount of use this product receives, it may be recommended to tighten up the fixings from time to time. This is completely normal!

ID	Description	Qty
A	Metal Bracket	1
В	Metal Bracket	1
С	Metal Bracket	2
D	Legs	4
E	Seat \angle	1
F	Star	1
G	M6 X50 MM Bolt	4
H	M6 X40 MM Bolt	4
0	M6 X35 MM Bolt	4


ID	Description		Qty
7	M6 X16 MM Bolt	OMM)	4
К	Nut	0	12
	Сар		12
M	Washer	0	4
Z	Spring Pad		4
•	Allen Key		1
<u> </u>	Nut Holding Tool		1
©	Ring	0	4




Common Question: How to distinguish between metal pieces A, B and C? It should be engraved on the metal pieces. :)



Please Note for Step 3:
The screw is inserted in
the side that has a double
hole, not the side with a
single hole.









Note for Step 5:

Make sure metal parts A and B are facing in the opposite direction and are facing outwards, towards the leg as shown in the picture below.









Notes for Step 7 and Step 9:


Make sure metal part C is facing inwards in the same direction and towards the star as shown in the picture below.








aykah

Notes for Step 7 and Step 9: Make sure metal part C is facing in the same direction and towards the star as shown in the picture below.












Connect Circle "Q" with the bottom holes of all the 4 legs using screw "G".



Cover all screw ends with part "L" after tightening.



Connect the seat to the legs using "M", "N" and "J". Legs "AD" and "BD" are the front legs of the stool.



Connect the seat to the legs using "M", "N" and "J". The two "CD" legs are the back legs of the stool.