## ROSA INSTALLATION GUIDE

## SINGLE UNIT



## UNITS IN REPEAT



SINGLE UNIT IS REPEATED AND ROTATED IN ORDER:

U-90° ROTATE ONCE COUNTERCLOCKWISE  ${\circlearrowright}90^{\circ}$  rotate once clockwise

₹ 180° ROTATE TWICE

