

THANK YOU

for Purchasing the Ammo Can by Liberty Safe!





LIMITED **5-YEAR** WARRANTY

USE & CARE GUIDE

To activate your LIMITED 5-YEAR WARRANTY go to

WWW.LIBERTYSAFE.COM

The Ammo Can comes with a 5-year parts and labor warranty against manufacturer's defects (see reverse side for details)

LOST KEY PROCEDURE: In the event you lose your keys, please contact customer service to verify and replace. Key replacement cost is \$5 each plus \$5 shipping.

Call Customer Service Toll Free:

1.800.247.5625

- 3 Perma-shelves (Non-adjustable. Max Shelf Weight: 125 lbs.)
- Dual 4" locking bars
- · Key lock entry
- · 14 gauge steel body
- 1" CNC door edge
- · Quiet door bumper

Made in the USA

Congratulations on your purchase of your new Liberty Ammo
Can designed and built by America's #1 gun safe company—
Liberty Safe! To insure proper set up and
installation, PLEASE READ THIS INSTRUCTION SHEET
before opening your Ammo Can.

SAFETY PRECAUTIONS

The Ammo Can door/body is heavy. Do not open the door with the Ammo Can on an uneven or unstable floor. Hanging on an open door may cause the Ammo Can to tip forward when not lag-bolted to the floor, resulting in serious injury or death to yourself or others. If you have or have occasion to have small children in your home, please make sure you never leave your Ammo Can unsecured. It is possible for small children to climb inside your Ammo Can and become locked inside. This could result in serious injury or death. We recommend ammunition be stored according to the manufacturer's recommendations. The Ammo Can is not designed for storage of firearms or other valuables.

PACKAGING MATERIALS

After opening the Ammo Can, remove the plastic protectors or foam in the corners of the door. The left side of the door jamb has a foam door cushion installed and should not be removed.

INSPECT YOUR AMMO CAN

Inspect your Ammo Can for shipping damage as soon as you receive it. If you find any damage, please contact the delivery company (or carrier) immediately. Any damage not noted upon delivery must be reported within fifteen (15) days or there will be no recourse.

REMOVING THE AMMO CAN FROM PALLET

With the Ammo Can upright and open, pry up the black plastic caps on the floor to expose the mounting bolts. Use a 9/16" socket and ratchet to remove the bolts. Caution: Have someone steady the Ammo Can while removing the safe from the pallet to prevent the Ammo Can from tipping forward. Close and key-lock the door to prevent accidental opening while removing the Ammo Can from the pallet to the final location. Make sure you have adequate help to move the Ammo Can off its pallet. Carefully slide the Ammo Can off the pallet until one edge is resting on the floor. While the Ammo Can is tilted on its edge, remove the pallet out from under the Ammo Can. Carefully lower the Ammo Can back to its upright position.

Recommendation: If you want help to have the pallet removed and the Ammo Can installed as described above, contact your local Liberty dealer.

PLACEMENT OF YOUR AMMO CAN

Before moving your Ammo Can, verify the load bearing weight of the floors and stairs, and types of flooring the Ammo Can will be moved over (tile, wood, and other flooring can be damaged by the weight of the Ammo Can). We recommend placing a protective barrier (such as a piece of carpet, treated wood or rubber mat) between the Ammo Can and floor to prevent scratching of the Ammo Can surface, which could lead to rust, and to protect your floor. To determine whether or not your Ammo Can will fit through doorways, stairs or corners take the empty Ammo Can shipping box and see if it will fit all the way through to its final location.

Proper installation and anchoring are critical to the protection of your Ammo Can and its contents. Make sure you consider the following:

- Install near a load-bearing wall as a precaution to supporting the weight of the Ammo Can.
- To help protect the exterior finish of your Ammo Can, install inside your home in a dry location where there is climate control (heat in the winter and cooling in the summer).
- Placing your Ammo Can away from potential hot spots (near flammable materials) or next to cement walls helps slow heating during a fire.

Note: The Ammo Can does not have a fire or BTU rating or heat expanding Palusol® door seal. Liberty has installed one layer of fireboard on each wall to support ammo shelves and includes one in the door panel.

ANCHORING YOUR AMMO CAN

To achieve the highest level of security and safety possible, anchor your Ammo Can securely to the floor. Before anchoring, make sure the Ammo Can is level. Use redwood door shims to adjust the Ammo Can level so the door has the desired swing. Use appropriate hardware for the wood or cement surface you are anchoring to. Anchoring kits with instructions are available from your dealer. If given enough time it is possible for a thief to break into security devices. The Ammo Can is built as a cabinet with simple security features. It is not a safe. Securing it to the floor helps secure and prevent removal of the Ammo Can by thieves. We also recommend Liberty's SAFELERT security device which can monitor your Ammo Can (or any safe) 24/7 for any movement, vibrations, temperature changes, and door openings. SAFELERT also sends weekly email status reports including humidity levels.

KEEP YOUR AMMO CAN INTERIOR DRY

It is recommended that the interior of your Ammo Can be kept at a low relative humidity. Visit www.LibertySafe.com and choose the "accessories" tab to view dehumidifier options.

LIMITED FIVE (5) YEAR WARRANTY

LIMITED FIVE (5) YEAR WARRANTY: Liberty Safe and Security Products, Inc. (Liberty) is proud of the workmanship of the product you have just purchased. Liberty warrants that each new Ammo Can will be free from defects in material and workmanship, including the lock and paint, for five (5) years from the date of purchase. If there is a defect as described during the five (5) year time period, Liberty will repair the Ammo Can at no cost to purchaser. Any damage from a fire, break-in or break-in attempt is not included in this Ammo Can limited warranty. This warranty does not cover products damaged or rendered defective due to accident, misuse, abuse, modification, water damage, neglect, reloading, improper handling or storage, or failure to follow instructions for use unusual or extreme conditions and/or environments, or to unreasonable wear and tear. Changing or modifying the Ammo Can in ways that affect its intended use will void this warranty. Liberty's obligation under the Limited Five (5) Year Warranty is limited to the repair (including labor) of any product that proves to be defective as set forth above. The repair will be without charge except for reasonable shipping, handling and insurance charges. This warranty is non-transferrable.

WARRANTY REGISTRATION: Online Registration Only. Online registration must be completed within (30) days of purchase. Failure to register the product shall void any warranty. Visit www.LibertySafe. com for additional info.

WARRANTY CLAIMS: Claims shall be made under this warranty by calling 800-247-5625 or writing to Liberty Safe and Security Products, 1199 West Utah Avenue, Payson, Utah 84651.

NO OTHER WARRANTIES: This agreement is understood to be the complete and exclusive agreement between the parties, superseding all prior agreements, oral or written, and all other communications between the parties relating to the subject matter of this agreement. No employee of Liberty or any other party is authorized to make any warranty in addition to those made in this agreement.

WARNING: Ammunition, gun powder, primers, brass, etc. may be hazardous materials. The storage of hazardous materials may be restricted by Federal, State, and/or Local law. Liberty does not and cannot grant the right or authority to persons to possess or store items in a manner which may be regulated pursuant to such laws.

REPAIR AS PROVIDED HEREIN IS YOUR EXCLUSIVE REMEDY FOR ANY DEFECTIVE PRODUCT. THIS WARRANTY PERTAINS ONLY TO THE LIBERTY AMMO CAN ITSELF, AND DOES NOT EXTEND TO THE CONTENTS OF THE AMMO CAN, MANNER OF STORAGE, OR ANY DAMAGES RESULTING THEREFROM. FOR OPTIMAL SECURITY AND PROTECTION, THE AMMO CAN SHOULD BE BOLTED TO THE FLOOR. PLEASE REFER TO THESE INSTRUCTIONS FOR DETAILS ON ANCHORING YOUR AMMO CAN TO THE FLOOR.

DISCLAIMER OF WARRANTY:

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH EXTENDS BEYOND THE WARRANTY SPECIFIED ABOVE. ANY WARRANTIES IMPLIED BY LAW SHALL IN NO EVENT EXTEND BEYOND DURATION OF THIS EXPRESS WARRANTY. IN NO EVENT SHALL THIS WARRANTY BE DEEMED TO COVER ANY SPECIAL, INCIDENTIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND ARISING OUT OF THE PURCHASE OR USE OF THIS PRODUCT, WHETHER BASED UPON CONTRACT, TORT, STATUTE OR OTHERWISE.