



Let's Move. Spare Parts.

Article No. LM202 Grey

02.2020




Brake levers, adjustment screws and brake housing.




Art. No. LM306.
Set Right + Left.

Rubber handle with tube, reflector and end stop.




Art. No. LM307 Left.
Art. No. LM308 Right.

Bushings with bottom tube stoppers.




Art. No. LM320.
Set Right + Left.

Height adjustment knobs.




Art. No. 0486.
Set Right + Left.

Mounting set for seat.




Art. No. LM324.
Set Right + Left.

Dome nuts for seat mounting.




Art. No. LM329.
Set 4 pcs.

Seat.




Art. No. LM310.

Unfold hook with mounting screws and spring.




Art. No. LM311.

Linkage arm with reinforcement, screws and hook.




Art. No. LM312 Left.

Linkage arm with reinforcement and screws.




Art. No. LM321 Right.

Brake wire guide inside rear leg.




Art. No. LM313.
Set Right + Left.

Top caps for front tubes.




Art. No. LM319.
Set Right + Left.

Front fork with front fork bearings.




Art. No. LM318.
Set Right + Left.

Front fork bearings.




Art. No. LM322.
Set Right + Left.

Rear wheel bracket with screws.




Art. No. LM323.
Set Right + Left.

Brake yokes.




Art. No. LM328.
Set Right + Left.

Wheel with bearings and mounting set.




Art. No. LM317.

Ball bearings for front and rear wheels.




Art. No. LM477.
Set 4 pcs.

Brake wire with spring and pin for left and right side.



Art. No. LM305.
Set 2 pcs.

Middle screw for folding cross, complete.



Art. No. 0493.