

尺寸：145mm*210mm

骑马钉

材质：封面128g铜版纸，内页80g 书纸

出血：5mm



E-mail:

support@taotronics.com

MANUFACTURER

Manufacturer: Shenzhen NearbyExpress Technology Development Co.,Ltd.
Address: Floor 7, Building E, Galaxy World Phase II, Shenzhen, China

Learn more about the EU Declaration of Conformity:
<https://www.taotronics.com/pages/user-manual>



Rev_1.1_EN-DE

Model: TT-AP003
Air Purifier
User Guide

Languages

English	01-13
Deutsch	15-28

Contents

IMPORTANT SAFETY INSTRUCTIONS	01
Specifications	02
Knowing Your Air Purifier	02
Getting Started	03
Using Your Air Purifier	04
Replacing the HEPA Filter	07
Cleaning and Maintenance	08
Troubleshooting	10
Warranty and Service	12



Thanks for choosing TaoTronics Air Purifier. Please read this User Guide thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

BEFORE USING THIS APPLIANCE READ ALL INSTRUCTIONS AND CAUTIONARY MARKINGS IN YOUR USER GUIDE AND ON THE APPLIANCE

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:


- Read all instructions before using the appliance.
- **IMPORTANT** - This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to rig this safety feature.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by person responsible for their safety.
- To avoid fire or shock hazard, plug the appliance directly into a right AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves, or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grille, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug, not the cord.
- NEVER drop or insert any objects into any openings.
- DO NOT run the cord under carpeting.
- DO NOT cover the cord with throw rugs or similar coverings.
- DO NOT route the cord under furniture or appliances. Arrange the cord away from traffic area and where it will not be tripped over.
- DO NOT operate any appliance with a damaged cord or plug, if the motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Send to Customer Service for assistance.
- Use appliance only for intended household purposes as described in this manual. Any other use is not recommended that may cause fire, electric shock, or injury to persons.
- DO NOT place anything on top of the unit.
- NEVER block the air openings, grille / outlets or place the unit on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air inlet or outlet.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.

FOR HOUSEHOLD USE ONLY READ AND SAVE THESE INSTRUCTIONS


Specifications

Model	TT-AP003
Operating Voltage	220-240V~50/60 Hz
Rated Power	36 W
Noise	55 dB (High Speed)


Knowing Your Air Purifier




Getting Started




1 Open Air Inlet Grill.




2 Press down U-shaped snap joint to take out Pre-Filter.



3 Hold pull tabs to take out HEPA Filter.




4 Remove from its plastic packaging.




5 Place HEPA Filter back (pull tabs facing out).



6 Align the slots and install Pre-Filter back.




7 Align the slots and buckle up Air Inlet Grill.




8 Place the unit on a firm, level and flat surface.

Using Your Air Purifier

Control Panel




LED Display Screen



Using Your Air Purifier

Quick Start of Your Air Purifier



1 Plug into an appropriate electrical outlet.



2 Tap to turn ON the air purifier.



AUTO MODE



3 Tap to activate Auto Mode, the fan speed will be adjusted intelligently.

4 Tap to turn OFF when finished using it.

Operation and Functions

Auto Mode



AUTO MODE



Indicator ON

- Tap to activate Auto Mode.
- When Auto Mode is enabled, the fan speed is adjusted intelligently according to the air quality.

Memory Function

The air purifier will always remember your last settings (except timer) when turned off, and will resume these settings when it is turned back on.

Using Your Air Purifier

Sleep Mode



SLEEP MODE




- Tap  to activate Sleep Mode.
- When Sleep Mode is enabled, the air purifier will run quietly under lowest possible fan speed, making it ideal for use while sleeping.

Fan Speed Control




SPEED






- Tap  repeatedly to cycle through the adjustable fan speeds: 1, 2, and 3 (Low, Medium, and High).
- When adjusting the fan speed under Auto or Sleep Mode, the Auto or Sleep Mode will be exited automatically.

Auto OFF Timer



TIMER




- Tap  repeatedly to select the desired auto off time (1, 2, 4 or 8 hours).
- When time reaches zero, the air purifier will go into standby mode.
- To cancel, tap  repeatedly to select 0 hour.

Child Lock





CHILD LOCK




- Press and hold  for 3 seconds to turn on or off the Lock function.


Replacing the HEPA Filter




- 1  will light up as a reminder to change the HEPA Filter.




- 2 Unplug the air purifier. Remove the old HEPA Filter and properly dispose of it.




- 3 Replace with a new one. Install the filters and air inlet grill back.



- 4 Plug in and tap  to turn on the air purifier.



TIMER

- 5 Press and hold  for 3 seconds to reset the HEPA Filter.


Note:

- **Important:** Always make sure the air purifier is turned off and unplugged before replacing the filter.
- It is recommended to replace the HEPA filter every 6 to 8 months (depending on the frequency of use and air quality).

Cleaning and Maintenance

Important: Always make sure the air purifier is turned off and unplugged before cleaning.

Cleaning the Air Purifier Body




Outer Surface

Wipe with a soft, dry cloth. If necessary, wipe with a damp cloth, then immediately dry.



Air Inlet Grill

Open air inlet grill, vacuum up dust with a vacuum cleaner or wipe it with a cloth.



Air Outlet Grill


Remove air outlet grill, vacuum up dust with a vacuum cleaner or wipe it with a cloth.

Note:


- DO NOT stick any foreign objects or your fingers inside of the unit.
- Never immerse the air purifier in water and never allow water to drip into the motor housing.
- For storage, you may leave the unit covered to protect it from dust. Store it in a cool, dry location.

Cleaning and Maintenance


Cleaning the Pre-Filter




1 Unplug the air purifier. Take out the Pre-Filter.




2 Vacuum the dust or wipe it with a cloth.



3 For heavy dust, soak with diluted common kitchen detergents for 10 minutes, and then clean.



4 Dry the Pre-Filter.



5 Install the Pre-Filter and air inlet grill back.

Note:

- It is recommended to clean the Pre-Filter at least once every two weeks. More frequent cleaning may be required depending on frequency of use and air quality.
- DO NOT clean with abrasive chemicals or flammable cleaning agents.

Troubleshooting

The following troubleshooting guide addresses the most common problems. If problems persist, feel free to contact the Customer Support at support@taotronics.com.

Problem	Possible Causes	Solution
Error Codes on LED Display	<ul style="list-style-type: none"> E1 Disassembly Protection 	<ul style="list-style-type: none"> Properly install all parts (Filters and Air Inlet Grille)
	<ul style="list-style-type: none"> E2 Sensor Failure 	<ul style="list-style-type: none"> Contact TaoTronics Support Team.
	<ul style="list-style-type: none"> E3 Abnormal Fan Speed 	<ul style="list-style-type: none"> Contact TaoTronics Support Team.
Filter Change Indicator does not turn off	<ul style="list-style-type: none"> The air purifier has been reset incorrectly. 	<ul style="list-style-type: none"> Replace the filter and reset by pressing and holding the Timer Button for 3 seconds.
Air purifier does not power on or respond to button controls	<ul style="list-style-type: none"> Unit is not plugged in or the power socket is not switched 	<ul style="list-style-type: none"> Connect the plug to a powered electrical outlet.
	<ul style="list-style-type: none"> Power socket is not working properly. 	<ul style="list-style-type: none"> Try plugging the air purifier into a different outlet.
	<ul style="list-style-type: none"> Power cord is damaged. 	<ul style="list-style-type: none"> Immediately stop using and contact TaoTronics Support Team.
	<ul style="list-style-type: none"> Air purifier is malfunctioning 	<ul style="list-style-type: none"> Contact TaoTronics Support Team.
Insufficient air flow	<ul style="list-style-type: none"> Fan speed is on low setting. 	<ul style="list-style-type: none"> Press Fan Speed Button to adjust the fan speed.
	<ul style="list-style-type: none"> Filter packaging has not been removed. 	<ul style="list-style-type: none"> Remove the filter from its packaging before use.
	<ul style="list-style-type: none"> Not enough free space around the unit. 	<ul style="list-style-type: none"> Leave 15 in / 38 cm of clearance for proper air flow.
	<ul style="list-style-type: none"> Filter is clogged and not replaced. 	<ul style="list-style-type: none"> Replace the filter.

Poor air purification quality	<ul style="list-style-type: none"> Room size exceeds the expected size the unit covers. 	<ul style="list-style-type: none"> Select the right air purifier as per the actual room size.
	<ul style="list-style-type: none"> Air intake or outlet is blocked. 	<ul style="list-style-type: none"> Remove objects blocking air intake or outlet.
	<ul style="list-style-type: none"> Filter is not properly placed inside the housing. 	<ul style="list-style-type: none"> Properly place the filter (see Replacing the HEPA Filter).
	<ul style="list-style-type: none"> Filter is dirty and cannot produce fresh air anymore. 	<ul style="list-style-type: none"> Replace the filter (see Replacing the HEPA Filter).
Excessive noise	<ul style="list-style-type: none"> Not enough free space around the unit. 	<ul style="list-style-type: none"> Leave 15 in / 38 cm of clearance for proper air flow.
	<ul style="list-style-type: none"> Filter packaging has not been removed. 	<ul style="list-style-type: none"> Remove the filter from its packaging before use.
	<ul style="list-style-type: none"> Foreign objects inside the unit. 	<ul style="list-style-type: none"> Immediately discontinue use and contact TaoTronics Support Team. DO NOT attempt to open the air purifier.
Producing an unpleasant odor	<ul style="list-style-type: none"> Unit is placed on an uneven surface. 	<ul style="list-style-type: none"> Place the unit on a level and flat place.
	<ul style="list-style-type: none"> Filter is dirty and cannot produce fresh air any more. 	<ul style="list-style-type: none"> Replace the filter (see Replacing the HEPA Filter).
	<ul style="list-style-type: none"> High humidity levels have caused mildew to grow on the filter. 	<ul style="list-style-type: none"> Replace the filter, and move the air purifier to a room where the relative humidity is less than 85% RH.

Warranty and Service

Thanks for choosing TaoTronics Air Purifier. This product is covered with TaoTronics product and labor warranty for 12 months from the date of its original purchase.

Additional Half-Year Warranty

Extend your warranty to **18** months by registering your new product on our website taotronics.com/warranty

The warranty will not apply in cases of:

- Accident, misuse, or repairs performed by unauthorized personnel.
- Any unit that has been tampered with or used for commercial purpose.
- Normal wear and tear of wearable parts.
- Use of force, damage caused by external influences.
- Damage caused by non-observance of the User Guide, e.g. connection to an unsuitable mains supply or non-compliance with the instructions.
- Partially or completely dismantled appliances.
- Defects caused by or resulting from damages from shipping or from repairs, service, or alteration to the product or any of its parts that have been performed by a repair person not authorized by TaoTronics.

We can only provide after sales service for products that are sold by TaoTronics or TaoTronics authorized retailers and distributors. If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

* Please have your invoice and order ID ready before contacting Customer Support.

TaoTronics

Model	TT-AP003	SUPPORT Should your product prove defective within the specified warranty period, or any questions regarding warranty or service, email us at support@taotronics.com.
Default Warranty Period	1 Year	
<i>Extend your warranty to 18 months at taotronics.com/warranty</i>		
Order ID		
Date of Purchase		
Purchased From		

Inhaltsverzeichnis

WICHTIGE SICHERHEITSHINWEISE	16
Spezifikationen	18
Wissen über Ihren Luftreiniger	18
Erste Schritte	19
Benutzung Ihres Luftreinigers	20
Austausch des HEPA-Filters	23
Reinigung und Pflege	24
Problemlösung	26
Garantie und Service	28



Vielen Dank, dass Sie sich für einen TaoTronics Luftreiniger entschieden haben. Bitte lesen Sie sich diese Bedienungsanleitung vor der Nutzung sorgfältig durch und bewahren Sie sie zur künftigen Bezugnahme gut auf.

WICHTIGE SICHERHEITSHINWEISE

Dieses Produkt sollte nur gemäß den Vorgaben, die in diesem Benutzerhandbuch aufgeführt werden, benutzt werden. Benutzung, die von diesen Bestimmungen abweicht, kann zu ernsthaften Verletzungen führen.

Bei der Nutzung von elektrischen Geräten sollten stets grundlegende Vorsichtsmaßnahmen eingehalten werden, um das Risiko von Feuer, Stromschlag und Verletzung von Personen zu vermeiden. So auch Folgende:

- Lesen Sie alle Hinweise, bevor Sie das Gerät benutzen.
- **WICHTIG** - Dieses Gerät verfügt über einen polarisierten Stecker (ein Stift ist breiter als der andere). Um das Risiko von Stromschlägen zu mindern, ist dieser Stecker so konstruiert, nur in einer Richtung in eine polarisierte Steckdose zu passen. Sollte der Stecker nicht richtig in die Steckdose passen, drehen Sie den Stecker um. Sollte er dann immer noch nicht passen, suchen Sie einen qualifizierten Elektriker auf. Versuchen Sie nicht, diesen Sicherheitsmechanismus zu umgehen.
- Um Feuer- und Stromschlaggefahr zu vermeiden, schließen Sie das Gerät direkt an einer korrekten AC Stromsteckdose an.
- Halten Sie das Kabel aus stark frequentierten Bereichen fern. Um Feuerrisiko zu vermeiden, legen Sie das Kabel NIEMALS unter Teppiche, Heizregister, Radiatoren, Öfen oder Heizkörper.
- Um sich vor Stromschlägen zu schützen, tauchen Sie das Gerät NICHT in Wasser oder andere Flüssigkeiten. Nicht in der Nähe von Wasser verwenden.
- Kinder können die Gefahren, die bei der Verwendung elektrischer Geräte auftreten können, nicht einschätzen. Deswegen sollten Kinder immer beaufsichtigt werden, wenn sie in der Nähe des Geräts sind.
- Trennen Sie den Luftreiniger stets vom Strom, wenn Sie ihn bewegen, das Gitter öffnen, Filter wechseln, ihn reinigen oder auch, wenn der Luftreiniger nicht benutzt wird. Ziehen Sie nur am Stecker und nicht am Kabel.

- Lassen Sie ihn NIEMALS fallen und stecken Sie keine Gegenstände in die Öffnungen.
- Verlegen Sie das Kabel NICHT unter Teppich.
- Bedecken Sie das Kabel NICHT mit Vorlegern oder ähnlichen Abdeckungen.
- Verlegen Sie das Kabel NICHT unter Möbelstücken oder Geräten. Verlegen Sie das Kabel fern von frequentierten Bereichen, damit niemand darüber stolpert.
- Verwenden Sie das Gerät NICHT mit beschädigtem Kabel oder Stecker, wenn das Motorgebläse nicht richtig rotiert, nachdem das Gerät ausgefallen oder heruntergefallen ist oder es auf irgendeine Art beschädigt wurde. Wenden Sie sich für weitere Hilfe an den Kundenservice.
- Verwenden Sie das Gerät nur für die vorgesehenen Haushaltszwecke, wie in dieser Bedienungsanleitung beschrieben. Jegliche andere Verwendung wird nicht empfohlen, da dies zu Feuer, Stromschlag oder Verletzung von Personen führen kann.


NUR FÜR DEN HAUSHALTSGEBRAUCH LESEN UND BEWAHREN SIE DIESE HINWEISE GUT AUF

Spezifikationen


Modell	TT-AP003
Spannung	220-240V~50/60 Hz
Nennleistung	36 W
Geräuschpegel	55 dB (Hohe Geschwindigkeit)

DE


Wissen über Ihren Luftreiniger




Erste Schritte




1 Öffnen Sie das Lufteinlassgitter.




2 Drücken Sie den U-förmige Einrastverschluss nach unten, um den Vorfilter herauszunehmen.




3 Greifen Sie die Ziehlaschen, um den HEPA-Filter herauszunehmen.




4 Entfernen Sie die Plastikverpackung.




5 Setzen Sie den HEPA-Filter wieder ein (Ziehlaschen zeigen nach vorne heraus).



6 Setzen Sie den Vorfilter nach korrektem Ausrichten wieder ein.



7 Verschließen Sie das Lufteinlassgitter wieder.




8 Stellen Sie das Gerät auf festen, ebenen und flachen Untergrund.


DE

Benutzung Ihres Luftreinigers

Bedienfeld




LED-Display




Benutzung Ihres Luftreinigers

Schnellstart Ihres Luftreinigers



1 Stecken Sie ihn an einer geeigneten Steckdose an.




2 Tippen Sie auf , um den Luftreiniger einzuschalten.




AUTO MODE

Anzeige AN



3 Tippen Sie auf , um den Auto-Modus zu aktivieren; die Lüftergeschwindigkeit passt sich dann intelligent an.

4 Tippen Sie nach der Nutzung zum Ausschalten auf .

Tastensteuerung & Funktionen


Auto-Modus



AUTO MODE



Anzeige AN

- Tippen Sie auf , um den Auto-Modus zu aktivieren.
- Bei aktiviertem Auto-Modus wird die Lüftergeschwindigkeit der Luftqualität entsprechend intelligent gesteuert.

Speicherfunktion

Der Luftreiniger merkt sich beim Ausschalten immer Ihre zuletzt gewählten Einstellungen (außer Timer) und nimmt diese automatisch wieder auf, wenn er eingeschaltet wird.

Benutzung Ihres Luftreinigers

Schlafmodus





- Tippen Sie auf ☾, um den Schlafmodus zu aktivieren.
- Bei aktiviertem Schlafmodus läuft der Luftreiniger leise bei der geringsten Lüftergeschwindigkeit, wodurch sich diese Einstellung ideal zum Schlafen eignet.

Lüftergeschwindigkeitssteuerung



- Tippen Sie wiederholt auf ⚙️, um durch die einstellbaren Lüftergeschwindigkeiten zu wechseln: 1, 2, 3.
- Wenn Sie die Lüftergeschwindigkeit im Auto- oder Schlafmodus ändern, wird der Auto- oder Schlafmodus automatisch beendet.

Auto Abschalt-Timer





- Tippen Sie wiederholt auf ⌚, um die gewünschte auto. Abschaltzeit einzustellen (1, 2, 4, 8h).
- Sobald die Zeit Null erreicht, wechselt der Luftreiniger in den Standby-Modus.
- Zum Abbrechen tippen Sie einfach wiederholt ⌚ an, um 0 Stunden auszuwählen.

Kindersperre





- Halten Sie 3 Sekunden lang gedrückt, um die Sperrfunktion ein- oder auszuschalten.

Austausch des HEPA-Filters



- 1 Leuchtet als Erinnerung daran auf, den HEPA-Filter zu wechseln.
- 2 Stöpseln Sie den Luftreiniger aus. Entnehmen Sie den alten HEPA-Filter und entsorgen Sie ihn ordnungsgemäß.



- 3 Ersetzen Sie ihn mit einem neuen. Setzen Sie die Filter und das Lufteinlassgitter wieder ein.
- 4 Stecken Sie ihn wieder ein und tippen Sie auf ⏻, um den Luftreiniger einzuschalten.



- 5 Halten Sie ⌚ 3 Sekunden lang gedrückt, um den HEPA-Filter zurückzusetzen.


Anmerkung:

- **Wichtig:** Achten Sie stets darauf, dass der Luftreiniger ausgeschaltet und der Stecker herausgezogen ist, bevor Sie den Filter wechseln.
- Es wird empfohlen, den HEPA-Filter alle 6 bis 8 Monate zu wechseln (je nach Nutzung sintensität und Luftqualität).

Reinigung und Pflege


Achten Sie darauf, dass der Luftreiniger vor dem Säubern ausgeschaltet und ausgesteckt ist.

Säubern des Luftreinigers




Außenfläche

Mit einem weichen, trockenen Tuch abwischen. Wenn nötig, mit einem feuchten Lappen abwischen und sofort trocknen.



Luftzugangsgitter

Öffnen Sie das Lufteinlassgitter, saugen Sie den Staub mit einem Staubsauger ab oder wischen Sie ihn mit einem Tuch ab.



Luftauslassgitter


Entnehmen Sie das Luftauslassgitter, saugen Sie den Staub mit einem Staubsauger ab oder wischen Sie ihn mit einem Tuch ab.

Anmerkung:


- Stecken Sie KEINE Fremdoobjekte oder Finger in das Gerät.
- Tauchen Sie den Luftreiniger nie in Wasser und lassen Sie kein Wasser in die Motorgehäuse eindringen.
- Zur Aufbewahrung können Sie das Gerät abdecken, um es vor Staub zu schützen. An einem kühlen, trockenen Ort lagern.

Reinigung und Pflege


Reinigen des Vorfilters




1 Stöpseln Sie den Luftreiniger aus. Nehmen Sie den Vorfilter heraus.



2 Saugen Sie den Staub ab oder wischen Sie ihn mit einem Tuch weg.



3 Lassen Sie ihn bei starker Verschmutzung 10 Minuten lang und säubern Sie ihn dann.



4 Lassen Sie den Vorfilter trocknen.



5 Setzen Sie Vorfilter und Lufteinlassgitter wieder ein.

Anmerkung:

- Es wird empfohlen, den Vorfilter mindestens alle zwei Wochen zu reinigen. Je nach Nutzungsintensität und Luftqualität kann häufigeres Reinigen erforderlich werden.
- Verwenden Sie zum Reinigen KEINE aggressiven Chemikalien oder entflammenden Reinigungsmittel.

Problemlösung

Die folgende Problemlösungsanleitung behandelt die häufigsten Probleme. Sollte das Problem bestehen bleiben, kontaktieren Sie gerne den Kundenservice unter support@TaoTronics.com.

Problem	Mögliche Ursachen	Lösung
Fehlercode auf dem LED-Display	<ul style="list-style-type: none"> E1 Demontage-Schutzhinweis 	<ul style="list-style-type: none"> Setzen Sie alle Teile ordnungsgemäß ein.
	<ul style="list-style-type: none"> E2 Sensorfehler 	<ul style="list-style-type: none"> Kontaktieren Sie das TaoTronics Support-Team.
	<ul style="list-style-type: none"> E3 Unnormale Lüftergeschwindigkeit 	<ul style="list-style-type: none"> Kontaktieren Sie das TaoTronics Support-Team.
Filterwechsel-Anzeige geht nicht aus	<ul style="list-style-type: none"> Der Luftreiniger wurde nicht richtig zurückgesetzt. 	<ul style="list-style-type: none"> Setzen Sie ihn zurück, indem Sie die Timer-Taste 3 Sekunden lang gedrückt halten.
Luftreiniger lässt sich nicht einschalten oder reagiert nicht auf Tasteneingaben	<ul style="list-style-type: none"> Das Gerät ist nicht eingesteckt oder die Steckdose ist nicht eingeschaltet. 	<ul style="list-style-type: none"> Stecken Sie den Stecker in eine aktive Steckdose.
	<ul style="list-style-type: none"> Die Steckdose funktioniert nicht richtig. 	<ul style="list-style-type: none"> Testen Sie den Luftreiniger an einer anderen Steckdose.
	<ul style="list-style-type: none"> Das Stromkabel ist beschädigt. 	<ul style="list-style-type: none"> Kontaktieren Sie das TaoTronics Support-Team.
	<ul style="list-style-type: none"> Luftreiniger funktioniert nicht richtig. 	<ul style="list-style-type: none"> Kontaktieren Sie das TaoTronics Support-Team.
Unzureichender Luftfluss	<ul style="list-style-type: none"> Die Lüftergeschwindigkeit ist zu niedrig eingestellt. 	<ul style="list-style-type: none"> Stellen Sie die Lüftergeschwindigkeit ein.
	<ul style="list-style-type: none"> Die Filterverpackung ist nicht entfernt worden. 	<ul style="list-style-type: none"> Nehmen Sie den Filter vor der Verwendung aus der
	<ul style="list-style-type: none"> Nicht genügend Freiraum um das Gerät. 	<ul style="list-style-type: none"> Lassen Sie 38 cm / 15 in Platz für ausreichend Luftfluss.
	<ul style="list-style-type: none"> Der Filter ist verstopft und wurde nicht ausgetauscht. 	<ul style="list-style-type: none"> Tauschen Sie den Filter aus.

Schlechte Luftreinigungsqualität	<ul style="list-style-type: none"> Die Raumgröße überschreitet die vom Gerät abgedeckte Größe. 	<ul style="list-style-type: none"> Wählen Sie den richtigen Luftreiniger.
	<ul style="list-style-type: none"> Luftzufluss oder -auslass ist blockiert. 	<ul style="list-style-type: none"> Entfernen Sie Objekte, die Lufteinlass oder -auslass blockieren.
	<ul style="list-style-type: none"> Der Filter ist im Gehäuse nicht richtig eingesetzt. 	<ul style="list-style-type: none"> Setzen Sie den Filter korrekt ein (siehe "Austausch des HEPA-Filters").
	<ul style="list-style-type: none"> Der Filter ist dreckig und kann keine frische Luft mehr produzieren. 	<ul style="list-style-type: none"> Tauschen Sie den Filter aus.
Übermäßiger Lärm	<ul style="list-style-type: none"> Nicht genügend Freiraum um das Gerät, um Belüftung zu garantieren. 	<ul style="list-style-type: none"> Lassen Sie 38 cm / 15 in Platz für ausreichend Luftfluss.
	<ul style="list-style-type: none"> Die Filterverpackung ist nicht entfernt worden. 	<ul style="list-style-type: none"> Nehmen Sie den Filter vor der Verwendung.
	<ul style="list-style-type: none"> Fremdobjekte im Inneren des Geräts. 	<ul style="list-style-type: none"> Kontaktieren Sie das TaoTronics Support-Team. Versuchen Sie NICHT, den Luftreiniger zu öffnen.
Unangenehme Geruchsbildung	<ul style="list-style-type: none"> Das Gerät steht auf unebenem Untergrund. 	<ul style="list-style-type: none"> Stellen Sie das Gerät auf eine gleichmäßige, ebene Fläche.
	<ul style="list-style-type: none"> Der Filter ist dreckig und kann keine frische Luft mehr produzieren. 	<ul style="list-style-type: none"> Tauschen Sie den Filter aus.
	<ul style="list-style-type: none"> Hohe Luftfeuchtigkeit hat dazu geführt, dass sich Schimmel auf dem Filter bildet. 	<ul style="list-style-type: none"> Ersetzen Sie den Filter und stellen in einen Raum, in dem die relative Luftfeuchtigkeit unter 85% liegt.

Garantie und Service

Dieses Produkt beinhaltet eine TaoTronics Produkt- und Verarbeitungsgarantie für 12 Monate ab Kaufdatum.

Sollten Probleme auftreten, kontaktieren Sie bitte das TaoTronics Kundenservice-Center mithilfe der Kontaktdetails in dieser Bedienungsanleitung.

Wir können Kundenservice nur für Produkte anbieten, die von taotronics oder von durch taotronics autorisierten Verkäufern und Händlern verkauft wurden. Sollten Sie Ihr Gerät anderweitig erworben haben, kontaktieren Sie bezüglich Rücknahme- und Garantiefragen bitte Ihren Verkäufer.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.



WEEE Compliance

Correct Disposal of This Product (Waste Electrical & Electronic Equipment) (Applicable in countries with separate collection systems) This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.