




Model: TT-BH095 TaoTronics SoundLiberty 95 True Wireless Stereo Earbuds **User Guide** 

## Package Contents



- ① TaoTronics True Wireless Stereo Earbuds (TT-BH095)
- ② 1 x USB-C Charging Cable

3 1 x User Guide

4 1 x Quick Start Guide

⑤ LED Indicator


- ⑦ Charging Indicator
- ® USB-C Charging Por
- Oharging Case
- 10 Reset Button

# Product Diagram




### ① Microphone 6 Charging Slot ② Multifunction Touch Control

- 3 Charging Contacts
- 4 Microphone



# Important Safety Instructions



## heat such as direct sunlight or fire to avoid explosion.

## **Wear Your Earbuds**

 Do not expose this product to high temperatures. Please wear the earbuds as shown below.

### benzene or abrasives. Avoid dropping.

• Place the earbuds back into the charging case when not in use and keep it away from children and pets to avoid choking hazard. • Unauthorized disassembly of any parts of this product is forbidden, which may

Always ask a professional technician or authorized personnel for repair.

• Do not immerse the earbuds into water or expose them to humidity for a

· Do not clean the product with detergent containing alcohol, ammonia,

- cause fire hazard, warranty voidance, and/or property loss. Close attention is needed when using near children.
  - Keep the charging case away from water, rain or any other liquid.
  - Don't use the product in thunderstorm to avoid malfunction or electric shock.

This product contains lithium battery. Never expose it to excessive

- Charging

2. Cover the lid and charging will start automatically.



When the device is connected wirelessly to another device, place

fences may shorten the effective range.

environmental circumstances.

- the two devices close to each other to achieve their normal functionalities and avoid possible signal interference.
- obstacles between the two devices. Obstacles including walls and

# **Using Your Earbuds**

- When battery is low, a "Battery low" voice prompt will be heard

1. Put the earbuds into the charging case as per the L (left) and R (right) marks.

## Charging the Charging Case

- 1. Connect the charging port with any USB charging adapter or active computer USB port.
- 2. The charging indicator will stay solid white, and turn off once fully charged.



• When using a wireless connection, make sure there are no


Charging the Earbuds

- The maximum effective Bluetooth range may vary with the

Pictures only for reference.

- Please fully charge the earbuds when using them for the first time.
- (if you are wearing the earbuds). Please charge in time or the earbuds will turn off automatically around 10 minutes later.
- Charge the earbuds at least once every 3 months when not using for a long time.

Power On



Uncover the lid and they will power on automatically

Unplug the charging cable (timely) when fully charged.

Put the earbuds into the charging case and close the lid, they will turn

**Power Off** 

Pairing




- 3. After the left one is connected, press and hold the Reset button for 3 seconds,
- 4. Once connected, the LED indicator on the charging case will flash blue slowly.

- will attempt to pair with the last connected device for the first 20 seconds. If re-pairing failed in 20 seconds, the earbuds will enter
- You can use one earbud or both earbuds as per your preference. Please refer to the corresponding pairing instructions.
- Before pairing, please turn off other Bluetooth devices and place the device to be connected close to the earbuds.
  - they will turn off automatically.

# Couple Earbuds Mode

\* Make sure both earbuds are placed in the charging case with the lid uncovered when pairing with your device.



- Find "TAOTRONICS SoundLiberty 95" in the searching results, tap on the name to connect with the left earbud.
- the indicator on the charging case will flash blue and white alternately. Find "TAOTRONICS SoundLiberty 95 R" in the searching results, tap on the name to connect with the right one. (This operation is for later switching of primary and secondary earbud).

1. Uncover the lid to turn on the earbuds, they will connect with each other

- The earbuds can remember the devices paired previously, and pairing mode.
- It is not recommended to wear the two earbuds on different people. If necessary, please keep the two earbuds close to each other in couple earbuds mode.
- · Please ensure both earbuds stays in the charging case and the lid is uncovered during pairing.
- When the earbuds are disconnected from your device for more than 10 minutes.



## support@taotronics.con MANUFACTURER

Manufacturer: Shenzhen Nearby Express Technology Development Co., Ltd Address: Floor 7, Building E, Galaxy World Phase II, Shenzhen, China



Rev\_1.3\_EN

the name to connect.

10 seconds.

the name to connect.

automatically.

## Single Earbud Mode

Pair both earbuds with your device in Couple Earbuds Mode before using in Sinale Earbud Mode.

### Use Primary (Left) Earbud Only

- case flashing blue and white alternately. 1. Take out the primary (left) earbud from the charging case, and make sure the secondary (right) earbud is placed in the charging case and the lid is covere
- 2. It will try to pair with the last connected device for the first 20 seconds. If re-pairing failed in 20 seconds, the earbud will enter pairing mode with voice prompt "Pairing" every 10 seconds.
- 3. Turn on the Bluetooth function on your device and search for the nearby devices. Find "TAOTRONICS SoundLiberty 95" in the searching results, tap on

### Use Secondary (Right) Earbud Only

- 1. Take out the secondary (right) earbud from the charging case, and make sure the primary (left) earbud is placed in the charging case and the lid is covered.
- 2. The secondary earbud will enter pairing mode with voice prompt "Pairing" every
- 3. Turn on the Bluetooth function on your device and search for the nearby devices, Find "TAOTRONICS SoundLiberty 95 R" in the searching results, tap on

Learn more about the EU Declaration of Conformity https://www.taotronics.com/pages/user-manual

If you want to change to couple mode, simply take out the other earbud from the charging case, they will pair with each other

1. Place both earbuds back in the charging case with the lid uncovered.

Manually Pairing

### 2. Press and hold the **Reset Button** for 3 seconds to disconnect the currently as instructed below:

- 3. The earbuds will enter pairing mode with the LED indicator on the charging
- 4. Pair with your new Bluetooth® device as instructed in "Pairing" section. 3. If you have paired your device with the earbuds before, remove

The pairing history will not be cleared under this operation.

## If you failed to pair your device with the earbuds, please clear the pairing history

- 1. Place both earbuds back in the charging case with the lid uncovered.
- charging case flash blue and white alternately. Tap the Touch Control on the right
  - "TAOTRONICS SoundLiberty 95" from the Bluetooth device list and pair again.

above if pairing failed.

Tap the Touch Control on the If you want to pair the earbuds with another device when you have already paired them with a device deactivate the Bluetooth function on the paired device or clear "TAOTRONICS SoundLiberty 95" from its Answer via earbuds: Bluetooth list. Restore the earbuds to factory settings as instructed

Clear Pairing List

- earbud twice under music

Tap the Touch Control on either of

## Operation and Functions

- 2. Press and hold the **Reset Button** for 8 seconds until the LED indicator on the Only available in Couple Earbuds Mode:
- 4. Re-pair with your Bluetooth® device as instructed in "Pairing" section. Tap the Touch Control on the

### right earbud three times

Answer via mobile phone:

Tap the Touch Control on either of the

earbuds three times

Bluetooth out of Range / Failed to Tap Answer on the mobile phone Disconnected Tap the Touch Control on either of the

· Couple Earbuds Mode:

Tap the Touch Control on the left

earbud twice until a beep is heard

Tap the touch control on either of the

earbuds twice until a beep is hear

Refer to the "Clear Pairing List"

Only when you are wearing the earbuds can you hear the voice prompt.

Cleaning and Maintenance

1. Clean the earbuds and the charging case on a regular basis.

4. Put the unit in a dry and shady place if it is to be idle for a long time.

2. Use dry and soft cotton cloth to wipe the unit.

3. Keep away from sharp objects to avoid scratches.

5. Do not clean the product with detergent or chemicals.

Note: Do not insert anything into the product.

# Failed to pair the

No. Problem

Failed to turn on the

Failed to charge th

## urn on the device and activate its Bluetooth function before pairing Bring the earbuds into pairing mode

# Multifunction Touch as instructed in the "Pairing" section

### case and cover the lid, disconnect the 11 control of the earbuds Bluetooth connection. Uncover the lid to

a phone call

# turn on the earbuds and pair again.

ace the two earbuds into the charging

arbuds low battery, please charge them

Place the earbuds into the charging

Make sure the charging cable is intact

The earbuds reconnected with previously

Bluetooth device list, and then search again

Put the device to be connected close to

• Make sure the charging case is

and plugged in properly

paired device automatically:

### case then take them out, they will pair No sound in one of the with each other automatically. If pairing earbuds in couple ailed, restore them back to the factory earbuds mode settings as instructed in the "Clear Pairing

Place both earbuds back to the chargi

# · Wear the earbuds properly and keep

### them close to each other. Place the connected device close to tl Poor sound quality earbuds or remove the obstacles

List" section

- Clear the debris on the earhuds
- · Keep the earbuds close to your Bluetooth

### The effective distance may shorten w 8 Unstable connection obstacles in the way

- Turn off other Bluetooth devices to
- Deactivate the Bluetooth function of decrease the interference previously paired device or clear
- Can't hear the other 'TAOTRONICS SoundLiberty 95" from its Set the volume to higher level party during a phone ca

The other party can't

hear your voice during

instructions, may cause harmful interference to radio communications. How there is no guarantee that interference will not occur in a particular installation Free the built-in microphone of any

following measures:

Bluetooth

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

under license. Other trademarks and trade names are those of their respective owners.

- Reorient or relocate the receiving antenna. terms and conditions of the purchase contract. This product and its electronic
- Increase the separation between the equipment and receiver.

# Warranty and Service

If any problems occur, please contact the TaoTronics Customer Care Centre via the contact information listed in this User Guide. Changes or modifications not expressly approved by the party responsible for

> compliance could void the user's authority to operate the equipment This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

> > (1) this device may not cause harmful interference, and

the receiver is connected.

(2) this device must accept any interference received, including interference The Bluetooth® word mark and logos are registered trademarks owned by th that may cause undesired operation. Bluetooth SIG. Inc. and any use of such marks by Sunyalleytek International Inc. is





Class B digital device, pursuant to part 15 of the FCC Rules. These limits are Correct Disposal of This Product (Waste Electrical & Electronic Equipment) designed to provide reasonable protection against harmful interference in (Applicable in countries with separate collection systems)

residential installation. This equipment generates uses and can radiate radi This marking on the product, accessories or literature indicates that the product frequency energy and, if not installed and used in accordance with the and its electronic accessories should not be disposed of with other household

accessories should not be mixed with other commercial wastes for disposal.

- Connect the equipment into an outlet on a circuit different from that to which

· Consult the dealer or an experienced radio/TV technician for help

waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate

these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact

either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the