




# AXCALIBAR PRO AXLES

## INSTALLATION INSTRUCTIONS

Your new Axcalibar Pro Axle features a new hard chrome surface coating. It is more durable than a regular show chrome finish, and will keep your axle looking new for a longer period of time!

Before installation, we highly recommend applying some high quality water proof grease to the splines and threads of the axle. It will help protect your hubs from wear, and also be easier to maintain your hubs should they need to be removed.

*Your new axle comes with a tapered spacer that must be installed over the wheel hub area first. Failure to do so will result in damage to the axle, wheel hub, and possible serious injury! See diagram :*



***Make sure to retighten all your hubs, and lock nuts after your first ride, and check them periodically to prevent premature wear!***

**CLEANING/ MAINTAINING:** Use soap and water to clean, taking care not to use high pressure pointed at the bearing housing and chain. Periodically check all hubs and locknuts for tightness!

LONE STAR RACING - 744 W. CRESCENT AVE. MESA, AZ 85210

1-800-4LS-RACE WWW.LSRACING.COM




# AXCALIBAR PRO AXLES

## INSTALLATION INSTRUCTIONS

Your new Axcalibar Pro Axle features a new hard chrome surface coating. It is more durable than a regular show chrome finish, and will keep your axle looking new for a longer period of time!

Before installation, we highly recommend applying some high quality water proof grease to the splines and threads of the axle. It will help protect your hubs from wear, and also be easier to maintain your hubs should they need to be removed.

*Your new axle comes with a tapered spacer that must be installed over the wheel hub area first. Failure to do so will result in damage to the axle, wheel hub, and possible serious injury! See diagram :*



***Make sure to retighten all your hubs, and lock nuts after your first ride, and check them periodically to prevent premature wear!***

**CLEANING/ MAINTAINING:** Use soap and water to clean, taking care not to use high pressure pointed at the bearing housing and chain. Periodically check all hubs and locknuts for tightness!

LONE STAR RACING - 744 W. CRESCENT AVE. MESA, AZ 85210

1-800-4LS-RACE WWW.LSRACING.COM