




QUARTZ MOVEMENT | QUARZ UHRWERK

MIYOTA GL 30



ACCURACY PER MONTH
 ± 20 sec

BATTERY
SR6261W

BATTERY LIFE
Appx. 3 Years

GANGGENAUIGKEIT (MONAT)
 ± 20 sek

BATTERIE
SR621SW

BATTERIE LEBENSDAUER
Ca. 3 Jahre



QUARTZ MOVEMENT | QUARZ UHRWERK

MIYOTA GL 30

INSTRUCTION MANUAL

SETTING THE TIME

1. Pull the crown out to the 1st position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position, the second hand begins to run.

GEBRAUCHSANLEITUNG

ZEIT EINSTELLEN

1. Krone auf Position 1 ziehen.
2. Krone drehen um den Stunden- und Minutenzeiger einzustellen.
3. Krone wieder auf die Normalposition stellen; Sekundenzeiger bewegt sich wieder.