

1998 TO PRESENT BED ASSEMBLY OR BED EXTENSION REPLACEMENT

A major design change in the attachment of the bed extensions occurred on 1998 model bed assemblies. Adjustments for bed tightness (working hard) can be made by adding or removing flat washers located behind the nylon wheels fastened to the body rail (refer to diagram). A minimum of one flat washer should be installed behind the nylon wheels at all times.

To remove or replace a bed extension, pull the bed assembly outward until the plastic end cap can be removed from the outer end of the bed extension. Extend the opposite bed assembly out of the trailer. (Note: Ensure bed assemblies are supported by the attached bed legs.) Remove the plastic end cap and slide the bed extension inward until disengaged from the nylon wheels on the bed frame and body rail. Slide the replacement bed extension over the nylon wheels and re-attach the plastic end cap.

