

1968



Camping Trailers




INDEX

Parts List	CT-280	2 and 3
	CT-281	4 and 5
	CT-282	6 and 7
	CT-280s	8 and 9
	CT-290	10 and 11
	CT-291	12 and 13
	CT-290s	14 and 15
	Miscellaneous Parts	16 thru 18

1968
CT-280

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4720A5241	Top Ass'y. Complete (Not shown as a unit)	40.	4720A1471	Body Corner Panel	93.	4720A2101	Panel End Short
1.	4720A1841	Top Panel Rear	41.	4720A1801	End Rail Front	94.	4720A2061	Panel R.S. Rear
2.	4720A1811	Top Panel Front	42.	4720A1391	Right Front Body Panel	95.	4720A2071	Panel R.S. Front
3.	4720A1821	Top End Panel	43.	4720A6261	Body Panel Front (With 4730A318 metal cal & 4730A322 x 2 tongue seals attached)	96.	4720A2081	Panel R.S. Middle
4.	4720A1851	Top Corner				97.	4720A2041	Panel C.S. Rear
5.	4720A3271	Top Seal Long	44.	4720A1371	Left Side Body Panel	98.	4720A2051	Panel C.S. Front
6.	4720B5411	Lift Bracket Ass'y.	45.	4720A1361	Side Rail Left	99.	4720A2031	Panel C.S. Middle
7.	4720B1681	Top Channel Side	46.	4720A1381	Right Rear Body Panel	100.	4720A2121	Corner Divider x 4
8.	4720A1831	Roof Rib	47.	4720A1351	Side Rail Right Rear	101.	4720A2111	Panel Divider x 4
9.	4720A0951	Door Support Tube x 2 (4720A331 Plate x 3)	48.	4720A1491	Body Panel Rear	102.	4730A4931	Panel Divider x 1
10.	4720A0941	Door Support x 2 (With spring washer 1202C383)	49.	4720A1451	Tail Light Cover	103.	4720A5561	Dinette Table
11.	4720A2611	Screen Door Brkt. x 2	50.	4730A1801	Coleman Name Plate (With 3 pushnuts 1201C793)	104.	4720A3161	Toilet Box Top
12.	4720A5961	Support Plate Ass'y. x 1	51.	4730A5991	Tail Light Ass'y. Package (Includes 4720A146 cover retainer, 4720A308 tail light trim, 4720-315 Tail light, 1044D0806 x 4 screw & 4730B373 tail light gasket)	105.	4720A3171	Small Cabinet Top
13.	4720A1671	Top Channel End				106.	4720A3201	R.S. Cabinet Top
14.	4720A3291	Seal - Long				107.	4720A5091	Stove Cover Ass'y.
15.	4720A3301	Seal - Short				108.	4720A3551	Stove
16.	4720A3601	Screen Door Hinge x 3				109.	4720A3491	Sink
17.	4720A2601	Top Door Hinge x 2	52.	4720B5141	Lift Ass'y. Complete (With one cable clip)	110.	4730-3151	Basket
18.	4720A0691	Door Seal Vertical x 2	53.	4720A6661	Jack Package (With snap ring 4720A334)	111.	4730-3101	Pump
19.	4720A5751	Sliding Panel Ass'y.	54.	4730A6331	Tire & Rim	112.	4720A2561	Galley Top
20.	4730A3801	Door Seal	55.	4720A5941	Stabilizer Right Rear	113.	4720A5921	Gas Bottle Package
21.	4730A3721	Metal Door Strip	56.	4720A5931	Stabilizer Left Rear	114.	4730A3921	Hub Cap
22.	4720A3781	Screen Door Handle	57.	4720A0731	Stabilizer Front	115.	4720C2221	Pulley x 8
23.	4720A3961	Door Latch (With spring washer 1202C383)	58.	4720A5191	Wheel Well Ass'y.	116.	4720A1571	Pin Short (With cotter pin)
24.	4720A6711	Strike & Catch (4720A353 & 352)	59.	4720A3091	Floor Covering	117.	4720A1561	Pin Long (With cotter pin)
	4720A5301	Screen Door Complete (Not shown as a unit)	60.	1213-1341	Plug	118.	4730A5981	Whiffle Tree & Screw Ass'y. (4720A520 Whiffle Tree) (4720A309 Screw Eye x 4) (1201B603 Hex Lock Nut x 4)
	4720A5391	Bed Ass'y. Rear (Not shown as a unit) (With rail stop 4730A121 x 4)	61.	4720A5261	Access Door Complete	119.	4720A1221	Coupling
	4720A5401	Bed Ass'y. Front (Not shown as a unit) (With rail stop 4730A121 x 4)	62.	4720A5851	Access Door Support	120.	4720-3031	Safety Chain
25.	4720A5631	Bow Brkt. Ass'y. x 2	63.	4720B5871	Pivot Rear	121.	4730A3691	Chain (Includes 4730A381 connecting link)
26.	4720A1251	Canvas Support Bed	64.	4720B5861	Pivot Front	122.	4720A2371	Guide Channel
27.	4720A5971	Canvas Support Ass'y.	65.	4720A2021	Access Door Skin	123.	4730A4041	Bearing (Kelsey-Hayes #L44643)
28.	4720A4021	Shock Cord Spool x 4 (With screw & washer)	66.	4720A1311	Seal Strip Rear	124.	4730A3091	Screw Eye x 4
29.	4720A5601	Bed Extension Ass'y. (Rail stop 4730A121 x 4)	67.	4720A1301	Seal Strip Front	125.	4720A3341	Snap Ring x 1
30.	4730B2701	Bed Seal Angle	68.	4720A3571	Seal	126.	4720A3041	Tag Holder & Light
31.	4730A2631	Bed Seal	69.	4730A3191	Access Door Tread	127.	4730A3701	Strike x 4
32.	4720A0771	Bed Support Clip x 4	70.	4730A5201	Lock Bar Ass'y.	128.	4730B3711	Latch x 2
33.	4720A0701	Bed Support Tube x 1 (Needed hardware supplied)	71.	4730B3111	Lock Handle	129.	4730A1221	Safety Latch
34.	4720A0981	Bed Support Rail	72.	4720A2621	Screen Door Support	130.	4730A1791	End Rail Rear
35.	4720A1211	Leg Brkt.	73.	4720A1481	Roll Pin x 5			
36.	4720A3991	Front Bed Support (With hardware)	74.	1212-0121	Grommet x 2			
37.	4720A3111	Mattress	75.	4720A5311	Door Bulkhead Rear			
	4720A6911	Mattress Skin (For 4720A3111 Mattress) (Not shown separately)	76.	4720A5321	Door Bulkhead Front			
38.	4720A3241	Dinette Cush. Small	77.	4720A1331	Side Rail Right Front			
	4720A6921	Dinette Cush. Small Skin (For 4720A3241 Cushion) (Not shown separately)	78.	4875-2361	Tote Can			
39.	4720A3231	Dinette Cush. Large	79.	4730A2541	Cooler Stop x 2			
	4720A6931	Dinette Cush. Large Skin (For 4720A3231 Cushion) (Not shown separately)	80.	4720A0721	Cooler Clip x 2			
			81.	4720A6461	Side Panel Ass'y. (2 canvas clips 4730A260)			
			82.	4720A6531	Rear Ass'y. (2 canvas clips 4730A260)			
			83.	4720A6591	Front Ass'y. (2 canvas clips 4730A260)			
			84.	4730A1211	Rail Stop x 4			
			85.	4730A3431	Gas Hose Ass'y.			
			86.	5257-7081	Cooler x 1			
			87.	4730A3671	Lower Door Seal			
			88.	4730A3741	Seal Angle			
			89.	4730A3381	Roll Pin x 1			
			90.	4730A4901	Screen Door Seal			
			91.	4730A4911	Seal Retainer			
			92.	4720A2091	Panel End Long			

1968
CT-281

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4720A5241	Top Ass'y. Complete (Not shown as a unit)	42.	4720A1801	End Rail Front	96.	4720A2041	Panel C.S. Rear
1.	4720A1841	Top Panel Rear	43.	4720A1391	Right Front Body Panel	97.	4720A2051	Panel C.S. Front
2.	4720A1811	Top Panel Front	44.	4720A6261	Body Panel Front (With 4730A318 metal cal & 4730A322 x 2 tongue seals attached)	98.	4720A2031	Panel C.S. Middle
3.	4720A1821	Top End Panel	45.	4720A1371	Left Side Body Panel	99.	4720A2121	Corner Divider x 4
4.	4720A1851	Top Corner	46.	4720A1361	Side Rail Left	100.	4720A2111	Panel Divider x 4
5.	4730A3701	Strike x 4	47.	4720A1381	Right Rear Body Panel	101.	4730A4931	Panel Divider x 1
6.	4720A3271	Top Seal Long	48.	4720A1351	Side Rail Right Rear	102.	4720A5561	Dinette Table
7.	4720B5411	Lift Brk't. Ass'y.	49.	4720A1791	End Rail Rear	103.	4720A3171	Small Cabinet Top
8.	4720B1681	Top Channel Side	50.	4720A1491	Body Panel Rear	104.	4730A3921	Hub Cap
9.	4720A1831	Roof Rib	51.	4720A1451	Tail Light Cover	105.	4720C2221	Pulley x 8
10.	4720A0951	Door Support Tube x 2 (4720A331 Plate x 3)	52.	4730A1801	Coleman Name Plate (With 3 pushnuts 1201C793)	106.	4720A1571	Pin Short (With cotter pin)
11.	4720A0941	Door Support x 2 (With spring washer 1202C 1202C383)	53.	4730A5991	Tail Light Ass'y. Package (Include 4720A146 cover retainer, 4720A308 tail light trim, 4720-315 tail light, 1044D0806 x 4 screw, & 4730B373 tail light gasket)	107.	4720A1561	Pin Long (With cotter pin)
12.	4720A2611	Screen Door Brk't. x 2				108.	4730A5981	Whiffle Tree & Screw Ass'y. (4720B520 Whiffle Tree) (4720A309 Screw Eye x 4) (1201 B603 Hex Lock Nut x 4)
13.	4720A5961	Support Plate Ass'y. x 1	54.	4720B5141	Lift Ass'y. Complete (With one cable clip)	109.	4720A1221	Coupling
14.	4720A1671	Top Channel End	55.	4720A6661	Jack Package (With snap ring 4720A334)	110.	4720-3031	Safety Chain
15.	4720A3291	Seal - Long	56.	4730A6331	Tire & Rim	111.	4730A3691	Chain (Includes 4730A381 connecting link)
16.	4720A3301	Seal - Short	57.	4720A5941	Stabilizer Right Rear	112.	4720A2371	Guide Channel
17.	4720A3601	Screen Door Hinge x 3	58.	4720A5931	Stabilizer Left Rear	113.	4730A4041	Bearing (Kelsey-Hayes #L44643)
18.	4720A2601	Top Door Hinge x 2	59.	4720A0731	Stabilizer Front	114.	4730A3091	Screw Eye x 4
19.	4720A0691	Door Seal Vertical x 2	60.	4720A5191	Wheel Well Ass'y.	115.	4720A3341	Snap Ring x 1
20.	4720A5751	Sliding Panel Ass'y.	61.	4720A3091	Floor Covering	116.	4720A3041	Tag holder and light
21.	4730A3801	Door Seal	62.	1213-1341	Plug			
22.	4730A3721	Metal Door Strip	63.	4720A5261	Access Door Complete			
23.	4720A3781	Screen Door Handle	64.	4720A5851	Access Door Support			
24.	4720A3961	Door Latch (With spring washer 1202C383)	65.	4720B5871	Pivot Rear			
25.	4720A6711	Strike & Catch (4720A353 & 352)	66.	4720B5861	Pivot Front			
	4720A5301	Screen Door Complete (Not shown as a unit)	67.	4720A2021	Access Door Skin			
	4720A5391	Bed Ass'y. Rear (Not shown as a unit) (With rail stop 4730A121 x 4)	68.	4720A1311	Seal Strip Rear			
	4720A5401	Bed Ass'y. Front (Not shown as a unit) (With rail stop 4730A121 x 4)	69.	4720A1301	Seal Strip Front			
26.	4720A5631	Bow Brk't. Ass'y. x 2	70.	4720A3571	Seal			
27.	4720A1251	Canvas Support Bed	71.	4730A3191	Access Door Tread			
28.	4720A5971	Canvas Support Ass'y.	72.	4730A5201	Lock Bar Ass'y.			
29.	4720A4021	Shock Cord Spool x 4 (With screw & washer)	73.	4730B3111	Lock Handle			
30.	4720A5601	Bed Extension Ass'y. (Rail stop 4730A121 x 4)	74.	4730A1221	Safety Latch			
31.	4730B2701	Bed Seal Angle	75.	4720A2621	Screen Door Support			
32.	4730A2631	Bed Seal	76.	4720A1481	Roll Pin x 5			
33.	4720A0771	Bed Support Clip x 4	77.	1212-0121	Grommet x 2			
34.	4720A0701	Bed Support Tube x 1 (Needed hardware supplied)	78.	4720A5311	Door Bulkhead Rear			
35.	4720A0981	Bed Support Rail	79.	4720A5321	Door Bulkhead Front			
36.	4720A1211	Leg Brk't.	80.	4720A1331	Side Rail Right Front			
37.	4720A3991	Front Bed Support (With hardware)	81.	4720A6461	Side Panel Ass'y. (2 canvas clips (4730A260))			
38.	4720A3111	Mattress	82.	4720A6531	Rear Ass'y. (2 canvas clips 4730A260)			
	4720A6911	Mattress Skin (For 4720A3111 Mattress) (Not shown separately)	83.	4720A6591	Front Ass'y. (2 canvas clips 4730A260)			
39.	4720A3241	Dinette Cushion Small	84.	4730A1211	Rail Stop x 4			
	4720A6921	Dinette Cushion Small Skin (For 4720A3241 Cushion)	85.	4730B3711	Latch x 2			
40.	4720A3231	Dinette Cushion Large	86.	4730A3671	Lower Door Seal			
	4720A6931	Dinette Cushion Large Skin (For 4720A3231 Cushion)	87.	4730A3741	Seal Angle			
41.	4720A1471	Body Corner Panel	88.	4730A3381	Roll Pin x 1			
			89.	4730A4901	Screen Door Seal			
			90.	4730A4911	Seal Retainer			
			91.	4720A2091	Panel End Long			
			92.	4720A2101	Panel End Short			
			93.	4720A2061	Panel R.S. Rear			
			94.	4720A2071	Panel R.S. Front			
			95.	4720A2081	Panel R.S. Middle			

1968
CT-282

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4720A5241	Top Ass'y. Complete (Not shown as a unit)	43.	4720A1371	Left Side Body Panel	98.	4720A2121	Corner Divider x 4
1.	4720A1841	Top Panel Rear	44.	4720A1361	Side Rail Left	99.	4720A2111	Panel Divider x 4
2.	4720A1811	Top Panel Front	45.	4720A1381	Right Rear Body Panel	100.	4730A4931	Panel Divider x 1
3.	4720A1821	Top End Panel	46.	4720A1351	Side Rail Right Rear	101.	4730A3281	Wheel Well Seal x 2
4.	4720A1851	Top Corner	47.	4720A1791	End Rail Rear	102.	4730A3291	Wheel Well Seal x 2
5.	4730A3701	Strike x 4	48.	4720A1491	Body Panel Rear	103.	4730A3921	Hub Cap
6.	4720A3271	Top Seal Long	49.	4720A1451	Tail Light Cover	104.	4720C2221	Pulley x 8
7.	4720B5411	Lift Brk't. Ass'y.	50.	4730A1801	Coleman Name Plate (With 3 pushnuts 1201C793)	105.	3720A1571	Pin Short (With cotter pin)
8.	4720B1681	Top Channel Side				106.	4720A1561	Pin Long (With cotter pin)
9.	4720A1831	Roof Rib	51.	4730A5991	Tail Light Ass'y. Package (includes 4720A146 cover retainer, 4720A308 tail light trim, 4720-315 tail light, 1044D0806 x 4 screw, & 4730B373 tail light gasket)	107.	4730A5981	Whiffle Tree & Screw Ass'y. (4720B520 Whiffle Tree) (4720A309 Screw Eye x 4) (1201B603 Hex Lock Nut x 4)
10.	4720A1831	Door Support Tube x 3 (4720A331 Plate x 3)				108.	4720A1221	Coupling
11.	4720A0941	Door Support x 2 (With spring washer 1202C383)	52.	4720B5141	Lift Ass'y. Complete (With one cable clip)	109.	4720-3031	Safety Chain
12.	4720A2611	Screen Door Brk't. x 2	53.	4720A6661	Jack Package (With snap ring 4720A334)	110.	4730A3691	Chain (Included 4730A381 connecting link)
13.	4720A5961	Support Plate Ass'y. x 1	54.	4730A6331	Tire & Rim	111.	4720A2371	Guide Channel
14.	4720A1671	Top Channel End	55.	4720A5941	Stabilizer Right Rear	112.	4730A4041	Bearing (Kelsey-Hayes #L44643)
15.	4720A3291	Seal - Long	56.	4720A5931	Stabilizer Left Rear	113.	4730A3091	Screw Eye x 4
16.	4720A3301	Seal - Short	57.	4720A0731	Stabilizer Front	114.	4720A3341	Snap ring x 1
17.	4720A3601	Screen Door Hinge x 3	58.	4720A5191	Wheel Well Ass'y.			
18.	4720A2601	Top Door Hinge x 2	59.	4720A3091	Floor Covering			
19.	4720A0691	Door Seal Vertical x 2	60.	1213-1341	Plug			
20.	4720A5751	Sliding Panel Ass'y.	61.	4720A5261	Access Door Complete			
21.	4730A3801	Door Seal	62.	4720A5851	Access Door Support			
22.	4730A3721	Metal Door Strip	63.	4720B5871	Pivot Rear			
23.	4720A3781	Screen Door Handle	64.	4720B5861	Pivot Front			
24.	4720A3961	Door Latch (With Spring Washer 1202C383)	65.	4720A2021	Access Door Skin			
25.	4720A6711	Strike & Catch (4720A353 & 352)	66.	4720A1311	Seal Strip Rear			
	4720A5301	Screen Door Complete (Not shown as a unit)	67.	4720A1301	Seal Strip Front			
	4720A5391	Bed Ass'y. Rear (Not shown as a unit) (With rail stop 4730A121 x 4)	68.	4720A3571	Seal			
	4720A5401	Bed Ass'y. Front (Not shown as a unit) (With rail stop 4730A121 x 4)	69.	4730A3191	Access Door Tread			
26.	4720A5631	Bow Brk't. Ass'y. x 2	70.	4730A5201	Lock Bar Ass'y.			
27.	4720A1251	Canvas Support Bed	71.	4730B3111	Lock Handle			
28.	4720A5971	Canvas Support Ass'y.	72.	4730A1221	Safety Latch			
29.	4720A4021	Shock Cord Spool x 4 (With screw & washer)	73.	4720A2621	Screen Door Support			
30.	4720A5601	Bed Exetnsion Ass'y. (Rail stop 4730A121 x 4)	74.	4720A1481	Roll Pin x 5			
31.	4730B2701	Bed Seal Angle	75.	1212-0121	Grommet x 2			
32.	4730A2631	Bed Seal	76.	4720A5311	Door Bulkhead Rear			
33.	4720A0771	Bed Support Clip x 4	77.	4720A5321	Door Bulkhead Front			
34.	4720A0701	Bed Support Tube x 1 (Needed hardward supplied)	78.	4720A1331	Side Rail Right Front			
35.	4720A0981	Bed Support Rail	79.	4720A6461	Side Panel Ass'y. (2 canvas clips 4730A260)			
36.	4720A1211	Leg Brk't.	80.	4720A6531	Rear Ass'y. (2 canvas clips 5730A260)			
37.	4720A3991	Front Bed Support (With hardware)	81.	4720A6591	Front Ass'y. (2 canvas clips 4730A260)			
38.	4720A3111	Mattress	82.	4730A1211	Rail Stop x 4			
	4720A6911	Mattress Skin (For 4720A3111 Mattress) (Not shown separately)	83.	4720A3041	Tag Holder & Light			
39.	4720A1471	Body Corner Panel	84.	4730B3711	Latch x 2			
40.	4720A1801	End Rail Front	85.	4730A3671	Lower Door Seal			
41.	4720A1391	Right Front Body Panel	86.	4730A3741	Seal Angle			
42.	4720A6261	Body Panel Front (With 4720A318 metal cal & 4730A322 x 2 tongue seals attached)	87.	4730A3381	Roll Pin x 1			
			88.	4730A4901	Screen Door Seal			
			89.	4730A4911	Seal Retainer			
			90.	4720A2091	Panel End Long			
			91.	4720A2101	Panel End Short			
			92.	4720A2061	Panel R.S. Rear			
			93.	4720A2071	Panel R.S. Front			
			94.	4720A2081	Panel R.S. Middle			
			95.	4720A2041	Panel C.S. Rear			
			96.	4720A2051	Panel C.S. Front			
			97.	4720A2031	Panel C.S. Middle			

1968
CT-280S

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4720A5241	Top Ass'y. Complete (Not shown as a unit)	43.	4720A1391	Right Front Body Panel	93.	4730A3381	Roll Pin x 1
1.	4720A1841	Top Panel Rear	44.	4720A6261	Body Panel Front (With 4730A318 metal cal & 4730A322 x 2 tongue seals attached)	94.	4730A4901	Screen Door Seal
2.	4720A1811	Top Panel Front				95.	4730A4911	Seal Retainer
3.	4720A1821	Top End Panel	45.	4720A1371	Left Side Body Panel	96.	4720A2091	Panel End Long
4.	4720A1851	Top Corner	46.	4720A1361	Side Rail Left	97.	4720A2101	Panel End Short
5.	4730A3701	Strike x 4	47.	4720A1381	Right Rear Body Panel	98.	4720A2061	Panel R.S. Rear
6.	4720A3271	Top Seal Long	48.	4720A1351	Side Rail Right Rear	99.	4720A2071	Panel R.S. Front
7.	4720B5411	Lift Brk't. Ass'y.	49.	4720A1781	End Rail Rear	100.	4720A2081	Panel R.S. Middle
8.	4720B1681	Top Channel Side	50.	4720A1491	Body Panel Rear	101.	4720A2041	Panel C.S. Rear
9.	4720A1831	Top Rib	51.	4720A1451	Tail Light Cover	102.	4720A2051	Panel C.S. Front
10.	4720A0951	Door Support Tube x 2 (4720A331 Plate x 3)	52.	4730A1801	Coleman Name Plate (With 3 pushnuts 1201C793)	103.	4720A2031	Panel C.S. Middle
11.	4720A0941	Door Support x 2 (With spring washer 1202C383)	53.	4730A5991	Tail Light Ass'y. Package (Includes 4720A146 cover retainer, 4720A308 tail light trim, 4720-315 tail light, 1044D0806 x 4 screw, & 5730B373 tail light gasket)	104.	4720A2121	Corner Divider x 4
12.	4720A2611	Screen Door Brk't. x 2				105.	4720A2111	Panel Divider x 4
13.	4720A5961	Support Plate Ass'y. x 1				106.	4730A4931	Panel Divider x 1
14.	4720A1671	Top Channel End				107.	4720A5561	Dinette Table
15.	4720A3291	Seal - Long				108.	4720A3161	Toilet Box Top
16.	4720A3301	Seal - Short				109.	4720A3171	Small Cabinet Top
17.	4720A3601	Screen Door Hinge x 3				110.	4720A3201	R.S. Cabinet Top
18.	4720A2601	Top Door Hinge x 2	54.	4720B5141	Lift Ass'y. Complete (With one cable clip)	111.	4720A5091	Stove Cover Ass'y.
19.	4720A0691	Door Seal Vertical x 2	55.	4720A6661	Jack Package (With snap ring 4720A334)	112.	4720A3551	Stove
20.	4720A5751	Sliding Panel Ass'y.				113.	4730A2461	Sink
21.	4730A3801	Door Seal	56.	4730A6331	Tire & Rim	114.	4730A3141	Pump
22.	4720A3721	Metal Door Strip	57.	4720A5941	Stabilizer Right Rear	115.	4730A2551	Galley Top
23.	4720A3781	Screen Door Handle	58.	4720A5931	Stabilizer Left Rear	116.	4730A5941	Gas Bottle Package
24.	4720A3961	Door Latch (With spring washer 1202C383)	59.	4720A0731	Stabilizer Front	117.	4730A3921	Hub Cap
25.	4720A6711	Strike & Catch (4720A353 & 352)	60.	4720A5191	Wheel Well Ass'y.	118.	4720C2221	Pulley x 8
	4720A5301	Screen Door Complete (Not shown as a unit)	61.	4720A3091	Floor Covering	119.	4720A1571	Pin Short (With cotter pin)
	4720A5391	Bed Ass'y. Rear (Not shown as a unit) (With rail stop 4730A121 x 4)	62.	1213-1341	Plug	120.	4720A1561	Pin Long (With cotter pin)
	4720A5401	Bed Ass'y. Front (Not shown as a unit) (With rail stop 4730A121 x 4)	63.	4720A5261	Access Door Complete	121.	4730A5981	Whiffle Tree & Screw Ass'y. (4720B520 Whiffle Tree) (4720A309 Screw Eye x 4) (1201B603 Hex Lock Nut) x 4)
26.	4720A5631	Bow Brk't. Ass'y. x 2	64.	4720A5851	Access Door Support	122.	4720A1221	Coupling
27.	4720A1251	Canvas Support Bed	65.	4720B5871	Pivot Rear	123.	4720-3031	Safety Chain
28.	4720A5971	Canvas Support Ass'y.	66.	4720B5861	Pivot Front	124.	4730A3691	Chain (Includes 4730A381 connecting link)
29.	4720A4021	Shock Cord Spool x 4 (With screw & washer)	67.	4720A2021	Access Door Skin	125.	4720A2371	Guide Channel
30.	4720A5601	Bed Extension Ass'y. (Rail stop 4730A121 x 4)	68.	4720A1311	Seal Strip Rear	126.	4730A4041	Bearing (Kelsey-Hayes #L44643)
31.	4730B2701	Bed Seal Angle	69.	4720A1301	Seal Strip Front	127.	4720A3091	Screw Eye x 4
32.	4730A2631	Bed Seal	70.	4720A3571	Seal	128.	4720A3341	Snap Ring x 1
33.	4720A0771	Bed Support Clip x 4	71.	4730A3191	Access Door Tread	129.	4730A2471	Fill Spout (With 1103B0608 screws x 3)
34.	4720A0701	Bed Support Tube x 1 (Needed hardware supplied)	72.	4730A5201	Lock Bar Ass'y.	130.	4730A4341	Gas Hose Ass'y.
35.	4720A0981	Bed Support Rail	73.	4730B3111	Lock Handle			
36.	4720A1211	Leg Brk't.	74.	4730A1221	Safety Latch			
37.	4720A3991	Front Bed Support (With hardware)	75.	4720A2621	Screen Door Support			
38.	4720A3111	Mattress	76.	4720A1481	Roll Pin x 5			
	4720A6911	Mattress Skin (For 4720A3111 Mattress) (Not shown separately)	77.	1212-0121	Grommet			
39.	4720A3241	Dinette Cushion Small	78.	4720A5311	Door Bulkhead Rear			
	4720A6921	Dinette Cushion Small Skin (For 4720A3241 Cushion)	79.	4720A5321	Door Bulkhead Front			
40.	4720A3231	Dinette Cushion Large	80.	4720A1331	Side Rail Right Front			
	4720A6931	Dinette Cushion Large Skin (For 4720A3231 Cushion)	81.	4730A2451	Water Tank (With 1210-028 elbow, 4730A244 elbow, 1211-178 nipple, & 1210-267 pipe cup)			
41.	4720A1471	Body Corner Panel	82.	4730A2541	Cooler Stop x 2			
42.	4720A1801	End Rail Front	83.	4720A0721	Cooler Clip x 2			
			84.	4720A6561	Side Panel Ass'y. (2 canvas clips 4730A260)			
			85.	4720A6531	Rear Ass'y. (2 canvas clips 4730A260)			
			86.	4720A6591	Front Ass'y. (2 canvas clips 4730A260)			
			87.	4730A1211	Rail Stop x 4			
			88.	4720A3041	Tag Holder & Light			
			89.	4730B3711	Latch x 2			
			90.	5257-7081	Cooler x 1			
			91.	4730A3671	Lower Door Seal			
			92.	4730A3741	Seal Angle			

1968
CT-290

PARTS LIST

Coleman
CAMPING TRAILERS




- | | | | | | |
|---------------|---|---------------|--|----------------|--|
| 14730A5241 | Top Ass'y. Complete
(Not shown as a unit) | 41. 4730A3371 | Dinette Cushion Small | 89. 4730A6531 | Rear Ass'y.
(2 canvas clips 4730A260) |
| 1. 4730A1841 | Top Panel Center | 4730A6921 | Dinette Small Skin
(Not shown separately) | 90. 4730A6591 | Front Ass'y.
(2 canvas clips 4730A260) |
| 2. 4730A1811 | Top Panel Front or Rear | 42. 4730A3361 | Dinette Cushion Large | 91. 4730A1211 | Rail Stop x 4 |
| 3. 4720A1821 | Top End Panel | 4730A6931 | Dinette Large Skin
(Not shown separately) | 92. 4730A3431 | Gas Hose Ass'y. |
| 4. 4720A1851 | Top Corner | 43. 4720A1471 | Body Corner Panel | 93. 4730B3711 | Latch x 2 |
| 5. 4730A3701 | Strike | 44. 4720A1801 | End Rail Front | 94. 5257-7091 | Cooler |
| 6. 4730A3271 | Top Seal Long | 45. 4730A1391 | Right Front Body Panel | 95. 4730A3671 | Lower Door Seal |
| 7. 4720B5411 | Lift Brk't Ass'y. | 46. 4720A1401 | Body Panel Front
(With 4730A318 metal cal
& 4730A322 x 2 tongue
seals attached) | 96. 4730A3741 | Seal Angle |
| 8. 4730B1681 | Top Channel Side | 47. 4730A1371 | Left Side Body Panel | 97. 4730A3381 | Roll Pin |
| 9. 4720A1831 | Roof Rib | 48. 4730A1361 | Side Rail Left | 98. 4730A4901 | Screen Door Seal |
| 10. 4730A0951 | Door Support Tube x 2 | 49. 4730A1381 | Right Rear Body Panel | 99. 4730A4911 | Seal Retainer |
| 11. 4720A0941 | Door Support x 2
(With Spring Washer
1202C383) | 50. 4730A1351 | Side Rail Right Rear | 100. 4720A2091 | Panel End Long |
| 12. 4720A2611 | Screen Door Brk't x 2 | 51. 4720A1791 | End Rail Rear | 101. 4720A2101 | Panel End Short |
| 13. 4720A5961 | Support Plate Ass'y. x 2 | 52. 4720A1491 | Body Panel Rear | 102. 4730A2381 | Panel R.S. Rear |
| 14. 4720A1671 | Top Channel End | 53. 4720A1451 | Tail Light Cover | 103. 4730A2071 | Panel R.S. Front |
| 15. 4720A3291 | Seal - Long | 54. 4730A1801 | Coleman Name Plate
(With 3 pushnut's
1201C793) | 104. 4730A2081 | Panel R.S. Middle |
| 16. 4720A3301 | Seal - Short | 55. 4730A5991 | Tail Light Ass'y. Package
(Includes 4720A146 cover
retainer, 4720A308 tail
light trim, 4720-315 tail
light, 1044D0806 x 4 screw,
& 4730B373 tail light
gasket) | 105. 4730A2371 | Panel C.S. Rear |
| 17. 4720A3601 | Screen Door Hinge x 3 | 56. 4730B5141 | Lift Ass'y. Complete Front
(With one cable clip) | 106. 4730A2051 | Panel C.S. Front |
| 18. 4720A2601 | Top Door Hinge x 2 | 57. 4730B5151 | Lift Ass'y. Complete Rear
(With one cable clip) | 107. 4730A2031 | Panel C.S. Middle |
| 19. 4720A0691 | Door Seal Vertical x 2 | 58. 4720A6661 | Jack Package
(With snap ring 4720A334) | 108. 4720A2111 | Panel Divider x 4 |
| 20. 4720A5751 | Sliding Panel Ass'y. | 59. 4730A4041 | Bearing
(Kelsey-Hayes #L44643) | 109. 4720A2121 | Panel Corner Divider x 4 |
| 21. 4730A3801 | Door Seal | 60. 4730A6321 | Tire & Rim | 110. 4730A4931 | Panel Divider x 1 |
| 22. 4730A3721 | Metal Door Strip | 61. 4720A5941 | Stabilizer Right Rear | 111. 4730A5561 | Dinette Table |
| 23. 4720A3781 | Screen Door Handle | 62. 4720A5931 | Stabilizer Left Rear | 112. 4730A3171 | R.S. Cabinet Top |
| 24. 4720A3961 | Door Latch
(With Spring Washer
1202C383) | 63. 4720A0731 | Stabilizer Front | 113. 4730A3201 | C.S. Cabinet Top - Small |
| 25. 4720A6711 | Strike & Catch
(4720A353 & 352) | 64. 4720A5191 | Wheel Well Ass'y. | 114. 4730A4621 | C.S. Cabinet Top - Large |
| 4720A5301 | Screen Door Complete
(Not shown as a unit) | 65. 4730A3091 | Floor Covering | 115. 4730A3101 | Pump |
| 4720A5391 | Bed Ass'y. Rear
(Not shown as a unit)
(With rail stop 4730A121
x 4) | 66. 1213-1341 | Plug | 116. 4730A5091 | Stove Cover |
| 4720A5401 | Bed Ass'y. Front
(Not shown as a unit)
(With rail stop 4730A121
x 4) | 67. 4720A5261 | Access Door Complete | 117. 4730A3351 | Stove |
| 26. 4720A5631 | Bow Brk't Ass'y. x 2 | 68. 4720A5851 | Access Door Support | 118. 4730A3481 | Sink |
| 27. 4720A1251 | Canvas Support Bed | 69. 4720B5871 | Pivot Rear | 119. 4730A2561 | Galley Top |
| 28. 4720A5971 | Canvas Support Ass'y. | 70. 4720B5861 | Pivot Front | 120. 4730-3151 | Basket |
| 29. 4720A4021 | Shock Cord Spool x 4
(With screw & washer) | 71. 4720A2021 | Access Door Skin | 121. 4720A5921 | Gas Bottle Package |
| 30. 4720A5601 | Bed Extension Ass'y.
(With rail stop 4730A121
x 4) | 72. 4720A1311 | Seal Strip Rear | 122. 4730A3881 | Hub Cap & Spinner |
| 31. 4730B2701 | Bed Seal Angle | 73. 4720A1301 | Seal Strip Front | 123. 4720C2221 | Pulley x 8 |
| 32. 4730A2631 | Bed Seal | 74. 4720A3571 | Seal | 124. 4720A1571 | Pin Short & Cotter Pin |
| 33. 4720A0771 | Bed Support Clip x 4 | 75. 4730A3191 | Access Door Tread | 125. 4720A1561 | Pin Long & Cotter Pin |
| 34. 4720A0701 | Bed Support Tube x 1
(Needed hardware supplied) | 76. 4730A5201 | Lock Bar Ass'y. | 126. 4730A5981 | Whiffle Tree & Screw Ass'y.
(4720A520 Whiffle Tree)
(4720A309 Screw Eye x 4)
(1201B603 Hex Lock Nut
x 4) |
| 35. 4720A0981 | Bed Support Rail | 77. 4730B3111 | Lock Handle | 127. 4720A1221 | Coupling |
| 36. 4720A1211 | Leg Brk't | 78. 4730A1221 | Safety Latch | 128. 4720-3031 | Safety Chain |
| 37. 4720A3991 | Front Bed Support
(With hardware) | 79. 4720A2621 | Screen Door Support | 129. 4730A3691 | Chain
(Included 4730A381
connecting link) |
| 38. 4730A3351 | Mattress | 80. 4720A1481 | Roll Pin x 5 | 130. 4720A2371 | Guide Channel |
| 4730A6911 | 4730A335 Mattress Skin
(Not shown separately) | 81. 1212-0121 | Grommet x 2 | 131. 4720A3341 | Snap Ring x 1 |
| 39. 4730A3901 | Gaucha Cushion Small
(Hinged) | 82. 4720A5311 | Door Bulkhead Rear | 132. 4730A3091 | Screw Eye x 4 |
| 4730A6941 | Hinged Gaucha Skin
(Not shown separately) | 83. 4720A5321 | Door Bulkhead Front | 4730A3951 | Electric Brake Package
(Not shown as a unit)
(Includes R.H., L.H. and
hardware) |
| 40. 4730A3891 | Gaucha Cushion Large | 84. 4730A1331 | Side Rail Right Front | 133. 4720A6701 | Electric Brake Shoes |
| 4730A6951 | Gaucha Large Skin
(Not shown separately) | 85. 4875-2361 | Tote Can | 134. 4720A3041 | Tag Holder |
| | | 86. 4730A2541 | Cooler Stop x 2 | 135. 4720A6671 | R.H. Brake Magnet |
| | | 87. 4720A0721 | Cooler Clip x 2 | 4720A6721 | L.H. Brake Magnet
(Not shown separately) |
| | | 88. 4730A6461 | Side Panel Ass'y.
(2 canvas clips 4730A260) | | |

1968
CT-291

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4730A5241	Top Ass'y. Complete (Not shown as a unit)	42.	4720A1801	End Rail Front	93.	4720A2091	Panel End Long
1.	4730A1841	Top Panel Center	43.	4730A1391	Right Front Body Panel	94.	4720A2101	Panel End Short
2.	4730A1811	Top Panel Front or Rear	44.	4720A1401	Body Panel Front (With 4730A318 metal cal & 4730A322 x 2 tongue seals attached)	95.	4730A2381	Panel R.S. Rear
3.	4720A1821	Top End Panel	45.	4730A1371	Left Side Body Panel	96.	4730A2071	Panel R.S. Front
4.	4720A1851	Top Corner	46.	4730A1361	Side Rail Left	97.	4730A2081	Panel R.S. Middle
5.	4730A3701	Strike	47.	4730A1381	Right Rear Body Panel	98.	4730A2371	Panel C.S. Rear
6.	4730A3271	Top Seal Long	48.	4739A1351	Side Rail Right Rear	99.	4730A2051	Panel C.S. Front
7.	4720B5411	Lift Brk't Ass'y.	49.	4720A1791	End Rail Rear	100.	4730A2031	Panel C.S. Middle
8.	4730B1681	Top Channel Side	50.	4720A1591	Body Panel Rear	101.	4720A2111	Panel Divider x 4
9.	4720A1831	Roof Rib	51.	4720A1451	Tail Light Cover	102.	4720A2121	Panel Corner Divider x 4
10.	4730A0951	Door Support Tube x 2	52.	4730A1801	Coleman Name Plate (With 3 pushnut's 1201C793)	103.	4730A4931	Panel Divider x 1
11.	4720A0941	Door Support x 2 (With Spring Washer 1202C383)	53.	4730A5991	Tail light Ass'y. Package (Includes 4720A146 cover retainer, 4720A308 tail light trim, 4720-315 tail light, 1044D0806 x 4 screw, & 4730B373 tail light gasket)	104.	4730A5561	Dinette Table
12.	4720A2611	Screen Door Brk't x 2	54.	4730B5141	Lift Ass'y. Complete Front (With one cable clip)	105.	4730A3171	R.S. Cabinet Top
13.	4720A5961	Support Plate Ass'y. x 2	55.	4730B5151	Lift Ass'y. Complete Rear (With one cable clip)	106.	4730A3881	Hub Cap & Spinner
14.	4720A1671	Top Channel End	56.	4720A6661	Jack Package (With snap ring 4720A334)	107.	4720C2221	Pulley x 8
15.	4720A3291	Seal - Long	57.	4730A4041	Bearing (Kelsey-Hayes #L44643)	108.	4720A1571	Pin Short & Cotter Pin
16.	4720A3301	Seal - Short	58.	4730A6321	Tire & Rim	109.	4720A1561	Pin Long & Cotter Pin
17.	4720A3601	Screen Door Hinge x 3	59.	4720A5941	Stabilizer Right Rear	110.	4730A5981	Whiffle Tree & Screw Ass'y. (4720A520 Whiffle Tree) (4720A309 Screw Eye x 4) (1201B603 Hex Lock Nut x 4)
18.	4720A2601	Top Door Hinge x 2	60.	4720A5931	Stabilizer Left Rear	111.	4720A1221	Coupling
19.	4720A0691	Door Seal Vertical x 2	61.	4720A0731	Stabilizer Front	112.	4720-3031	Safety Chain
20.	4720A5751	Sliding Panel Ass'y.	62.	4720A5191	Wheel Well Ass'y.	113.	4730A3691	Chian (Included 4730A381 Connecting Link)
21.	4730A3801	Door Seal	63.	4730A3091	Floor Covering	114.	4720A2371	Guide Channel
22.	4730A3721	Metal Door Strip	64.	1213-1341	Plug	115.	4730A3131	Cabinet Top
23.	4720A3781	Screen Door Handle	65.	4720A5261	Access Door Complete	116.	4720A3341	Snap Ring x 1
24.	4720A3961	Door Latch (With Spring Washer 1202C383)	66.	4720A5851	Access Door Support	117.	4730A3091	Screw Eye x 4
25.	4720A6711	Strike & Catch (4720A353 & 352)	67.	4720B5871	Pivot Rear	4730A3951	Electric Brake Package (Not shown as a unit) (Include: R.H., L.H., and hardware)	
	4720A5301	Screen Door Complete (Not shown as a unit)	68.	4720B5861	Pivot Front	118.	4720A6701	Electric Brake Shoes
	4720A5391	Bed Ass'y. Rear (Not shown as a unit) (With rail stop 4730A121 x 4)	69.	4720A2021	Access Door Skin	119.	4720A3041	Tag Holder
	4720A5401	Bed Ass'y. Front (Not shown as a unit) (With rail stop 4730A121 x 4)	70.	4720A1311	Seal Strip Rear	120.	4720A6671	R.H. Brake Magnet
26.	4720A5631	Bow Brk't Ass'y. x 2	71.	4720A1301	Seal Strip Front	4720A6721	L.H. Brake Magnet (Not shown separately)	
27.	4720A1251	Canvas Support Bed	72.	4720A3571	Seal			
28.	4720A5971	Canvas Support Ass'y.	73.	4730A3191	Access Door Tread			
29.	4720A4021	Shock Cord Spool x 4 (With screw & washer)	74.	4730A5201	Lock Bar Ass'y.			
30.	4720A5601	Bed Extension Ass'y. (With rail stop 4730A121 x 4)	75.	4730B3111	Lock Handle			
31.	4730B2701	Bed Seal Angle	76.	4730A1221	Safety Latch			
32.	4730A2631	Bed Seal	77.	4720A2621	Screen Door Support			
33.	4720A0771	Bed Support Clip x 4	78.	4720A1481	Roll Pin x 5			
34.	4720A0701	Bed Support Tube x 1 (Needed hardware supplied)	79.	1212-0121	Grommet x 2			
35.	4720A0981	Bed Support Rail	80.	4720A5211	Door Bulkhead Rear			
36.	4720A1211	Leg Brk't	81.	4720A5321	Door Bulkhead Front			
37.	4720A3991	Front Bed Support (With hardware)	82.	4730A1331	Side Rail Right Front			
38.	4730A3351	Mattress	83.	4730A6461	Side Panel Ass'y. (2 canvas clips 4730A260)			
	4730A6911	4730A335 Mattress Skin (Not shown separately)	84.	4730A6531	Rear Ass'y. (2 canvas clips 4730A260)			
39.	4730A3371	Dinette Cushion Small	85.	4730A6591	Front Ass'y. (2 canvas clips 4730A260)			
	4730A6921	Dinette Small Skin (Not shown separately)	86.	4730A1211	Rail Stop x 4			
40.	4730A3361	Dinette Cushion Large	87.	4730B3711	Latch x 2			
	4730A6931	Dinette Large Skin (Not shown separately)	88.	4730A3671	Lower Door Seal			
41.	4720A1471	Body Corner Panel	89.	4730A3741	Seal Angle			
			90.	4730A3381	Roll Pin			
			91.	4730A4901	Screen Door Seal			
			92.	4730A4911	Seal Retainer			

1968
CT-290S

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4730A5241	Top Ass'y. Complete (Not shown as a unit)	40.	4730A3891	GaUCHO Cushion Large	86.	4730A2541	Cooler Stop x 2
	4730A5241	Top Ass'y. Complete (Not shown as a unit)		4730A6951	GaUCHO Large Skin (Not shown separately)	87.	4720A0721	Cooler Clip x 2
1.	4730A1841	Top Panel Center	41.	4730A3371	Dinette Cushion Small	88.	4730A6461	Side Panel Ass'y. (2 canvas clips 4730A260)
2.	4730A1811	Top Panel Front or Rear		4730A6921	Dinette Small Skin (Not shown separately)	89.	4730A6561	Rear Ass'y. (2 canvas clips 4730A260)
3.	4720A1821	Top End Panel	42.	4730A3361	Dinette Cushion Large	90.	4730A6591	Front Ass'y. (2 canvas clips 4730A260)
4.	4720A1851	Top Corner		4730A6931	Dinette Large Skin (Not shown separately)	91.	4730A1211	Rail Stop x 4
5.	4730A3701	Strike	43.	4720A1471	Body Corner Panel	92.	4730A4341	Gas Hose Ass'y.
6.	4730A3271	Top Seal Long	44.	4720A1801	End Rail Front	93.	4730B3711	Latch x 3
7.	4720B5411	Lift Brk't Ass'y.	45.	4730A1391	Right Front Body Panel	94.	5257-7091	Cooler
8.	4730B1681	Top Channel Side	46.	4720A1401	Body Panel Front (With 4730A318 metal cal & 4730A322 x 2 tongue seals attached)	95.	4730A3671	Lower Door Seal
9.	4720A1831	Roof Rib	47.	4730A1371	Left Side Body Panel	96.	4730A3741	Seal Angle
10.	4730A0951	Door Support Tube x 2	48.	4730A1361	Side Rail Left	97.	4730A3381	Roll Pin
11.	4720A0941	Door Support x 2 (With Spring Washer 1202C383)	49.	4730A1381	Right Rear Body Panel	98.	4730A4901	Screen Door Seal
12.	4720A2611	Screen Door Brk't x 2	50.	4730A1351	Side Rail Right Rear	99.	4730A4911	Seal Retainer
13.	4720A5961	Support Plate Ass'y. x 2	51.	4720A1791	End Rail Rear	100.	4720A2901	Panel End Long
14.	4720A1671	Top Channel End	52.	4720A1491	Body Panel Rear	101.	4720A2101	Panel End Short
15.	4720A3291	Seal - Long	53.	4720A1451	Tail Light Cover	102.	4730A2381	Panel R.S. Rear
16.	4720A3301	Seal - Short	54.	4730A1801	Coleman Name Plate (With 3 pushnut's 1201C793)	103.	4730A2071	Panel R.S. Front
17.	4720A3601	Screen Door Hinge x 3	55.	4730A5991	Tail Light Ass'y. Package (Includes 4720A146 cover retainer, 4720A308 tail light trim, 4720-315 tail light, 1044D0806 x 4 screw, & 4730B373 tail light gasket)	104.	4730A2081	Panel R.S. Middle
18.	4720A2601	Top Door Hinge x 2				105.	4730A2371	Panel C.S. Rear
19.	4720A0691	Door Seal Vertical x 2				106.	4730A2051	Panel C.S. Front
20.	4720A5751	Sliding Panel Ass'y.				107.	4730A2031	Panel C.S. Middle
21.	4730A3801	Door Seal				108.	4720A2111	Panel Divider x 4
22.	4730A3721	Metal Door Strip				109.	4720A2121	Panel Corner Divider x 4
23.	4720A3781	Screen Door Handle				110.	4730A4931	Panel Divider x 1
24.	4720A3961	Door Latch (With Spring Washer 1202C383)	56.	4730B5141	Lift Ass'y. complete Front (With one cable clip)	111.	4730A5561	Dinette Table
25.	4720A6711	Strike & Catch (4720A353 & 352)	57.	4730B5151	Lift Ass'y. Complete Rear (With one cable clip)	112.	4730A3171	R.S. Cabinet Top
	4720A5301	Screen Door Complete (Not shown as a unit)	58.	4720A6661	Jack Package (With snap ring 4720A334)	113.	4730A3201	C.S. Cabinet Top - Small
	4720A5391	Bed Ass'y. Rear (Not shown as a unit) (With rail stop 4730A121 x 4)	59.	4730A4041	Bearing (Kelsey-Hayes #L44643)	114.	4730A4621	C.S. Cabinet Top - Large
	4720A5401	Bed Ass'y. Front (Not shown as a unit) (With rail stop 4730A121 x 4)	60.	4730A6321	Tire & Rim	115.	4730A3141	Pump
26.	4720A5631	Bow Brk't Ass'y. x 2	61.	4720A5961	Stabilizer Right Rear	116.	4730A5091	Stove Cover
27.	4720A1251	Canvas Support Bed	62.	4720A5931	Stabilizer Left Rear	117.	4730A3351	Stove
28.	4720A5971	Canvas Support Ass'y.	63.	4720A0731	Stabilizer Front	118.	4730A2361	Sink
29.	4720A4021	Shock Cord Spool x 4 (With screw & washer)	64.	4720A5191	Wheel Well Ass'y.	119.	4730A2571	Galley Top
30.	4720A5601	Bed Extension Ass'y. (With rail stop 4730A121 x 4)	65.	4730A3091	Floor Covering	120.	4730A5941	Gas Bottle Package
31.	4730B2701	Bed Seal Angle	66.	1213-1341	Plug	121.	4730A3881	Hub Cap & Spinner
32.	4730A2631	Bed Seal	67.	4720A5261	Access Door Complete	122.	4720C2221	Pulley x 8
33.	4720A0771	Bed Support Clip x 4	68.	4720A5861	Access Door Support	123.	4720A1571	Pin Short & Cotter Pin
34.	4720A0701	Bed Support Tube x 1 (Needed hardware supplied)	69.	4720B5871	Pivot Rear	124.	4720A1561	Pin Long & Cotter Pin
35.	4720A0981	Bed Support Rail	70.	4720B5861	Pivot Front	125.	4730A5981	Whiffle Tree & Screw Ass'y. (4720A520 Whiffle Tree) (4720A309 Screw Eye x 4) (1201B603 Hex Lock Nut x 4)
36.	4720A1211	Leg Brk't	71.	4720A2021	Access Door Skin	126.	4720A1221	Coupling
37.	4720A3991	Front Bed Support (With hardware)	72.	4720A1311	Seal Strip Rear	127.	4720-3031	Safety Chain
38.	4730A3351	Mattress	73.	4720A1301	Seal Strip Front	128.	4730A3691	Chain (Included 4730A381 connecting link)
	4720A6911	4730A335 Mattress Skin (Not shown separately)	74.	4720A3571	Seal	129.	4720A2371	Guide Channel
39.	4730A3901	GaUCHO Cushion Small (Hinged)	75.	4730A3191	Access Door Tread	130.	4720A3341	Snap Ring x 1
	4730A6941	Hinged GaUCHO Skin (Not shown separately)	76.	4730A5201	Lock Bar Ass'y.	131.	4730A3091	Screw Eye x 4
			77.	4730B3111	Lock Handle		4730A3951	Electric Brake Package (Not shown as a unit) (Includes R.H., L.H., and hardware)
			78.	4730A1221	Safety Latch	132.	4730A6701	Electric Brake Shoes
			79.	4720A2621	Screen Door Support	133.	4720A3041	Tag Holder & Light
			80.	4720A1481	Roll Pin x 5	134.	4730A2471	Fill Spout (with screws)
			81.	1212-0121	Grommet x 2	135.	4720A6711	R.H. Brake Magnet
			82.	4720A5311	Door Bulkhead Rear		4720A6721	L.H. Brake Magnet (Not shown separately)
			83.	4720A5321	Door Bulkhead Front			
			84.	4730A1331	Side Rail Right Front			
			85.	4730A2451	Water Tank (With 1210-028 Elbow, 4730A244 Elbow, 1211-178 nipple, and 1210-267 pipe cap)			




MISC. PARTS & INFORMATION

1. TOP SEALANT 4730A5771
2-3 oz. tubes per package
2. CRANK HANDLE — 4720A5211
3. STABILIZER HANDLE — 4730A4191
4. ACCESS DOOR KEYS 4730A3211
2 keys to the package
5. PUMPS


Pumps should be identified by the drawings below and ordered by their corresponding numbers.



4730A3141




4730-3101



4730A3101

#1.1

6. WIRING




NOTE: WIRE HARNESS & PIGTAIL FIT ALL TRAILERS

1.2

7. CABINET AND DOOR TRIM

- (a) 280 Series Door Trim 4730A6001
Enough trim to fit any trailer in the 280 series.
- (b) 290 Series Door Trim 4730A6011
Enough trim to fit any trailer in the 290 series.
- (c) Cabinet Trim — 4730A6021
Enough trim for any camping trailer.

8. CABLES



#1.3

<u>Ref. No.</u>	<u>Part Name</u>	<u>290 Series</u>	<u>280 Series</u>
1	Cable Ass'y, Long Front	4730B5281 (one cable clip attached) (one clip in package)	4720B5281 (one cable clip attached) (one clip in package)
	Cable Ass'y, Long Back	4730B5271 (one cable clip attached) (one clip in package)	4720B5281 (one cable clip attached) (one clip in package)
2	Cable Ass'y	4730B5161	4730B5161
3	Cable Ass'y Short	4720B5271	4720B5271
4	Pin x 3 (with 4730A098 retaining ring x 3)	4730A2491	4730A2491
5	Pulley x 8	4720C2221	4720C2221

NOTE: All cable ass'y come with cable clips attached on both ends unless otherwise specified.

If 3/32 inch dia. cables are needed, order by the following table referring to Drawing #1.3 for reference numbers:

<u>Ref. No.</u>	<u>Part Name</u>	<u>290 Series</u>	<u>280 Series</u>
1	Cable Ass'y, Long Front	4730A5281 (one cable clip attached) (one clip in package)	4720A5281 (one cable clip attached) (one clip in package)
	Cable Ass'y, Long Back	4730A5271 (one cable clip attached) (one clip in package)	4720A5281 (one cable clip attached) (one clip in package)
2	Cable Ass'y	4730A5161 (one cable clip attached) (one clip in package)	4730A5161 (one cable clip attached) (one clip in package)
3	Cable Ass'y, Short	4720A5271 (one cable clip attached) (one clip in package)	4720A5271 (one cable clip attached) (one clip in package)
4	Pin x 3 (with 4730A098 retaining ring x 3)	4730A2491	4730A2491
5	Pulley x 8	4720C2221	4720C2221

9. TRAILER TOUCH UP PAINT

	<u>Part Number</u>	<u>Part Name</u>	<u>Usage</u>
(a)	8-214	Trailer Frame Black	Used on all tongue & frame members
(b)	8-215	Polar White	Used on outside of top
(c)	8-216	Top Interior Green	Used on inside of top only
(d)	8-217	Trailer Body Blue	Use on all trailer body panels & corners