


NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4720C5241	Top Assembly, Complete (not shown as unit)	49.	4730A6331	Tire & Rim	103.	4710A644	Cabinet Door Ass'y, Large
1.	4720B3271	Top Seal Long	50.	4710-5191	Stabilizer Ass'y, Right Rear	104.	4710-0311	Stove (Safari Range, Gold)
2.	4715A5411	Lift Bracket Ass'y.	51.	4710-5181	Stabilizer Ass'y, Left Rear		4710A0311	Stove, Holiday 163, Gold (not shown)
3.	4720C168	Top Channel Curb Side	52.	4720A0731	Stabilizer Ass'y, Front	105.	4710A0301	Sink
	4730A191	Top Channel Road Side (not shown)	53.	4731-539	Wheel Well Ass'y.		4710-051	Sink Clips (not shown)
4.	4720B167	Top Channel, End	54.	4720C3101	Floor Covering, Green	106.	4730A3101	Pump
5.	4720B2611	Screen Door Bracket, M2	55.	1213-1341	Buttons	107.	4730-3151	Basket - Strainer with tail piece (2 1/2")
6.	4715A519	Support Bracket	56.	4720D5261	Access Door	108.	4720B5091	Stove Cover Ass'y.
7.	4730A4311	Screen Door Snap, M2	57.	4720C5851	Access Door Support	109.	4710B0521	Galley Top
8.	4715-2091	Strike	58.	4720C5871	Pivot Ass'y, Rear	110.	4730A3881	Spinner & Hub Cap, M2
9.	4715-5051	Latch Ass'y.	59.	4720C5861	Pivot Ass'y, Front	111.	4720B592	Gas Bottle
10.	4710A5051	Screen Door & Spring	60.	4720A6391	Access Door Skin		4730A2251	Hold Down Bolt (not shown)
11.	4710A5091	Screen Door Frame	61.	4720A6491	Seal Strip Ass'y, Rear		4730A3431	Gas Hose (See Code 76)
12.	4720B2601	Top Door Hinge M2		4720A6771	Seal Strip Pkg.	112.	4715-291	Floor Trim
13.	4720B360	Screen Door Hinge	62.	4720A6691	Seal Strip Ass'y, Front	113.	4731-1981	Floor Trim
14.	4710-5061	Sliding Panel (Window)	63.	4720B3571	Seal (Access Door)	114.		No Number Assigned
15.	4710A4101	Door Seal Vertical	64.	4731-1741	Access Door Tread	115.	4730A1221	Safety Latch
	4720C539	Bed Ass'y, Rear (not shown as unit)	65.	4730A5201	Lock Bar Ass'y.	116.	4720A3041	Tag Holder & Light
	4720C540	Bed Ass'y, Front (not shown as unit)	66.	4730B3111	Lock Handle	117.	4720A3341	Snap Ring
16.	4720B5631	Bow Bracket Ass'y, M2	67.	4720B2621	Screen Door Support	118.	4720A6331	Right Front Body Panel
17.	4715-4251	Canvas Support, Rear Bed	68.	4720B5311	Door Bulkhead, Rear	119.	4730A4041	Bearing
18.	4720B5971	Canvas Support Ass'y.	69.	4720B5321	Door Bulkhead, Front	120.	4720B2371	Guide Channel
19.	4720A4021	Shock Cord Spool, M4	70.	4720C1331	Side Rail, Right Front	121.	4720A3691	Chain
20.	4720C5601	Bed Extension Ass'y.	71.	4715A4371	Water Tank, 10 Gallon	122.	4720A3031	Safety Chain
21.	4730B2701	Bed Seal Angle		4715-445	Water Line (not shown separately)	123.	4720A1221	Coupling Pkg.
22.	4730B2631	Bed Seal	72.	4720A0721	Cooler Clip	124.	4720E5201	Whiffle Tree & Screw Pkg. (Contains "D" Whiffle Tree)
23.	4720A0771	Bed Support Clip M4 (Ft Bed)	73.	4727A6801	Side Canvas Ass'y.		4720A2421	Thrust Bearing (not shown separately)
24.	4715-5181	Bed Support Ass'y.	74.	4727B6811	Rear Canvas Ass'y.		4720A238	Thrust Nut (not shown separately)
25.	4731-1711	Recessed Fill Spout	75.	4727B6821	Front Canvas Ass'y.	125.	4730-4011	Axle Complete
	4731-1081	Fill Spout Hose & Clamp (not shown)	76.	4730A3431	Gas Hose		4710A1021	Axle Hub (not shown separately)
26.	4720B1211	Leg Bracket	77.	5257-710	Cooler		4731-1351	Grease Cap (not shown separately)
27.	4720A5821	Front Support Ass'y.	78.	4730A3671	Lower Door Seal	126.	4720D1561	Long Pin, M2
28.	4725-5391	Mattress Complete	79.	4730A3741	Seal Angle	127.	4720B1571	Short Pin M4
	4714-5391	Mattress Skin (not shown separately)	80.	4715-2941	Seal Retainer, Front	128.	4715-528	Plastic Pulley
29.	4725-5171	Cushion Cover Ass'y.	81.	4715-2951	Seal Retainer, Rear	129.	4720B3091	Screw Eye
30.	4725-5241	Cushion Ass'y.	82.	4731-1261	End Panel	130.	4730A3381	Roll Pin, Long
31.	4720A6291	Corner Panel Ass'y.	83.	4731-5471	Long Panel Ass'y.	131.	4720A1481	Roll Pin, Short
32.	4720B1801	End Rail, Front	84.	4720A2101	Short End Panel Ass'y.	132.	4710-3621	Roll Pin, M4 (Drive)
33.	4720B1791	End Rail, Rear	85.	4731-194	Panel Curb Side	133.	1212-0121	Grommet
34.	4720A6351	Front Body Panel Ass'y.	86.		Number not assigned	134.	4720B2121	Corner Divider, M4
35.	4720A6301	Body Panel, Left	87.	4731-195	Roadside Panel Ass'y.	135.	4720B2111	Panel Divider
36.	4720C1351	Side Rail, Right Rear	88.	4731-2361	Wheel Well Seal, Short	136.	4715-2901	Panel Divider, Short
37.	4720A6761	Panel Ass'y, Rear	89.	4720A2051	Panel, Curb Side Front	137.	4731-2361	Wheel Well Seal
38.	4720C1361	Side Rail, Left	90.	4731-1971	Panel Ass'y.	138.	4710-4201	Screen Door Latch
39.	4720A6731	Right Rear Panel Ass'y.	91.	4731-2031	Pivot Arm, Left	139.	4730B1211	Rail Stop, M4
40.	4715A5011	Tail Light Frame Ass'y.	92.	4731-2021	Pivot Arm, Right	140.	1201B660	Lug Nut
41.	4715A1241	Tail Light Lens		4731-5021	Bracket Ass'y. (not shown)	141.	1204B108	Cotter Pin
42.	4715-1291	Reflector Trim	93.	4725-5711	Back Rest Ass'y.	142.	4715-537	Pulley & Bearing
43.	4715-1251	Reflector Holder - Red	94.	4731-5101	Dinette Table	143.	4730A5661	Pulley Bracket Ass'y, Rt. Fnt, L. RR
44.	4715-1411	Reflector - Red	95.	4720A5461	Table Leg Ass'y.	144.	4730A5671	Pulley Bracket Ass'y, Rt. RR, L. Fnt.
45.	4715-1271	Reflector Holder, Amber	96.	4731-561	Curb Side Cabinet	145.	4714-6011	Side Shock Cord Ass'y.
46.	471F-1391	Reflector, Amber	97.	4710B0411	Cabinet Top	146.	4714-6021	End Shock Cord Ass'y.
47.	4730C5141	Lift Ass'y, Complete	98.	4710-0401	Drawer	147.	4715A6371	Separator Pulley Pkg.
48.	4720A6661	Tongue Jack Pkg.	99.	4710A6101	Cabinet Door Ass'y.	148.	4715A5661	Separator Ass'y. No Number Assigned
	4720A3351	Jack Caster (Wheel) (not shown separately)	100.	4710A646	Galley Ass'y, Lower	149.	4731A546	Dinette Seat Road Side
	4714-1601	Lock Screw Ass'y. for Jack Caster (not shown)		4710-6511	Galley Cable, Long (not shown)	151.	4731A545	Dinette Seat Curb Side
	4720A3331	Jack Bracket (not shown separately)		4710-6521	Galley Cable, Medium (not shown)			
	4720A3341	Snap Ring (See 117)		4710-6531	Galley Cable, Short (not shown)			
				4710-0471	Knob, (not shown separately)			
			101.	4710A648	Galley Ass'y, Upper			
				4710A655	Galley Complete (not shown)			
			102.	4710A643	Cabinet Door Ass'y, Small			

1970
CT-481

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4720B5241	Top Ass'y, Complete (not shown as a unit)	48.	4720C6661	Tongue Jack Package	98.	4731-207	Floor Trim, Front
1.	4720B3271	Top Seal, Long		4720A3351	Jack Caster (wheel) (not shown separately)	99.	4731A545	Dinette Seat Curb Side
2.	4715A5411	Lift Bracket Ass'y		4720A3331	Jack Bracket (not shown separately)	100.	4730A1221	Safety Latch
3.	4720C168	Top Channel Curb Side		4720A3341	Snap Ring (see code 102)	101.	4720A3041	Tag Holder & Light
	4720C191	Top Channel Road Side (not shown)		4714-1601	Lock Screw Ass'y for Jack Caster	102.	4720A3341	Snap Ring
4.	4720B167	Top Channel, End		4730A6331	Tire & Rim	103.	4720B1391	Right Front Body Panel
5.	4720B2611	Screen Door Bracket, M2	49.	4710-5191	Stabilizer Ass'y, Right Rear	104.	4730A4041	Bearing
6.	4715A519	Support Bracket	50.	4710-5181	Stabilizer Ass'y, Left Rear	105.	4720B2371	Guide Channel
7.	4730A4311	Screen Door Snap, M2	51.	4720A0731	Stabilizer Ass'y, Front	106.	4720A3691	Chain
8.	4715-2091	Strike	52.	4731-5391	Wheel Well Ass'y	107.	4720A3031	Safety Chain
9.	4715-5051	Latch Ass'y	53.	4720C3101	Floor Covering, Green	108.	4720A1221	Coupling Pkg.
10.	4710A5051	Screen Door & Spring	54.	1213-1341	Button	109.	4720E5201	Whiffle Tree (contains "D" Whiffle Tree)
11.	4710A5091	Screen Door Frame	55.	4710A5461	Access Door Ass'y		4720A2421	Thrust Bearing (not shown separately)
12.	4720B2601	Top Door Hinge, M2	56.	4720B5851	Access Door Support		4720A238	Thrust Nut (not shown separately)
13.	4720B360	Screen Door Hinge	57.	4720B5871	Pivot Ass'y, Rear	110.	4730-4011	Axle Complete
14.	4710-5061	Sliding Door Panel	58.	4720C5861	Pivot Ass'y, Front		4710A1021	Axle Hub (not shown separately)
15.	4710A4101	Door Seal Vertical	59.	4720B2021	Access Door Skin		4731-1351	Grease Cap (not shown separately)
	4720C539	Bed Ass'y, Rear (not shown as a unit)	60.	4720B1311	Seal Strip, Rear	111.	4720D1561	Long Pin, M2
	4720C540	Bed Ass'y, Front (not shown as a unit)	61.	4720B1301	Seal Strip Ass'y, Front	112.	4720B1571	Short Pin, M4
16.	4720B5631	Bow Bracket Ass'y, M2	62.	4720B3571	Seal (Access Door)	113.	4715-528	Plastic Pulley
17.	4715-4251	Canvas Support, (Rear Bed)	63.	4731-1721	Access Door Tread (yellow)	114.	4720B3091	Screw Eye
18.	4720B5971	Canvas Support Ass'y	64.	4730A5201	Lock Bar Ass'y	115.	4730A3381	Roll Pin, Long
19.	4720A4021	Shock Cord Spool, M4	65.	4730B3111	Lock Handle	116.	4720A1481	Roll Pin, Short
20.	4720C5601	Bed Extension Ass'y	66.	4720B2621	Screen Door Support	117.	4710-3621	Roll Pin, M4
21.	4730B2701	Bed Seal Angle	67.	4720B5311	Door Bulkhead, Rear	118.	1212-0121	Grommet for Supply Line
22.	4730B2631	Bed Seal	68.	4720B5321	Door Bulkhead, Front	119.	4720A2121	Corner Divider, M4
23.	4720A0771	Bed Support Clip, M4 (Front Bed)	69.	4720C1331	Side Rail, Right Front	120.	4720B2111	Panel Divider, Short
24.	4715-5181	Bed Support Ass'y	70.	4727A6801	Side Canvas Ass'y	121.	4715-2901	Panel Divider, Short
25.		Number not assigned	71.	4727B6811	Rear Canvas Ass'y	122.	4730A3281	Wheel Well Seal, Long
26.	4720B1211	Leg Bracket	72.	4727B6821	Front Canvas Ass'y	123.	4710-4201	Screen Door Latch
27.	4720A5821	Front Support Ass'y	73.	4730A3671	Lower Door Seal	124.	4730B1211	Rail Stop, M4
28.	4725-5391	Mattress Complete	74.	4730A3741	Seal Angle	125.	1201B660	Lug Nut
	4714-5391	Mattress Skin (not shown separately)	75.	4715-2941	Seal Retainer Front	126.	4730A5661	Left Front Pulley Bracket Ass'y
29.	4725-5171	Cushion Cover Ass'y	76.	4715-2951	Seal Retainer Rear	127.	4730A5671	Pulley Bracket Ass'y, Right Front
30.	4725-5241	Cushion Ass'y	77.	4720A2091	End Panel, Long	128.	4715A5661	Separator Ass'y
31.	4720A6291	Corner Panel Ass'y	78.	4720A2101	End Panel Ass'y, Short	129.	1204B108	Cotter Pin
32.	4720B1801	End Rail Front	79.	4731-194	Panel Curbside	130.	4715-537	Pulley & Bearing
33.	4720B1791	End Rail Rear	80.	4731-5571	End Panel Ass'y, Long	131.	4714-6011	Side Shock Cord Ass'y
34.	4720C1401	Body Panel, Front	81.	4731-195	Roadside Panel	132.	4714-6021	End Shock Cord Ass'y
35.	4720C1371	Body Panel, Left Side	82.	4731-2371	Wheel Well Seal	133.	4715A6371	Separator Pulley Pkg.
36.	4720C1351	Side Rail, Right Rear	83.	4720A2051	Panel Curb Side Front	134.	4731-548	Supply Line (not shown)
37.	4731-5231	Panel Ass'y Rear	84.	4731-1971	Panel Ass'y	135.	4731A556	Dinette Seat Ass'y.
38.	4720C1361	Side Rail, Left	85.	4731-2031	Pivot Arm, Left	136.	4715-2891	Corner Divider, Short
39.	4720C1381	Right Rear Body Panel	86.	4731-2021	Pivot Arm, Right			
40.	4715A5011	Tail Light Frame Ass'y	87.	4731-5021	Bracket Ass'y (not shown)			
41.	4715A1241	Tail Light Lens	88.	4731-517	Back Rest Ass'y			
42.	4715-1291	Reflector Trim	89.	4731-5101	Dinette Table			
43.	4715-1251	Reflector Holder, Red	90.	4720A5461	Table Leg Ass'y			
44.	4715-1411	Reflector Red	91.	4731-561	Curb Side Cabinet			
45.	4715-1271	Reflector Holder, Amber	92.	4710B0411	Cabinet Top			
46.	4715-1391	Reflector, Amber	93.	4710-0401	Drawer			
47.	4730C5141	Lift Ass'y Complete	94.	4710A6101	Cabinet Door Ass'y			
			95.	4715-291	Floor Trim, Rear			
			96.	4710-415	Floor Trim, Left Front			
			97.	4730A3881	Spinner & Hub Cap, M2			

1970
CT-490

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4730C5241	Top Ass'y Complete (not shown as unit)	48.	4730A6321	Tire & Rim	104.	4710A0301	Sink
1.	4730B3271	Top Seal Long	49.	4710-5191	Stabilizer Ass'y, Right Rear,	4710-051		Clips (not shown)
2.	4715A5411	Lift Bracket Ass'y.	50.	4710-5181	Stabilizer Ass'y, Left Rear,	105.	4730A3101	Pump
3.	4730C1681	Top Channel	51.	4720A0731	Stabilizer Front	106.	4730-3151	Drain Basket
4.	4720B167	Top Channel End	52.	4720A5191	Wheel Well Ass'y.	107.	4720B5091	Stove Cover
5.	4720B2611	Screen Door Bracket M2	53.	4730C3091	Floor Covering	108.	4710B098	Galley Top
6.	4715A519	Support Bracket	54.	1213-1341	Button	109.	4730A3881	Spinner & Hub Caps, M2
7.	4730A4311	Screen Door Snaps, M2	55.	4730B5511	Access Door Complete	110.	4720B592	Gas Bottle
8.	4715-2091	Strike	56.	4720B5851	Door Support Ass'y.	111.	4730A1041	Floor Trim, Rear
9.	4715-5051	Latch	57.	4720C587	Pivot Ass'y, Rear	112.	4730A1051	Floor Trim, Curb Side
	4730B570	Door and Jamb Ass'y. (not shown separately)	58.	4720C586	Pivot Ass'y, Front	113.	4730A1221	Safety Latch
10.	4730B5471	Screen Door	59.	4730A6891	Access Door Panel Ass'y.	114.	4720A3041	Tag Holder
11.	4710A5091	Screen Door Frame	60.	4730A6981	Seal Ass'y, Rear	115.	4720A3341	Snap Ring
12.	4720B2601	Top Door Hinge		4730A6991	Seal Strip Pkg. (not shown)	116.	4720B3091	Screw Eye
13.	4720B3601	Screen Door Hinge	61.	4730A6971	Seal Ass'y, Front	117.	4730A4041	Bearing
14.	4710-5061	Sliding Panel (Window)	62.	4720B3571	Access Door Seal	118.	4720A2371	Guide Channel
	4720C539	Bed Ass'y, Rear (not shown as unit)	63.	4731-1751	Access Door Tread	119.	4720A3691	Chain
	4720C540	Bed Ass'y, Front (not shown as unit)	64.	4730A5201	Lock Bar Ass'y.	120.	4720A3031	Safety Chain
15.	4720B5631	Bow Bracket Ass'y.	65.	4730B3111	Lock Handle	121.	4720A1221	Coupling
16.	4715-4251	Canvas Support - Bed	66.	4720B2621	Screen Door Support	122.	4720E5201	Whiffle Tree & Screw Pkg. (Contains "D" Whiffle Tree)
17.	4720B5971	Canvas Support Ass'y.	67.	4720B5311	Bulkhead, Rear	123.	4720D1561	Long Pin M2
18.	4720A4021	Shock Cord Spool	68.	4720B5321	Bulkhead, Front	124.	4720B1571	Short Pin M4
19.	4720C5601	Bed Extension Ass'y.	69.	4730B1331	Side Rail, Right Front	125.	4715-528	Plastic Pulley
	4720B0831	Bed Side Pulley Wheel (not shown)	70.	4715A4371	Water Tank, 10 Gallon	126.	4730A3381	Roll Pin, Long
20.	4730B2701	Bed Seal Angle		4715-4501	1 1/4" Hose Clamp (not shown)	127.	4720A1481	Roll Pin, Short M5
21.	4730B2631	Bed Seal	71.	4720A0721	Cooler Clip	128.	4710-3621	Roll Pin, M4 (Drive Pin)
22.	4720A0771	Bed Support Clip	72.	4727A6901	Side Canvas Ass'y.	129.	4730B1211	Rail Stop
23.	4715-5181	Bed Support Ass'y.	73.	4727B6911	Rear Canvas Ass'y.	130.	1212-0121	Grommet
24.	4731-1711	Recessed Fill Spout	74.	4727B6921	Front Canvas Ass'y.	131.	4720B2111	Panel Divider
	4731-1081	Fill Spout, Hose & Clamp (not shown)	75.	4730A3431	Gas Hose	132.	4730A5681	Left Rear Pulley Bracket
25.	4720B1211	Leg Bracket	76.	5257-710	Cooler	133.	4710-4101	Door Seal Vertical
26.	4720A3991	Front Bed Support	77.	4730A3671	Lower Door Seal	134.	1200B551	Lug Nut
27.	4725-5401	Mattress Complete	78.	4730A3741	Seal Angle	135.	4710-4121	Screen Door Latch & Screw Ass'y.
28.	4725-5281	Cushion Ass'y for Dinette Seat (4731A531)	79.	4715-2931	Screen Door Seal	136.	4725-5831	Back Rest Ass'y.
29.	4725-5821	Cushion Ass'y.	80.	4715-294	Seal Retainer	137.	4725-561	Cushion Ass'y.
30.	4730A5711	Corner Body Panel Ass'y.		4715-295	Seal Retainer	138.	4731-558	Dinette Seat
31.	4720B1801	End Rail, Front	81.	4731-1261	End Panel	139.	4710B685	Slide Out Bench
32.	4720B1791	End Rail, Rear	82.	4730A5731	Panel Ass'y (End Long)	140.		Part Number not assigned
33.	4730A5761	Front Body Panel Ass'y.	83.	4720A2101	End Panel (Short)	141.	4710-649	Slide Ass'y.
34.	4730B5651	Panel Ass'y, Left	84.	4731-2381	Curb Side Panel	142.	4730A3011	Axle Complete
35.	4730C1351	Side Rail, Right Rear	85.	Part Number	Not Assigned	143.	4720A6701	Electric Brake Shoes
36.	4731A5011	Body Panel, Rear	86.	4715-2891	Corner Divider, Short	144.	4720A6671	R. H. Brake Magnets
37.	4730C1361	Side Rail, Left	87.	4715-2901	Corner Divider, Short		4720A6721	L. H. Brake Magnets
38.	4730A5961	Right Rear Body Panel	88.	4731-1381	Paneling	145.	4714A1021	Axle Hub
39.	4715A5011	Frame Ass'y, Tail Light	89.	4731A531	Dinette Seat		4731-1351	Grease Cap (not shown separately)
40.	4715A1241	Tail Light Lens	90.	4731-2031	Pivot Arm, Left	146.	4730A5811	Right Front Body Panel
41.	4715-1291	Reflector Trim	91.	4731-2021	Pivot Arm, Right	147.	4715A5661	Separator Ass'y.
42.	4715-1251	Reflector Holder, Red	92.	4731A507	Dinette Seat	148.	1204B108	Cotter Key
43.	4715-1411	Reflector Red	93.	4731-5111	Dinette Table Front	149.	4715A6371	Separator Pulley Pkg.
44.	4715-1271	Reflector Holder, Amber		4731-5101	Dinette Table Rear	150.	4730A5691	Right Rear Pulley Brkt.
45.	4715-1391	Reflector, Amber	94.	4720A5461	Dinette Table Leg Ass'y.	151.	4730A5661	Right Front Pulley Brkt.
46.	4730C5141	Lift Ass'y, Complete	95.	4710A665	Curb Side Cabinet	152.	4730A5671	Left Front Pulley Brkt.
47.	4720A6661	Tongue Jack Complete	96.	4710A0801	C. S. Cabinet Top	153.	4715-537	Steel Pulley Ass'y.
	4720A3331	Jack Bracket (not shown separately)	97.	4710A697	Small Cabinet Door	154.	4714-6011	End Shock Cord Ass'y.
	4720A3341	Snap Ring (See 115)	98.	4710A662	Cabinet Door Ass'y.	155.	4714-6021	Side Shock Cord Ass'y.
	4720A3351	Jack Caster (Wheel)	99.	4710A678	Lower Galley Ass'y.			
	4714-1601	Lock Screw Ass'y. for Jack Caster	100.	4710A679	Upper Galley Ass'y.			
				4710-0471	Knob (not shown)			
			101.	4710-0401	Drawer			
			102.	4710A644	Galley Door Ass'y.			
			103.	4710-0311	Stove (Safari Range, Gold)			
				4710A0311	Stove Holiday 163, Gold (not shown)			

1970
CT-490S

PARTS LIST


Coleman
CAMPING TRAILERS



NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
	4730C5241	Top Ass'y Complete (not shown as unit)	48.	4730A6321	Tire & Rim	107.	4720B5091	Stove Cover
1.	4730B3271	Top Seal Long	49.	4710-5191	Stabilizer Ass'y, Right Rear	108.	4710B098	Galley Top
2.	4715A5411	Lift Bracket Ass'y.	50.	4710-5181	Stabilizer Ass'y, Left Rear	109.	4730A3881	Spinner & Hub Caps, M2
3.	4730C1681	Top Channel	51.	4720A0731	Stabilizer Front	110.	4720B592	Gas Bottle
4.	4720B167	Top Channel End	52.	4720A5191	Wheel Well Ass'y.	111.	4730A1041	Floor Trim, Rear
5.	4720B2611	Screen Door Bracket, M2	53.	4730C3091	Floor Covering	112.	4730A1051	Floor Trim, Curb Side
6.	4715A519	Support Bracket	54.	1213-1341	Button	113.	4730A1221	Safety Latch
7.	4730A4311	Screen Door Snaps, M2	55.	4730B5511	Access Door Complete	114.	4720A3041	Tag Holder
8.	4715-2091	Strike	56.	4720B5851	Door Support Ass'y.	115.	4720A3341	Snap Ring
9.	4715-5051	Latch	57.	4720C587	Pivot Ass'y, Rear	116.	4720B3091	Screw Eye
	4730B570	Door & Jam Ass'y. (not shown separately)	58.	4720C586	Pivot Ass'y, Front	117.	4730A4041	Bearing
			59.	4730A6891	Access Door Panel Ass'y.	118.	4720A2371	Guide Channel
10.	4730B5471	Screen Door	60.	4730A6981	Seal Ass'y, Rear	119.	4720A3691	Chain
11.	4710A5091	Screen Door Frame		4730A6991	Seal Strip Pkg. (not shown)	120.	4720A3031	Safety Chain
12.	4720B2601	Top Door Hinge	61.	4730A6971	Seal Ass'y, Front	121.	4720A1221	Coupling
13.	4720B3601	Screen Door Hinge	62.	4720B3571	Access Door Seal	122.	4720E5201	Whiffle Tree & Screw Pkg. (contains "D" Whiffle Tree)
14.	4710-5061	Sliding Panel (Window)	63.	4731-1751	Access Door Tread			
	4720C539	Bed Ass'y, Rear (not shown as unit)	64.	4730A5201	Lock Bar Ass'y.	123.	4720D1561	Long Pin M2
	4720C540	Bed Ass'y, Front (not shown as unit)	65.	4730B3111	Lock Handle	124.	4720B1571	Short Pin M4
15.	4720B5631	Bow Bracket Ass'y.	66.	4720B2621	Screen Door Support	125.	4715-528	Plastic Pulley
16.	4715-4251	Canvas Support - Bed	67.	4720B5311	Bulkhead, Rear	126.	4730A3381	Roll Pin, Long
17.	4720B5971	Canvas Support Ass'y.	68.	4720B5321	Bulkhead, Front	127.	4720A1481	Roll Pin, Short M5
18.	4720A4021	Shock Cord Spool	69.	4730B1331	Side Rail, Right Front	128.	4710-3621	Roll Pin, M4 (Drive Pin)
19.	4720C5601	Bed Extension Ass'y.	70.	4715A4371	Water Tank, 10 Gallon	129.	4730B1211	Rail Stop
	4720B0831	Bed Side Pulley Wheel (not shown)		4715-4501	1 1/2" Hose Clamp (not shown)	130.	1212-0121	Grommet
20.	4730B2701	Bed Seal Angle	71.	4720A0721	Cooler Clip	131.	4720B2111	Panel Divider
21.	4730B2631	Bed Seal	72.	4727A6931	Side Canvas Ass'y.	132.	4730A5681	Left Rear Pulley Bracket
22.	4720A0771	Bed Support Clip	73.	4727B6911	Rear Canvas Ass'y.	133.	4710-4101	Door Seal Vertical
23.	4715-5181	Bed Support Ass'y.	74.	4727B6921	Front Canvas Ass'y.	134.	1200B551	Lug Nut
24.	4731-1711	Recessed Fill Spout	75.	4730A3431	Gas Hose	135.	4710-4121	Screen Door Latch & Screw Ass'y.
	4731-1081	Fill Spout, Hose & Clamp (not shown)	76.	5257-710	Cooler			
25.	4720B1211	Leg Bracket	77.	4730A3671	Lower Door Seal	136.	4725-5831	Back Rest Ass'y.
26.	4720A3991	Front Bed Support	78.	4730A3741	Seal Angle	137.	4725-561	Cushion Ass'y.
27.	4725-5401	Mattress Complete	79.	4715-2931	Screen Door Seal	138.	4731-558	Dinette Seat
28.	4725-5281	Cushion Ass'y. for Dinette Seat (4731A531)	80.	4715-294	Seal Retainer	139.	4710B685	Slide Out Bench
				4715-295	Seal Retainer	140.		Part Number not assigned
29.	4725-5821	Cushion Ass'y.	81.	4731-1371	End Panel	141.	4710-649	Slide Ass'y.
30.	4730A5711	Corner Body Panel Ass'y.	82.	4730A5731	Panel Ass'y. (End Long)	142.	4730A3011	Axle Complete
31.	4720B1801	End Rail, Front	83.	4720A2101	End Panel (Short)	143.	4720A6701	Electric Brake Shoes
32.	4720B1791	End Rail, Rear	84.	4731-2381	Curb Side Panel	144.	4720A6671	R. H. Brake Magnets
33.	4730A5761	Front Body Panel Ass'y.	85.		Part Number not assigned		4720A6721	L. H. Brake Magnets
34.	4730B5651	Panel Ass'y, Left	86.	4715-2891	Corner Divider, Short	145.	4714A1021	Axle Hub
35.	4730C1351	Side Rail, Right Rear	87.	4715-2901	Corner Divider, Short		4731-1351	Grease Cap (not shown separately)
36.	4731A5011	Body Panel, Rear	88.	4731-1381	Paneling	146.	4730A5811	Right Front Body Panel
37.	4730C1361	Side Rail, Left	89.	4731A531	Dinette Seat	147.	4715A5661	Separator Ass'y.
38.	4730A5961	Right Rear Body Panel	90.	4731-2031	Pivot Arm, Left	148.	1204B108	Cotter Key
39.	4715A5011	Frame Ass'y, Tail Light	91.	4731-2021	Pivot Arm, Right	149.	4731A545	Dinette Seat Curb Side
40.	4715A1241	Tail Light Lens	92.	4731A507	Dinette Seat	150.	4730A5691	Rt. RR Pulley Bracket
41.	4715-1291	Reflector Trim	93.	4731-5111	Dinette Table Front	151.	4730A5661	Right Front Pulley Brkt.
42.	4715-1251	Reflector Holder, Red		4731-5101	Dinette Table Rear	152.	4730A5671	Left Front Pulley Brkt.
43.	4715-1411	Reflector Red	94.	4720A5461	Dinette Table Leg Ass'y.	153.	4715-537	Steel Pulley Ass'y.
44.	4715-1271	Reflector Holder, Amber	95.	4710A665	Curb Side Cabinet	154.	4714-6011	End Shock Cord Ass'y.
45.	4715-1391	Reflector, Amber	96.	4710A0801	C. S. Cabinet Top	155.	4714-6021	Side Shock Cord Ass'y.
46.	4730C5141	Lift Ass'y, Complete	97.	4710A697	Small Cabinet Door			
47.	4720A6661	Tongue Jack Complete	98.	4710A662	Cabinet Door Ass'y.			
	4720A3331	Jack Bracket (not shown separately)	99.	4710A678	Lower Galley Ass'y.			
	4720A3341	Snap Ring (See 115)	100.	4710A679	Upper Galley Ass'y.			
	4720A3351	Jack Caster (Wheel)		4710-0471	Knob (not shown)			
	4714-1601	Lock Screw Ass'y. for Jack Caster	101.	4710-0401	Drawer			
			102.	4710A644	Galley Door Ass'y.			
			103.	4710-0311	Stove (Safari Range, Gold)			
				4710A0311	Stove Holiday 163, Gold (not shown)			
			104.	4730A2461	Sink			
			105.	4730A3101	Pump			
			106.	4730-3151	Drain Basket			

MISC. PARTS & INFORMATION

1. CRANK HANDLE - 4720A5211
2. STABILIZER HANDLE - 4730A4191
3. ACCESS DOOR KEYS - 4730A3211
2 Keys to the package
4. PUMP — 4730A3101 (Fits All Models)
Replaces 4730A3141, 4730-3101



4730A3101


#1.1

5. LOGOS and SCRIPTS

<u>Description</u>	<u>Part Number</u>
Coleman Logo (6¼" x 2¼")	4730A166
Coleman Name Tape (32" x 3½")	4715-416
460 Logo	4710A161
470 Logo	4715A161
480 Script	4715-480
480S Script	4715-414
481 Logo	4730B156
482 Logo	4730B157
490 Script	4715-398
490S Script	4731-122
Accent Strip Tape	4715-2221


6. WIRING

a. 380, 480 Series, 370, 470 and 360, 460




#1.2

b. 390 and 490 Series



#1.3

7. CABLES



#1.4


<u>Code</u>	<u>Description</u>	<u>Part No.</u>	<u>Used On Models</u>
1	Cable Ass'y, Long	4730B5271	470, 480, 490 and all 200 and 300 Series.
2	Cable Ass'y, Intermediate	4730B5161	470, 480, 490 and all 200 and 300 Series.
3	Cable Ass'y, Short	4720B5271	470, 480, 490, and all 200 and 300 Series.
4	Pin & Retaining Ring Pkg. Pin 4730D249 Ring 4730B098	4730D2491	470, 480, 490, and all 200 and 300 Series.
5	Nylon Pulley	4715-528	Used on top two sections of Lift Arm.
6	Steel Pulley	4715-537	Used on Stationary or bottom section of lift.

Note: All Cable Assemblies come with cable clips (4720B169).

8. TRAILER TOUCH UP PAINT


	<u>Part Number</u>	<u>Part Name</u>	<u>Usage</u>
(a)	8-214	Trailer Frame Black	Used on all tongue & frame members
(b)	8-217	Trailer Body Aqua	Used on all 360 & 460 body panels & corners
(c)	8-218	Trailer Body Autumn Green	Used on all 380 & 480 series body panels & corners
(d)	8-219	Trailer Body Harvest Brown	Used on all 390 & 490 series body panels & corners
(e)	8-220	Trailer Body Blue	Used on all 370 & 470 body panels & corners
(f)	8-221	Trailer Body Butterscotch	Cooler touch up.

9. 110 VOLT ELECTRICAL SYSTEM
300 Series, 480 and 490




Code No.	Part No.	Qty.	Part Name
1.	4710-352	x 1	Fuse Holder
2.	4710-370	x 1	Fustat Adapter
3.	4710-371	x 1	Fuse
4.	4710-355	x 1	Receptacle Cover
5.	4710-354	x 1	Receptacle
6.	4710A364	x 1	Switch Box
7.	4710A365	x 1	Fuse Box
8.	4710-353	x 1	Outside Receptacle
9.	4710B367	x 1	Wire-Short
10.	4710B368	x 1	Wire-Long
11.	1216-239	x 4	Strain Relief

110 VOLT
WIRING DIAGRAM



10. 110 VOLT ELECTRICAL SYSTEM
For 480S & 490S Trailers



#1.7

Code No.	Part Number	Description	Quantity Used
1	4731-527	Breaker Box & Lid Ass'y	x 1
2	1216-451	St. Square Connector	x 2
3	4731-132	Breaker Switch	x 1
4	4710-355	Receptacle Cover	x 1
5	4710-354	Receptacle	x 1
6	4710A364	Switch Box	x 1
7	4710-353	Outside Receptacle	x 1
8	4731-133	Wire, Short	x 1
9	4731-134	Wire, Long	x 1
10	1216-239	Strain Relief	x 4

110 VOLT
WIRING DIAGRAM #1.8

