


1970

Original



Camping Trailers




INDEX

Parts List	CT-460.....	2 and 3
	CT-470.....	4 and 5
	CT-480.....	6 and 7
	CT-481.....	8 and 9
	CT-482.....	10 and 11
	CT-480s.....	12 and 13
	CT-490.....	14 and 15
	CT-490s.....	16 and 17
	Miscellaneous Parts.....	18 thru 22

1970
CT-460

PARTS LIST

Coleman
CAMPING TRAILERS




NO.	PART NO.	PART NAME	NO.	PART NO.	PART NAME
1.	4727A6601	Canvas Complete	43.	4710-3201	Reflector (Red)
	4710A540	Lower Bed Complete	44.	4710-061	Floor Trim
	4710A537	(not shown as a unit) Upper Bed Complete	45.	4715-3101	Floor Covering
		(not shown as a unit)	46.	4715-2401	Panel
2.	4720B5631	Bow Bracket Ass'y	47.	4720A2091	Panel, End, Long
3.	4710B1631	Bed Slide Left	48.	4715-2421	Panel
4.	4710B157	Bed Rest Front	49.	4715-2031	Panel (Wheel Well)
5.	4710B141	Bed Rest Rear	50.	4715-2381	Panel
6.	4710B1621	Bed Slide Right	51.	4715-2391	Panel
7.	4715B5601	Bed Extension - Lower Bed	52.	4715-2371	Panel
8.	4710A1811	Lower Bed Pull	53.	4710-160	Gasket
9.	4710A4251	Canvas Support (Bed)	54.	4710-3171	Tag Holder & Light
10.	4710-5621	Bow Support Ass'y	55.	4710-3161	Tail Light
11.	4725-5371	Mattress Ass'y	56.	4710B1171	Access Door Skin
	4714-5371	Mattress Skin	57.	4720A1311	Seal Strip Rear (Door)
		(not shown Separately)	58.	4720A1301	Seal Strip Front (Door)
12.	4720C5601	Bed Extension - Upper	59.	4720B3571	Seal (Access Door)
13.	4715-5181	Bed Support Ass'y	60.	4720B5851	Access Door Support
14.	4720B1211	Log Bracket	61.	4730A5201	Lock Bar Ass'y
15.	4730A3291	Wheel Well Seal	62.	4730B3111	Lock Handle
16.	4720A5191	Wheel Well Ass'y	63.	4720C5871	Pivot Rear
17.	4730A3281	Wheel Well Seal	64.	4720C5861	Pivot Front
18.	4710A1341	Rail Front	65.	4731-1721	Access Door Tread
19.	4710A1401	Body Panel Front	66.	4710A5521	Canvas Support Inside
20.	4710-394	Side Rail Left	67.	4710-4041	Bed Canvas Support
21.	4710-180	Side Rail Right		4710A561	Canvas & Pole Support
22.	4710A4401	Left Side Body Panel			(not shown as a unit)
23.	4720A1471	Corner Panel	68.	4710A3051	Canvas Support
24.	4710A1351	Rail, Left Rear	69.	4710-5141	Pole & Lock Ass'y
25.	4710A5221	Bed Holder Ass'y	70.	4710-5131	Pole Support
26.	4710A1311	Rail, Right Rear	71.	4710B512	Lock Bracket
27.	4710A3621	Drive Pin	72.	4710A5371	Access Door Complete
28.	4715A1381	Rail Stop	73.	4715-2441	Floor Trim
29.	4715A1371	Rail Stop	74.	4715-2451	Floor Trim
30.	4710A4431	Left Rear Body Panel	75.	4715-2461	Floor Trim
31.	4710A4421	Right Rear Body Panel	76.	4715-2471	Floor Trim
32.	4710A5991	Door Bulkhead Left	77.	4715-2481	Floor Trim
33.	4710A5981	Door Bulkhead Right	78.	4715-2491	Floor Trim
34.	4710A4411	Right Side Body Panel	79.	4720B2111	Panel Divider
35.	4720A3031	Safety Chain	80.	4720B2121	Corner Divider
36.	4710-4011	Axle	81.	4710-5181	Stabilizer Right Front - Left Rear
	4714A1021	Hub Ass'y	82.	4715-4031	Road Cover Seal
		(not shown Separately)	83.	4715-4041	Road Cover Seal
	4731-1351	Grease Cap (not shown Separately)	84.	4715-4051	Road Cover Seal
37.	4730A4041	Bearing	85.	4715-4061	Road Cover Seal
38.	4715-3791	Tire & Rim		4727B5131	Road Cover (not shown Separately)
39.	4730A3921	Hub Cap	86.	4720B0831	Bed Extension Pulley
40.	1200B551	Lug Bolt		4715B5641	Step Complete (not shown Separately)
41.	4710-5191	Stabilizer, Right Rear-Left Front	87.	4720A4021	Shock Cord Spool
42.	4710-3191	Reflector (Amber)	88.	4730-356	Coupler

1970
CT-470

PARTS LIST

Coleman
CAMPING TRAILERS



NO.	PART NO.	DESCRIPTION	NO.	PART NO.	DESCRIPTION
	4715A5341	Top Ass'y Complete (not shown as a unit)	53.	4715-3791	Tire & Rim
1.	4715-3271	Top Seal, Long	54.	4730A3921	Hub Cap
2.	4720D5411	Lift Bracket Ass'y	55.	4730A4041	Bearing
3.	4715-165	Top Channel, Side	56.	4715A6201	Whiffle Tree & Screw
4.	4715A167	Top Channel, End	57.	4715-5241	Pulley Bracket
5.	4715A519	Support Bracket	58.	4730A3381	Roll Pin, Large
6.	4715-2091	Strike Pkg.	59.	4720A1481	Roll Pin, Short M5
7.	4715-5051	Latch	60.	4720B3091	Eye Bolt, M4 "Screw Eye"
8.	4727A6701	Canvas, Roadside	61.	4720D1561	Pin, Long M2
9.	4727A6751	Canvas, Curbside	62.	4720A2371	Guide Channel
10.	4730B5141	Lift Ass'y, Complete	63.	4715-1391	Reflector, Amber
	4715A540	Lower Bed Complete (not shown as a unit)	64.	4715-1271	Reflector Holder, Amber
11.	4715B5601	Bed Extension (Lower Bed)	65.	4710-3621	Drive Pin, M4
	4720B0831	Bed Side Pulley Wheel (not shown)	66.	4715A1381	Rail Stop, M2
12.	4720B5631	Bow Bracket Ass'y, M2	67.	4715A1371	Rail Stop, M2
13.	4710A1811	Lower Bed Pull	68.	4720A3031	Safety Chain
14.	4710B1621	Bed Slide, Right	69.	4730A1221	Safety Latch
15.	4710B141	Bed Rest, Rear	70.	4715-240	Panel
16.	4710B163	Bed Slide, Left	71.	4720A2091	End Panel, Long
17.	4710B157	Bed Rest, Front	72.	4715-237	Panel
18.	4725-5381	Mattress Ass'y	73.	4715-203	Panel, Wheel Well
	4714-5381	Mattress Skin (not shown separately)	74.	4715-239	Panel
	4715-A539	Upper Bed Complete (not shown as a unit)	75.	4715-238	Panel
19.	4720B1211	Bracket Leg	76.	4715-242	Panel
20.	4715-5181	Bed Support Ass'y	77.	4715-528	Plastic Pulley Ass'y
21.	4715A194	End Rail Front	78.	4720B1571	Short Pin, M4
22.	4715-5481	Panel, Front	79.	1200B551	Lug Bolt
23.	4720A5191	Wheel Well Ass'y	80.	4710-061	Floor Trim
24.	4710-180	Side Rail Left	81.	4715A3101	Floor Covering
25.	4715-5431	Panel, Left Side Body	82.	4715-4251	Canvas Support - Bed
26.	4715-5471	Panel, Body Corner	83.	4720C5601	Bed Extension Ass'y (Upper Bed)
27.	4715B195	Left Rear Rail		4720A4021	Shock Cord Spool (not shown)
28.	4715B191	Right Rear Rail	4720B0831	Bed Side Pulley Wheel (not shown)	
29.	4715-5441	Panel, Left Rear Body	84.	4710A522	Bed Holder
30.	4715-5461	Panel Ass'y, Right Rear	85.	4720B2111	Panel Dividers, M4
31.	4715-5421	Panel, Right Side Body	86.	4720B2121	Corner Dividers, M4
32.	4710-5191	Stabilizer, Left Front, Right Rear	87.	4731-1731	Access Door Tread
33.	4715-6381	Access Door Skin	88.	4715A5361	Access Door Complete
34.	4715-640	Seal Strip, Right	89.	4715-244	Floor Trim
	4715-6411	Access Door Seal Strip Pkg.	90.	4715-245	Floor Trim
35.	4715-639	Seal Strip, Left	91.	4715-246	Floor Trim
36.	4730A5201	Lock Bar Ass'y	92.	4715-247	Floor Trim
37.	4730B3111	Lock Handle	93.	4715-248	Floor Trim
38.	4730C5871	Pivot, Rear	94.	4715-249	Floor Trim
39.	4730C5861	Pivot, Front	95.	4720B5971	Canvas Support Ass'y
40.	4720B3571	Seal	96.	4715-6041	Screen Door (Spring & Screws Included)
41.	4720B5851	Access Door Support		4710A5091	Screen Door Frame Ass'y (not shown separately)
42.	4730A329	Wheel Well Seal	97.	4720B2621	Screen Door Support
43.	4730A328	Wheel Well Seal	98.	4710-5181	Stabilizer, Right Front, Left Rear
44.	4715A5011	Tail Light Frame	99.	4715-537	Steel Pulley Ass'y
45.	4720A3041	Tag Holder and Light	100.	4715-5221	Pulley Bracket
46.	4715A1241	Tail Light Lens	101.	4715-5231	Pulley Bracket
47.	4715-1251	Reflector Holder, Red	102.	4715-5251	Pulley Bracket
48.	4715-1411	Reflector, Red	103.	1204B108	Cotter Pin
49.	4715-1291	Reflector Trim	104.	4710-3621	Drive Pin
50.	4715-699	Door Bulkhead, Left	105.	4715A5661	Separator Ass'y
51.	4715-698	Door Bulkhead, Right	106.	4715A6371	Separator Pulley Pkg.
52.	4710-401	Axle			
	4714A1041	Axle Hub Ass'y (not shown separately)			
	4731-1351	Grease Cap (not shown separately)			

1970
CT-480

PARTS LIST

