



Greenbrier Operations,  
Atwood Mobile Products  
P.O. Box R, Kelly Willis Road  
Greenbrier, TN 37073 Phone: (615) 643-4556 FAX: (615) 643-4616

# Wedgewood Drop-Ins

- INSTALLATION
- OPERATION
- MAINTENANCE
- WARRANTY

## Contents:

Effective 3/91

Safety Information .....	1
Installation .....	2
Operation and Maintenance .....	3
Warranty .....	4



## SAFETY INFORMATION

**Installer:** Provide these instructions to the consumer.

**Consumer:** Thoroughly read and understand this manual before attempting to use your Wedgewood Drop-In. Keep these instructions for future reference.

### WARNING: For Your Safety!

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult Atwood, a qualified installer, service center, or the gas supplier.

### WARNING: For Your Safety!

#### If you smell gas:

1. Open windows
2. Do not touch electric switches.
3. Extinguish any open flame.
4. Shut gas off at L.P. gas bottle.
5. From a neighbor's phone, immediately call your L.P. gas supplier or a qualified L.P. gas appliance service person.
6. If you cannot reach your gas supplier, call the fire department.

### WARNING: For Your Safety!

Do not store or use gasoline or other flammable vapors and liquids near this or any other appliance.

### WARNING: For Your Safety!

Shut off all gas appliances when refueling or traveling. This includes pilot lights.

Wedgewood gas operated Drop-Ins are for use with L.P. gas only, and installation in recreational vehicles only (e.g. travel trailers, motor homes, tent campers, etc.).

Drop-Ins must not be used as space heaters because of potential danger and possible damage to operating components of the unit. Death by asphyxiation due to carbon monoxide may result.

A window (or air vent) should be open slightly while using the Drop-In. Gas flame consumes oxygen which has to be replaced to assure proper combustion.

### NOTE:

Have the installer show you where the gas shut off valve is located, so that you will know how and where to turn off the gas supply when necessary.

## INSTALLATION

### NOTE:

Installation must conform with local codes or in the absence of local codes, with the American National Standard for Recreational Vehicles, ANSI/A119.2-1990 and Article 551, ANSI/NFPA 70. In Canada, installation must conform with CSA Z240.4.2-M.

1. Make cut out in counter with clearances as shown (Figure 1).

### CAUTION:

The minimum verticle distance to combustibile material above the Drop-In is 24 inches.

2. Slip unit into cutout and, when it is squarely and firmly in place, secure to counter with wood screws (not supplied).
3. Attach gas supply line as follows:
  - a. on two burner models attach 3/8" gas supply line to center of the manifold pipe at the union with flare nut.
  - b. on three burner models select most convenient access hole in burner box. Install open heyco bushing in that hole and install closed plug into remaining access hole. Attach 3/8" gas supply line to right end of the manifold pipe at the union with flare nut.
4. Turn gas supply on.
5. Test all fittings and gas lines for leaks, using a leak detecting solution.

### WARNING:

Do not use matches, candles or other source of ignition for this purpose.

6. When certain there are no gas leaks, position cook top surface in place and attach with nylon screws.
7. Your Wedgewood Drop-In is ready for operation.


## OPERATION and MAINTENANCE

1. The burner controls operate counterclockwise, and must be pressed inward to turn on.
2. Clean all surfaces as soon as possible after spills or spotting. Use warm soapy water with a soft cloth only. Grit or acid-type cleaners should never be used.
  - a. never wash warm porcelain surfaces.
  - b. pitting and discoloration will result if spills are allowed to remain for any length of time on stainless steel.
3. Burner and burner tube may be cleaned by removing screw which holds the burner assembly to the burner box. Be sure the burner assembly is clean and dry before replacing.
4. If any of the burner's ports are stopped up, carefully clean with a toothpick.

### CAUTION:


When cleaning any orifice or the burner assembly, care must be used to prevent damaging or enlarging the openings. Never use a wire or other metallic implement to clean an orifice or burner port. Any enlargement of an orifice or the burner ports will affect the gas flow and, consequently, the burner's function.

5. If flames lift off the burner there is too much pressure in the gas line, or if the flame flashes back into the burner tube there is not enough pressure in the gas line. Under both conditions, have your regulator checked by a qualified Service Center.



MODEL	A	B	C	D	E	F
2 burners	16 3/8"	11 5/8"	3 1/8"	4 3/4"	2 1/4"	3/4"
3 burners	18 15/16"	16 1/8"	3 1/8"	4"	2 1/2"	2 3/8"

FIGURE 1  
Drop-In Cutout



**FIGURE 2**  
**Drop-In Exploded Views**

**Two Burner Drop-In**

Item	Part Number	Description
1A	53304	Grate, Designer
1B	51007	Grate, Medallion
N/S	51406	Grate Clip, Medallion
2	52537	Thumb Screw
3	Order by Color/Style	Cook Top
4	53000	Burner Knob
5	52530	Right Burner
6	52516	Knob Tray
7	52506	Burner Valve
8	52503	Manifold
9	52549	Burner Box
10	52529	Left Burner

**Three Burner Drop-In**

Item	Part Number	Description
1A	53303	Rear Grate Designer
1B	53302	Front Grate Designer
1C	51007	Grate, Medallion
N/S	51406	Grate Clip, Medallion
2	52537	Thumb Screw
3	Order by Color/Style	Cook Top
4	53000	Burner Knob
5	52533	Right Rear Burner
6	52524	Knob Tray
7	52506	Burner Valve
8	52519	Manifold
9	52550	Burner Box
10	52532	Left Rear Burner
11	52531	Left Front Burner

## WEDGEWOOD DROP-IN LIMITED WARRANTY

Atwood Mobile Products, warrants to the original purchaser only that Wedgewood Drop-Ins are free from defects in material or workmanship under the following conditions.

1. For one (1) year from the date of purchase Atwood will repair or replace any part defective in material or workmanship. This includes reasonable labor charges required to remove and replace the part. Service calls to the customer's location are not considered part of these charges and are therefore the responsibility of the original purchaser.
2. In the event of a claim, the original purchaser **must contact in advance**, either the nearest authorized Wedgewood Service Station or the Wedgewood Consumer Service Department. Warranty claim service must be performed at an authorized Wedgewood Service Station or as approved by the Wedgewood Consumer Service Department; Atwood Mobile Products, P.O. Box R, Kelly Willis Rd., Greenbrier, TN, 37073. Phone: 615/643-4556 FAX:615/643-4616. A current list of Wedgewood Service Stations can be obtained by writing to the above address. To speed service, write RE: Service Station List, on the outside of your envelope.
3. Upon request of such notification, Atwood shall decide whether to repair or replace the defective item, reserving at all times the right to inspect and verify any claimed defects. If the examination, in the sole judgement of Atwood, proves that any part of the Wedgewood Drop-In failed because of defective material or workmanship, Atwood will, at its option, either repair or replace the part. The original purchaser must pay the cost of examination to determine whether or not the part is defective.
4. Each Drop-In, or replacement part, covered under this Warranty shall be furnished at the nearest Wedgewood Service Station. The original purchaser is responsible for all handling, transportation, and shipping charges on replacement parts from the factory. Every defective Drop-In or part replaced under this Warranty shall become the property of Atwood, and at our request must be returned to the Consumer Service Department, Atwood Mobile Products, P.O. Box R, Kelly Willis Rd., Greenbrier, TN, 37073. The original purchaser bears the cost of shipping and postage.
5. The warranty on replacement parts (or Drop-In) is the unused portion of the original warranty period.
6. This warranty applies only to the original purchase, and only if installed according to the installation instructions provided and complies with local and state codes.
7. Damage or failure resulting from misuse (including failure to seek prompt repair service), misapplication or alterations are the original purchaser's responsibility.
8. Porcelain enamel finished parts are warranted as commercially acceptable only as of the date the product was manufactured. Porcelain is breakable; its care or treatment in use is beyond the control of Atwood.
9. Atwood does not assume responsibility for any loss of use of vehicle, loss of time, inconvenience, expense for gasoline, telephone, travel, lodging, loss or damage to personal property or revenues. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.
10. Any implied warranties are limited to one (1) year. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This Warranty gives you specific legal rights, you may also have other rights which vary from state to state.