

quick start guide

voice-activation skill for Amazon
Alexa

stashcan®



Patent Pending 2021 LockedBrands LLC.

LockedBrands, The StashCan® and the LockedBrands logo are all trademarks of LockedBrands LLC.
All Rights Reserved.

Amazon, Alexa, and all related marks are trademarks of Amazon.com, Inc. or its affiliates.

next

IMPORTANT

before you can use Voice-Activation,
you **MUST**...

1. have your lockbox set up and the
2. StashCan® app downloaded.
3. connect to WiFi.
4. download the Amazon Alexa App.
have a voice profile on your Alexa device.

this guide will walk you through all of the steps. let's get started!

table of contents

getting started.....	4
setting up with Amazon Alexa.....	5
downloading the skill.....	6
linking your Stashcan®.....	7

functions and uses

StashCan Skill commands.....	10
support.....	12

getting started

download the Amazon Alexa App to control
your Stashcan®



Amazon, Alexa, and all related marks are trademarks of Amazon.com, Inc. or its affiliates.




setting up with Amazon Alexa

1. login or create an account with Amazon.
open the app on your device and follow the on screen instructions.




downloading the skill

1. access the “more” menu on the bottom right corner of the screen.
2. press “Skills and Games”.




downloading the skill cont.

1. press Search icon and search for "My Stashcan®".
2. click on the "My Stashcan®" skill.
3. enable the skill by pressing the "ENABLE TO USE" button.



linking your Stashcan®

1. login using your email associated with your
2. StashCan account and password.
enter a 4-digit code into the “voice pin code” box.



Link Account


Done Not Secure — login.lockedbrand AA ↻

Account Login

Email address

Password

Login



Link Account

Done Not Secure — login.lockedbrand AA ↻

A four digit voice code is required, even if you choose to opt out of using it.

The voice code should be changed every 60 days. Return to the account login to update the code.

Step 1: Enter your code.

XXXX

Step 2: Select Opt In to use the code; Opt out to disable.

Opt In (default)


Opt out

Step 3: Press Save

Save

linking your Stashcan®

1. you have the option to either Opt In to use the code or Opt Out to disable the voice code function.
2. press save.
3. grant Permission for the skill to access your Stashcan® information.



you are now ready to use
Alexa to control your
Stashcan®!

*if you opt in, you will be required to say the pin code every time you Ask Alexa to perform a function on your lockbox.

linking your Stashcan®

if you wish to change your use of the voice pin
code,
visit:

<https://login.lockedbrands.com/login/stashcan>

voice-activation functions with Ask Alexa

to use the skill to control your Stashcan®, invoke a function by saying one of the following

- Alexa, tell My Stashcan® to unlock
- Alexa, ask My Stashcan® to change color to.....
(Blue,
Red, Green, Yellow, Orange, Purple, Gray, Navy,
White, & Light Blue)
- Alexa, tell My Stashcan® to change style to.....
(Solid,
Breathing, Solid Night, Breathing Night, and
OFF)

voice-activation functions with Ask Alexa

Cont.

- Alexa, tell My Stashcan® to set brightness to..... (a number from 1 to 100%) percent
- Alexa, tell My Stashcan® to change access time to (any number from 5-10) seconds.

note: you must use the specific phrases and say "My Stashcan®" to invoke the functions or Alexa will not recognize the command.

*access time is the amount of time that the Stashcan® will stay unlocked.

support

Amazon and Amazon Alexa Support

- support can be found on [Amazon.com](https://www.amazon.com/help) under Help > Device and Digital Content Support Voice ID

Stashcan@ support

quick start guide

- [instructions](#)

share access and transfer

- [instructions](#)

master password guide

- [instructions](#)



Patent Pending 2021 LockedBrands LLC.

LockedBrands, The StashCan® and the LockedBrands logo are all trademarks of LockedBrands LLC.
All Rights Reserved.