




PRODUCT SPECIFICATIONS

Dishwasher Rinse Temp THERMOLABEL® Temperature Indicators

The Dishwasher Rinse Temp Themolabel accurately verifies that the dish machine's final rinse water temperature is reaching the necessary 180°F. It can be used with all models of hot water sanitation dishwashers that have an accessible rinse water pipe. Applied to the outside of the rinse water pipe, the label's temperature sensitive square will change from white to black when 180°F is reached. Store labels in a cool, dry place; preferably under refrigeration.

Item Number	RW-180
Unit of Measurement	Package
Labels Per Package	12
Country of Manufacture	USA

Dimensions	3/4" x 2 1/4"
Temperature	180°F/82°C
Waterproof	Water-resistant
Response Time	Approximately 10 seconds
Product Expiration	2 years from date of purchase
Indication Method	Non-toxic white to black color change



Product Instructions:

Locate the rinse water pipe. It is typically a vertical pipe on the right side of the machine towards the rear. Remove label from sheet. Apply to rinse water pipe carefully with the non-adhesive tab extended off pipe. The pipe will still be hot. Protect hands when applying to avoid burns. Run the machine's cycle as normal. The temperature sensitive square will turn black as the temperature is reached. Peel label from pipe using the non-adhesive tab.

Please contact us with any questions about these or any other Paper Thermometer products

Paper Thermometer Company Inc.
 62 Colin Dr | Manchester NH 03103 | USA
 1-877-PTLABEL | t: 603-547-2034

sales@paperthermometer.com | www.paperthermometer.com

