
SUNAOFE

Assembly Manual

Elite67




Please read this manual carefully before any operation and keep it properly for future use.

Customer Service : info@sunaofe.com

FUNCTION DESCRIPTION

Part Names




ACCESSORY LIST Included in Package

A M6*38		B M6*25		C M8*20		M8*35	
Screw	6pcs	Screw	4pcs	Screw	2pcs	Screw	1pcs
E	Ф22*Ф9	FΦ	16*Ф6.5	G of	25*6mm	Н	5#
Washer	3pcs	Washer	4pcs	Washer	2pcs	Spanner	1pcs

INSTALLATION INSTRUCTIONS 15min Assembly Time


STEP 1:

Fit casters into five-star base.



STEP 2:

Insert the bottom end of gas lift into the central hole of the base.




INSTALLATION INSTRUCTIONS

15min Assembly Time


STEP 3:

Tighten the aligned screws(A) and Washer(G, put between armrest and seat cushion as showed) into holes on the seat cushion to fix armrests.



STEP 4:

Tighten the aligned screws(B) and washers(F) into holes on the seat cushion to fix control mechanism.




INSTALLATION INSTRUCTIONS

15min Assembly Time

STEP 5:

Place three screws (D&C) and corresponding washers (E) at the points shown below to connect the chair back to the seat.




INSTALLATION INSTRUCTIONS

15min Assembly Time


STEP 6:

Align the control mechanism hole with the upper end of the gas lift and lower the seat vertically.




PRODUCT FEATURES

Ergonomic Chair




Lumbar Support Adjustment

The pad is designed to be flexible, which allowes it suitable for users with 30mm height adjustment.




Titlting

Press the lever A and then recline on the back of the chair until you reach the preferred angle. Release to lock position, and it could be locked in 3 positions.



3D Armrest Adjustment

Arm height(press the tabs under armrests); arm cap(front-back) & pivot inwards and outwards(angle movement) adjustments.



Seat Height and Sliding

Pull the lever C up to adjust seat height. Release at the proper height. Pull the lever B to slide the seat in and out while seated.

