



TO INSTALL, Mounting holes are 14" apart. Making sure to be level, mark the center of where you want your Photo Rail and measure outward. Drill a 3/16" hole, insert wall anchors and install screws about a 1/4" above the surface. **Please note, fine-tuning screw depth is crucial to functionality.**







