


VINGLI METAL STORAGE CABINET

ASSEMBLY INSTRUCTION



Thank you for purchasing from VINGLI!

Please contact us via email if parts are missing or damaged, we will gladly ship your replacement parts free of charge

4 IMPORTANT

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

RETURN & WARRANTY

Thank you for choosing our product!

We would like to take this opportunity to thank you for choosing VINGLI.

We hope that you are completely satisfied with your purchase, and enjoy it for years to come.

Your satisfaction is our highest pursuit.

Return Policy

VINGLI believes you will absolutely love your Metal Storage Cabinet, but if for some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service organization can answer most concerns and can assist you with any questions you may have about your new product.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

Warranty

VINGLI warrants this product to be free from defects in material and workmanship agrees to remedy any such defect. This warranty covers one year from the date of original purchase. This is solely limited to be repair or replacement of defective parts and no assembly labor is included.

This warranty does not apply to any product which has been improperly assembled, subjected to misuse or abuse or which has been altered or repaired in anyway.

Components repaired or replaced warranted through the remainder of the original warranty period only. The defective components will be repaired or replaced without charge, subject to the terms and conditions described above.

For help with assembly, identifying parts, product information or to order parts, please contact us freely.

BEFORE STARTING

Before Using Product



☐ Read each step carefully before starting. It is very important that each step is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.



☐ Make sure all parts are included. Most board parts are labeled or stamped on the raw edge.





☐ Recommended # of people needed for assembly: 2 Estimated assembly time is 2 hours.



□ Work in a spacious area and near where the unit will be used, preferably on a carpet, or use a piece of the cardboard packaging to protect your floor and product.




☐ For a smooth assembly process, we suggest you keep a lite tightness for all the screws during assembly. After the whole product is assembled, firmly tighten all the screws.


A WARNING:


- -Do not allow children to climb on unit
- -Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over, it must be permanently fixed to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer
- -Avoid sharp objects or corrosive chemicals to prevent damage to the product
- -During assembly, keep parts and packaging materials away from children and pets as there could be potential injury and choking hazards














Top Panel






G Front View




G Back View

COMPONENTS




COMPONENTS




						_
M	Magnet	2PCS		M4*10		
			R		116PC	S
				Screw M6*15		
	Telloll .		S		18PCS	3
Ν	Hook	4PCS		Screw M4*16		
	<u>^</u>				6PCS	
				Screw		
			U		6PCS)
0	/all-mounting Bracket 2PCS			Hinge Bearing		
			V		2PCS	
				Expansion Screw		
P	Shelf Clasp	16PCS	W	M4*8	6PCS	
				Screw		
			X	<u> </u>	2PCS	
_		2PCS		Lock Rod		_
Q	Handles		Y		1PC	
				Screwdriver		
			Z		4PCS	
				Hook		1

Step 1


S





16pcs


Attach the casters to the bottom panel using screw S



Step 2


R






46pcs


Connect side panel A and B respectively to the bottom panel, and secure them together using iron corners and screw R



Step 3

R






46pcs

Connect the top panel D to the side panels using iron corners and screw R


Tips: Please pay attention to distinguish the front and back of the top panel



Step 4


R







20pcs

Facing the back of the cabinet, place back panels F and E into the cabinet and secure them using screw R




Step 5





6pcs


Secure the 2 magnets M onto the top and bottom panels respectively using screw T



Step 6 P 9 16pcs


Put the shelf clasps into the cabinet.


Note that the more curled end should be inside the cabinet. Also, adjust the height setting of the shelf to be at least 4 inches away from the door lock devices to avoid any interference with their use



Step 7 J / 1pcs Q 1pcs

Attach the meeting stile to the left door using screw W And then, install the handle without lock accordingly







Step 9		4pcs		6pcs
	R	4pcs	Z	4pcs

Insert the hinge bearing first and then attach the doors to the cabinet

Remember to attach the hooks accordingly





Secure the cabinet to the wall if needed



FQAs

1. What should I do when I received a defective item or missing parts?

Please feel free to contact VINGLI customer service via the link where you purchased this item with your order ID and pictures of the defective parts. We are eager to help make it right

2. Is it easy to put the screws to the panels?

Yes, as long as you follow the instructions, use the correct screws, and put them into the correct holes. We recommend using an electric drill

3. Why does my Shelf Clasp keep falling off?

Please refer to Step 6th. The more curled end of Shelf Clasp should be inside the cabinet

4. Why does the lock hit the Shelf when I turn the lock?


The height setting of the shelf should be at least 4 inches away from the door lock to avoid any interference with its use


5. What should I do if I still don't know how to assemble the lock according to the manual?

If the schematic diagrams are not clear enough, please contact us to request some pictures of the physical lock assembly process for reference

Supplementary Instructions for Safe Use

WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- •NEVER put a TV on this product.
- •NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- •NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.
- •Do not defeat or remove the drawer interlock system.

This is a permanent label.

Do not remove!

A ATTENTION





Des enfants sont morts du basculement des meubles. Pour réduire le risque de basculement des meubles:

- TOUJOURS installer la retenue de basculement fournie.
- NE JAMAIS mettre de téléviseur sur ce produit.
- NE JAMAIS permettre aux enfants de se tenir debout, de grimper ou de s'accrocher à des tiroirs, des portes ou des étagères.
- N'ouvrez JAMAIS plus d'un tiroir à la fois.
- Placez les objets les plus lourds dans les tiroirs les plus bas.
- Ne désactivez pas et ne retirez pas le système de verrouillage du tiroir.
 Ceci est une étiquette permanente.

Ne pas enlever!

WARNUNG





Kinder sind an einem Möbelkipp gestorben. So verringern Sie das Risiko eines Umkippens von Möbeln:

- · Installieren Sie IMMER die mitgelieferte Kipprückhaltevorrichtung.
- Stellen Sie NIEMALS einen Fernseher an dieses Produkt.
- Lassen Sie Kinder NIEMALS an Schubladen, Türen oder Regalen stehen klettern oder hängen.
- · Öffnen Sie NIEMALS mehr als eine Schublade gleichzeitig.
- · Legen Sie schwerste Gegenstände in die untersten Schubladen.
- Besiegen oder entfernen Sie das Schubladenverriegelungssystem nicht.
 Dies ist ein dauerhaftes Etikett.

Nicht entfernen!