



- The battery controller has a short-circuit protection function: during activation, if the device short circuits, the LED will flash red 3 times and the battery will shut down.
- Your ePen 3 device is only suitable for operation between 0-40°C. If your device is operated outside of this temperature range it may be damaged or stop working.
- The recommended storage temperature for Vype products is between 0-25°C.
- No facilities for repair or supply of parts for this product are available or guaranteed.
- If the button is pressed for more than 8 seconds, the LED will flash and the ePen 3 device will shut down. To restart the ePen 3, follow the 'How to use your Vype ePen 3' instructions.
- Protection provided by the equipment may be impaired if used in a manner not specified by the manufacturer.
- Do not use e-cigarettes when you, or anyone in the vicinity, is using oxygen.
- If you have any queries or doubts about the use of your ePen 3 or any other Vype products, please contact the Vype Customer Care Team.

Disposal and recycling of Vype products

Electrical and electronic goods and batteries should not be disposed of as part of regular household waste, but should be separately collected for recovery and recycling. Please see our website, vype.co.nz, for more information on how to dispose of your Vype products.



THIS PRODUCT MAY BE HAZARDOUS TO HEALTH AND CONTAINS NICOTINE WHICH IS ADDICTIVE. KEEP OUT OF REACH OF CHILDREN.
IF SWALLOWED: Rinse mouth. **IF ON SKIN:** Wash with plenty of soap and water. Call a **POISON CENTRE** or a doctor/physician if you feel unwell.

THIS PRODUCT IS NOT SUITABLE FOR USE BY:

- Persons under the age of 18.
- Persons who are allergic/sensitive to nicotine and any other listed ingredients.
- Pregnant or breast-feeding women.
- Persons who should avoid using tobacco or nicotine products for medical reasons.
- Persons with an unstable heart condition, severe hypertension or diabetes.

IMPORTANT SAFETY INFORMATION:

Immediately stop use of this product and seek medical advice if you experience any of the following: Development of an irregular heartbeat; allergic reaction such as rash, itching or swelling of the tongue, mouth or throat; feeling faint; nausea; headache; or any other unusual or adverse effect. This product is not intended for use by persons with reduced sensory, physical, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.



Vype Customer Care, British American Tobacco (New Zealand) Limited, PO Box 2618, Auckland 1140, New Zealand. T: 0800 897 369 Email: info@vype.co.nz

eLiquid made in the UK. Vype ePen 3 device, USB charging cable and cartridge (excluding eLiquid) made in China. Designed in London.



Model number: EP3

WV_NZ_EP33_STK_LFT01

ePen 3 kit User Guide



Quick Start:



Step one: Insert your ePen 3 cartridge into the ePen 3 battery unit, it will click fit.



Step two: Click on the button 3 times quickly to switch on your ePen 3.



Step three: Simply press down on the button whilst inhaling to enjoy rich vapour at the click of a button. Enjoy!

Read before use. Keep the user guide for future reference.

Know your Vype ePen 3



Tips:

- Each ePen 3 cartridge is designed for single use. You should not attempt to refill as this may lead to leakage and damage your device.
- All Vype eLiquids have been developed bespoke to Vype devices for an optimal vaping experience.

How to use your Vype ePen 3

- For optimal performance, your ePen 3 should be fully charged before first use.
- Remove the silicone cover on the ePen 3 cartridge before clicking it onto the ePen 3 battery.
- To switch on your ePen 3, rapidly click

the button three times.

- For optimum enjoyment and satisfaction it is recommended to close your lips over the cartridge so the tip is inside your mouth, not resting directly on your lips.
- To begin your vaping experience, press the button and hold it down whilst inhaling.
- Only use Vype ePen 3 cartridges with the Vype ePen 3 device.
- The ePen 3 can be switched off by rapidly clicking on the button three times. The ePen 3 will confirm that it has switched off by flashing the LED three times.
- If the ePen 3 remains unused for 10 minutes, it will automatically

switch off and will need to be switched back on to use.

- To confirm whether your ePen 3 is on or off, press the button once. If the ePen 3 is on, the LED will illuminate for three seconds. If the ePen 3 is off the LED will not illuminate.

When to change your Vype ePen 3 cartridge

It's time to change your ePen 3 cartridge when:

- You notice a deterioration in the taste or quality of the vapour.
- Your ePen 3 LED flashes white five times.
- Your ePen 3 stops producing vapour.

If your ePen 3 stops producing vapour and the cartridge is not yet empty, check your

battery is fully charged.

Battery charging indicators on your Vype ePen 3

When the ePen 3 is turned from off to on or when the button is pressed once when the ePen 3 is on, the colour of the LED will indicate the battery level.

- **Green:** Your battery is between 40% and 100% charged.
- **Amber:** Your battery is between 10% and 40% charged.
- **Red:** Your battery is less than 10% charged.

Your ePen 3 battery may run out of charge before the ePen 3 cartridge is finished so don't automatically discard the cartridge when charging the battery as there may

be eLiquid in it.

How to charge your Vype ePen 3

- To charge your ePen 3, attach the USB charging cable supplied with your ePen 3 kit to the micro USB port on the base of the ePen 3.
- Connect the other end of the USB charging cable to the USB port of a computer.
- When charging, the LED on the ePen 3 will indicate the battery level.
- **Green:** Your battery is between 85% and 100% charged.
- **Red solid:** Your battery is less than 85% charged.
- **Red pulsing:** Your battery is less than

10% charged.

- When the LED shows continuous green, the ePen 3 is fully charged and the USB charging cable should be disconnected.
- It should take no longer than 2 hours to fully charge your ePen 3 battery.
- If your ePen 3 LED starts to flash red rapidly whilst charging please disconnect and contact the Vype customer care line.
- You can also charge your ePen 3 using a Vype USB car charger which is available at vype.co.nz.

Important product use information

- To avoid the risk of fire, injury and/or damage to your Vype ePen 3 or other property, only charge your Vype ePen 3 battery with the equipment provided in your Vype ePen 3 kit or with compatible Vype charging accessories (available at vype.co.nz).
- Never leave your battery unattended whilst on charge.
- Never keep loose batteries in your pocket, particularly next to keys or coins.
- Rating input of USB charging cable: DC 5 V 500 mA
- The build-up of dirt inside your Vype ePen 3 cartridge and

the top of your battery unit may prevent you from enjoying your experience and it may disrupt normal charging. To prevent this, check and if necessary detach your ePen 3 cartridge from the ePen 3 battery, clean with a dry cloth and carefully blow into the ePen 3 cartridge to dislodge any build-up of dirt.

- The device will automatically stop charging your ePen 3 battery after a period of 3 hours. It has an overvoltage, an overcurrent and a short-circuit protection function.