



3-way adjustable arm rests
 (forward/back, side-to-side, up and down)
 Press button to adjust arms.




height adjustable lumbar
 Place hands on left and right sides
 to glide up or down.



seat depth
 Lift lever and hold, slide seat forward
 or back, and release lever to lock.



width adjustable arms
 Push lever down and move arms in or out,
 pull lever back up to lock.



back tension
 Controls resistance to body weight.
 Turn knob forward for more resistance
 and backward for less.



seat height adjustment
 To raise the chair, lift your body weight
 and pull lever up. To lower the chair,
 stay seated and pull lever up.



back lock
 Multi-position locking mechanism
 Rotate knob to lock or unlock.