

IMPORTANT!

This electric kit has to be installed by a professional workshop or a suitable qualified person.

The installation instructions must have been read and fully understood before the start of any installation. Please contact your wiring kit provider or the hotline shown in the footer should vou need assistance!

Make sure the vehicle is approved/homologated by the manufacturer to tow a trailer!

Also please check that there is a definite compatibility between this vehicle and the electric kit!

Following the installation of the electric kit, the fitting instructions should be kept together with the vehicle service document and vehicle handbook. The fitting instructions contain important information relating to the use and function of the towing kit as well as for any diagnostic or activation process, that might have to be repeated in the future (e.g. after the performance of a vehicle software update).

All warranty claims will be forfeited if the electric kit or components contained therein are used incorrectly or modified. If a towing socket adaptor has been used to connect to the trailer or bike rack, this must be removed from the trailer socket once the trailer or bike rack has been disconnected

If the trailer or bike rack is not equipped with a rear fog lamp, depending on the towing vehicle type, the correct function of the towing kit cannot be guaranteed. In such cases, a rear fog lamp should be retro fitted.

This towing electric kit will not be covered under warranty if any technical or electrical modifications or software updates have been performed by the vehicle manufacturer after the initial commissioning of the kit. That applies especially to modifications or updates which may cause malfunctions in the trailer socket or any other part of the trailer electrical equipment!

Depending on the type of trailer module used in this electric kit, diagnostic interrogation with the vehicle's electrical system may be limited or will not function. The error memory inside the trailer module may not be able to be accessed by vehicle manufacturers diagnostic system.

Error logs relating to the trailer electrical equipment, that may be generated in the vehicle manufacturers diagnostic system as a result of a test procedure, may be due to the incorrect installation of the towing electric kit or the false activation of the trailer module.

We always recommend whenever possible, the following troubleshooting process:

An analysis of the vehicle's error memory and possibly clearing of all faults before the start of the installation!

Try disconnecting the trailer module from the towing harness and re-start the fault clearing process!
If in doubt, limit the time for troubleshooting to a max of 0,5 hours and call our Technical Support Team!

Please follow our instructions carefully and always test the towing electrics using a true lighting board or a specifically designed bulb tester. If an LED tester is used, ensure it is equipped with correct load resistors or malfunctions will occur!

1/20

This instruction is subject to changes and we reserve the right to make changes to design, colour etc.


All of the data and illustrations may not be an exact representation but the text contained in this instruction must be observed!

ECS Electronics UK The Old Dyehouse Macclesfield Cheshire, SK11 7RN UK

SALE: +44 (0) 7980 847124 TECHNICAL: +44 (0) 7440 202052 WEB: www.ecs-electronicsuk.co.uk

Email-sales: n.lea@ecs-electronics.com Email-technical: t.skinner@ecs-electronics.com

Revision: 3 / 13.05.2019 AU-068-13MU




-ऴॖॕ-	Left (58-L) respectively Right (58-R) tail light		Cigarette lighter / accessory socket
54 (STOP)	Stop light (54) / high mounted, third stop light (54)		Loudspeaker / buzzer
	Turn signal indicator left		Park Distance Control
	Turn signal indicator right	-/	Switch / source of function
	Rear fog light(s)	•	Connect together
Reverse 0	Reversing light(s)	(Disconnect
30+	Permanent power supply / 13pin socket, chamber 9		Look at / See further information
15+	Charging wire for trailer battery / 13pin socket, chamber 10		Look carefully at selected area
	Trailer / trailer recognition	V	Present / Occupied / OK
B+/30	Permanent current power supply	Xare	Not present / Not occupied / Not OK
<u>_</u>	Ground or Earth (31)	$\mathbb{P}((($	Acoustic indication
$\overline{}$	Ground connection battery terminal lug		Attention / important advice
•	Positive connection battery terminal lug	20 Amp.	Fuse / fuse capacity 20 Ampère
		increased when retro	
	The vehicle's cooling capacity may have to be	increased when retroons!!	the battery!
ATTENTION	The vehicle's cooling capacity may have to be	increased when retroons!!	the battery!
Suces	The vehicle's cooling capacity may have to be You must observe the manufacturer's instruction	Increased when retro ons!!	A set terminal must be


ECS Electronics UK The Old Dyehouse Macclesfield Cheshire, SK11 7RN UK


-


5


SALE: +44 (0) 7980 847124 TECHNICAL: +44 (0) 7440 202052 WEB: www.ecs-electronicsuk.co.uk Email-sales: n.lea@ecs-electronics.com Email-technical: t.skinner@ecs-electronics.com Revision: 3 / 13.05.2019 AU-068-13MU 5







































AU-068-13MU

Set up trailer operation



Diagnosis Services or diagnostic methods (local / offline):

Please note:

Always use the latest diagnostic version! The vehicle to be coded must be supported by the diagnostic service provider and already be implemented in the diagnostics version! Please contact your diagnostic service provider in case of any question.

- ODIS
- **Hella Gutmann**
- VCDS
- Autologic Bosch / KTS
- **SP Diagnostic**
- SUN
- Jifeline
- Autocom
- etc. pp.

CODING WITH ODIS

Please note:

The procedure described below for encoding and orientation and can vary greatly depending on the model (motorisation / equipment). If necessary less or further control units will have to be adapted.

After connecting to ODIS, the "69 trailer function" controller has to be set to encoded in the target installation list.

The following may be necessary in the further course of work:

EZE_09 (electronic central electric controller): Diagnosis (possible login code: 31347)

Networking plan Controller self-diagnosis Encode Trailer connection device >installed or: hitch_ecu >installed

Alternative encoding EZE_09 as follows (MY 2017 >>): Self diagnose control unit Access authorization >31347

Adjustment

Integration Trailer control unit > installed

ZKS 46 (Central module convenience system)

trailer monitoring >put on active trailer control unit >installed

SWA_3C (Lane Change Assist) ECU for draw bar >with ECU for draw bar

SW2_CF (Lane Change Assist2) >with ECU for draw bar ECU for draw bar

SCH_17 (Dash panel insert) Trailer >yes

RFK_6C (reverse camera system) equipment_ahk >installed

STF_74 (chassis control system) Trailer >installed

EPH_76 (PDC controller) Trailer >trailer device can be removed manually

DIS_13 (controller distance control (possible login code: 20103) Control module for towing sens >installed

Alternative encoding DIS_13 as follows: Self diagnose control unit Access authorization Encoding >20103

Binary encoding Byte 3 Binary or Hex

>xxxx1xxx

FFF_A5 (front sensor system controller) AĀG >coded

HDE_6D (boot lid electronics controller) Trailer >installed

Important note on encoding and activating in trailer mode The aforementioned settings are carried out in the

wehicle's electrical system and saved locally. During general updates for the vehicle software (for example, within the scope of service or repair work), the settings may be overwritten and deleted under certain circumstances. In this case, the trailer mode activation has to be updated again locally after the update. Diagnostic information relating to the trailer mode that may appear during variance comparisons with the data saved in the manufacturer's works, may form the basis of the local activation.

The following light functions for the trailer are not supported by all towing vehicles with DRL circuit:

- Rear lights
- Side lights
- Numberplate lights

The taillights or dimmed headlights

must be switched on to activate this function!

18/20

ECS Electronics UK The Old Dyehouse Macclesfield Cheshire, SK11 7RN UK

44

43

SALE: +44 (0) 7980 847124 TECHNICAL: +44 (0) 7440 202052 WEB: www.ecs-electronicsuk.co.uk

Email-sales: n.lea@ecs-electronics.com Email-technical: t.skinner@ecs-electronics.com

Revision: 3 / 13.05.2019 AU-068-13MU

