



SPINNING GUIDE SPACING CHART

6'0"	3"	6 5/8"	10 3/4"	15 3/8"	20 3/4"	26 15/16"	34"	41 3/4"	--	--	--
6'6"	3"	6 1/4"	10 1/8"	14 5/8"	19 5/8"	25 1/2"	32 1/4"	40"	--	--	--
7'0"	3 3/8"	7 1/4"	11 5/8"	16 3/4"	22 5/8"	29 3/8"	37"	46"	--	--	--
7'6"	3"	6 1/2"	10 3/8"	14 7/8"	20"	26"	33"	40 7/8"	50"	--	--
8'0"	3 1/4"	7"	11 3/8"	16 3/8"	22 1/8"	28 3/4"	36 1/4"	45"	55"	--	--
8'6"	3"	6 1/2"	10 1/2"	15"	20 1/4"	26 1/4"	33 1/4"	41 1/4"	50 3/8"	61"	--
9'	3 1/4"	7"	11 1/4"	16 1/4"	21 7/8"	28 1/2"	36"	44 5/8"	54 1/2"	66"	--
9'6"	3"	6 3/8"	10 1/4"	14 3/4"	19 7/8"	25 7/8"	32 3/4"	40 5/8"	49 5/8"	60"	72"
10'	3 1/4"	6 7/8"	11 1/8"	16"	21 5/8"	28"	35 3/8"	44"	53 3/4"	65"	78"