



# Salvo Casting Guide Kit Spacing

Spacing measured in inches from tip top ring to guide ring, starting from the tip.

Rod Length	Rear Grip Length*	1	2	3	4	5	6	7	8	9	10	11	12
6'0"	7"	2 3/4"	5 7/8"	9 1/8"	13 1/4"	18 3/4"	24 3/4"	31 3/4"	40"				
6'3"	7"	2 3/4"	5 7/8"	9 1/8"	12 3/4"	17 1/4"	22"	27 5/8"	34 3/4"	43 1/8"			
6'6"	8"	2 3/4"	5 3/4"	9"	12 5/8"	17 1/8"	21 7/8"	28 3/8"	36 1/4"	45 1/8"			
6'9"	9"	2 3/4"	5 3/4"	9"	12 5/8"	17"	22 1/2"	30 1/4"	37 7/8"	47"			
6'10"	9"	2 3/4"	5 3/4"	9"	12 5/8"	17 1/8"	22 3/4"	30 3/8"	38 3/8"	47 7/8"			
7'0"	10"	2 5/8"	5 1/2"	8 5/8"	12 3/8"	16 5/8"	21 5/8"	27 1/4"	33 3/4"	41 1/4"	49 7/8"		
7'2"	10"	2 5/8"	5 1/2"	8 5/8"	12 3/8"	16 5/8"	21 5/8"	27 3/8"	33 7/8"	41 1/2"	51"		
7'3"	10"	2 5/8"	5 1/2"	8 3/4"	12 1/2"	16 3/4"	21 3/4"	27 1/2"	34 1/4"	42 3/8"	52"		
7'4"	11"	2 5/8"	5 1/2"	8 3/4"	12 1/2"	16 3/4"	21 3/4"	27 1/2"	34 1/4"	42 3/8"	52"		
7'6"	11"	2 5/8"	5 1/2"	8 3/4"	12 3/8"	16 5/8"	21 1/4"	26 1/8"	31 1/4"	37 1/8"	44 3/4"	53 7/8"	
7'9"	12"	3 1/8"	6 5/8"	10 3/8"	14 1/2"	19 1/4"	24 1/2"	30 1/2"	37 1/4"	45 3/16"	54 1/8"		
7'11"	12"	3 1/8"	6 5/8"	10 3/8"	14 1/2"	19 1/4"	24 1/2"	30 7/8"	38 1/2"	47"	56 1/2"		
8'0"	12"	3 1/8"	6 1/4"	9 3/4"	14"	18 7/8"	24 3/8"	30 1/2"	38 3/8"	47 1/4"	57 1/4"		
8'6"	12"	3 1/8"	6 1/4"	9 7/8"	14 1/8"	19"	24"	29 5/8"	35 3/4"	43 1/4"	52"	61 3/4"	
9'0"	14"	3 1/8"	6 1/4"	9 7/8"	14 1/8"	19"	23 3/4"	28 1/2"	33 3/4"	39 3/4"	47 1/4"	55 7/8"	65 7/8"

\*Rear Grip Length is measured from the butt to the rear edge of the reel seat.

The guide spacing shown in this chart is a general recommendation suitable for many applications. However, you may need to adjust it slightly to better fit your specific rod blank and application needs.