

RDCA ROD DRYER w/ CLUTCH



The RDS Dryer Clutch Assembly is designed to work exclusively with the CRB RDS Rod Drying System. The Dryer Clutch allows you to stop the rotation of your rod without turning off your RDS Dryer. This allows for complete control and improved finishing during the coating process.

Adjusting the Clutch

1. The tension on the chuck can be increased or decreased at your convenience. To adjust the pressure applied to the Chuck loosen the Set Screw (E) and tighten or loosen the Center Bolt (F) to the appropriate level.
2. Once finished, retighten the Set Screw (E) to lock the Center Bolt (F) in place.

